



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Elcis

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

| Product  | Description                                      |
|--|--|
| <a href="#">I/72E10-2048-5-BZ-L-CL-R</a>       | Encoder  |
| <a href="#">115-1024-10305-BZ-N-CW-R-03</a>    | Encoder  |
| <a href="#">I/115-1024-10305-BZ-Z-CL-R</a>     | Encoder  |
| <a href="#">I/115-1024-10305-BZ-N-CW-R-03</a>  | (I / 115-1024-10305-BZ-N-CW-R03 Optical encoder) |
| <a href="#">59C15-10-1230-BZ-C-VL-R-01</a>     |  |
| <a href="#">I/90-200-1828-BZ-L-CL</a>          | (Encoder Optical encoder)                        |
| <a href="#">I/AZ115R-1000-824-BZ-L-CH</a>      | Incremental encoder                              |
| <a href="#">I/38C8-12-824-B-B-CV-R-01</a>      | encoder  |
| <a href="#">I/59C12-1500-824-B-B-CV-R-05</a>   | RUGGED ENCODER                                   |
| <a href="#">I/59C15-2500-1828-B-B-CV-R-01</a>  | Incremental encoder                              |
| <a href="#">I/62CD-2500-5-BZ-N-CV-R-01</a>     | PINION-ENCODER                                   |
| <a href="#">I/63-5000-5-BZ-Z-CL-R</a>          | Encoder  |
| <a href="#">I/X63 100 824 BZ B CM</a>          | Encoder  |
| <a href="#">I/Z115-2000-824-B-B CM-R</a>       | Incremental Encoder                              |
| <a href="#">L/XEFK601-1828-B-B-1000-1-CM-R</a> | ENCODER  |
| <a href="#">A/XZ390A-G-3600-5-CM5-R-AR</a>     |  |
| <a href="#">EFK150-824-B-B-1000-1-CM-R</a>     | Optischer Drehgeber                              |
| <a href="#">A/X365-G-360-1828-B-F-CD4-R</a>    | Encoder  |
| <a href="#">I/63-5000-5-BZ-C-CL-R</a>          |  |
| <a href="#">Mating connector VLF</a>           |  |
| <a href="#">Q80-500-824-BZ-CW</a>              | Optical encoder                                  |
| <a href="#">Q80-1-824-BZ-CW</a>                | Optical encoder                                  |
| <a href="#">I/40-10-1224-BZ-H-CVK-R-02</a>     |  |
| <a href="#">I/A115T-200-1030-B-Z-CL-R</a>      | Encoder Complete with tachometer type BRB 11/6   |
| <a href="#">I/63-1024-5-BZ-N-CL-R</a>          | Incremental encoder                              |
| <a href="#">I/115K-2000/2000-5/5-9N-N-LL</a>   | Encoder  |
| <a href="#">XV-7210-1000-1828-B-B-CD-R</a>     |  |
| <a href="#">I/ 115-600-1828-M-K-CM-R</a>       |  |
| <a href="#">I/63-5000-5-BZ-N-CL</a>            | Incremental encoder                              |
| <a href="#">I/38Z8-1024-5-BZ-N-CVC-R-01</a>    |  |
| <a href="#">L/EFK300-10305-BZ-Z-100-4-CL-R</a> | Encoder  |
| <a href="#">I/H408-1500-5-BZ-N-CVK-R-02</a>    | Tightening ruler                                 |
| <a href="#">I/ZV38LP-2540-5-BZ-N-CV-R-01</a>   |  |
| <a href="#">I/115T-200-1230-BZ-Z-CL-R</a>      | Tacho Encoder                                    |

| Product  | Description         |
|--|---------------------|
| <a href="#">A/958HP13-12-10-B-DP-0-3PG</a>                                     | Encoder             |
| <a href="#">I/115T-2048-5-BZ-Z-CL-R</a>  | Encoder             |
| <a href="#">A/390-G-256-5-CD4-R</a>  | Encoder             |
| <a href="#">I/63-2000-18285-B-N-CM</a>   | Encoder             |
| <a href="#">I/115-1000-1030-B-L-CL-R</a>                                       | ENCODER             |
| <a href="#">I/115-1024-1230-BZ-Z-CW-R-02</a>                                   | Incremental encoder |
| <a href="#">I/X59CM15-2000-5-BZ-N-CL-R</a>                                     | encoder             |
| <a href="#">I/63-50-824-BZ-B-CM-R</a>  | INCREMENTAL ENCODER |
| <a href="#">Connector VFM</a>  | Connector           |
| <a href="#">I/5910-500-824-BZ-B-CV-R-01</a>                                    | encoder             |
| <a href="#">I/115T-360-824-BZ-B-CM-R</a>                                       | encoder             |
| <a href="#">I/45CC-1000-815-BZ-C-CD</a>  | ENCODER             |
| <a href="#">I/115/1024/1230/BZ/CW</a>  | Incremental encoder |
| <a href="#">I/172CD-2500-5-BZ-N-CL-R</a>                                       | Incremental encoder |
| <a href="#">7210-1250-5-BZ-Z-CL-R</a>  | encoder             |
| <a href="#">L/F3C076-N-W-CV-01</a>   | Encoder             |
| <a href="#">I/63-2500-5-BZ-N-CL-R</a>  | encoder             |
| <a href="#">I/Z59C15-1024-1230-BZ-Z-VL-R-01</a>                                | Incremental encoder |
| <a href="#">I/63S-10000-5-BZ-Z-CL-R</a>  | encoder             |
| <a href="#">I/38C6-150-824-BZ-P-CV-R-02</a>                                    | encoder             |
| <a href="#">I/A9-466-500-5-BZ-N-CV-R-01</a>                                    | Encoder             |
| <a href="#">VD4F</a>   | connector           |
| <a href="#">I/62CD-267-824-BZ-B-VM-R-01</a>                                    | Encoder             |
| <a href="#">I/7210-1250-5-BZ-C-GL-R</a>  | Encoder             |
| <a href="#">V4-SS-2-U-AT</a>   | Encoder             |
| <a href="#">I/90A-10000-5-BZ-N-CW-0</a>  | encoder             |
| <a href="#">I/58H-900-5-BZ-N-CV-R-01</a>                                       | encoder             |
| <a href="#">I/XY63-1000-824-B-CM-R</a>   | encoder             |
| <a href="#">A/MM1001-B-2048-1828-KP-L-CM6</a>                                  | Encoder             |
| <a href="#">F3-2500-5-BZ-N-CL-R</a>  | Encoder             |
| <a href="#">I/F3-2500-5-BZ-N-CL-R old code/ I/63-2500-5-BZ-N-CL-R new code</a> | Encoder             |
| <a href="#">V/XMVP51-100-5-B-N-VM5-08S</a>                                     | complete device     |
| <a href="#">I/XA59C12-60-824-B-B-CV-</a>                                       | Incremental encoder |
| <a href="#">I/59C15-10-1230-BZ-Z-VL-R-03</a>                                   |                     |
| <a href="#">I/X7210-1000-1828-B-B-CD-R</a>                                     | Encoder             |
| <a href="#">I/Z115-720-824-BZ-B-CM-R</a>                                       | Incremental encoder |
| <a href="#">I/Z115-2000-824/5-B-N-CM-R</a>                                     | Incremental Encoder |
| <a href="#">F3-5000-5-BZ-N-CL</a>  |                     |
| <a href="#">I/Z115-720-824/5-B-N-CM-R</a>                                      | Encoder             |
| <a href="#">I/X59CM15-1024-5-BZ-N-CL-R</a>                                     |                     |
| <a href="#">I/58S-2000-5-BZ-N-CL-R</a>   | Encoder             |
| <a href="#">58S</a>  | Encoder             |
| <a href="#">I/115-5-1230-BZ-Z-CL-R</a>   | encoder             |

| Product  | Description                      |
|--|----------------------------------|
| <a href="#">A/959CP12-12-15-DP-0-3PG</a>                           |                                  |
| <a href="#">I/X115-500-815-BZ-Z-CM-R</a>                           | Encoder                          |
| <a href="#">I/X59CA14-1024-85/85-5-N-CC-R-01</a>                   | ENCODER                          |
| <a href="#">I/XYM63-500-5-BZ-C-CL-R</a>                            | encoder                          |
| <a href="#">I/7210-1250-5-BZ-Z-CL-R</a>                            | Optical rotary encoder           |
| <a href="#">I/63S-180-1828-BZ-L-CH-R</a>                           |                                  |
| <a href="#">I/63-1500-824-B-B-CM-R</a>                             | Encoder                          |
| <a href="#">I/E6-300-18728-BZ-B-CD-MG1820053</a>                   |                                  |
| <a href="#">I/115-1024-815-B-Z-CM</a>                              | Encoder                          |
| <a href="#">ESG 10/10/25</a>                                       |                                  |
| <a href="#">I/79B-1-1224-B-H-CVK-02</a>                            |                                  |
| <a href="#">I/46P8-2250-1828-BZ-B-CV-R-01</a>                      | encoder                          |
| <a href="#">BRB 11/6</a>   | Tachymetric dynamo               |
| <a href="#">I/H6310-1250-5-BZ-CM</a>                               |                                  |
| <a href="#">X46P6-140-1828-BZ-B-CV-R-07</a>                        | Encoder incrementale             |
| <a href="#">I/115-4096-5-B-N-CM-R</a>                              | encoder                          |
| <a href="#">I/58H-1250-1030-BZ-L-CV-01</a>                         | ENCODER                          |
| <a href="#">I/58H-100-530-BZ-Z-CV-R-02</a>                         | Encoder                          |
| <a href="#">A/959CP12-12-15-B-DP-0-3PG</a>                         | encoder                          |
| <a href="#">A/H759CP16-14-15-B-DP-0-3PG</a>                        |                                  |
| <a href="#">I/ 45CC-2000-5-BZ-N-CD</a>                             | Encoder                          |
| <a href="#">I/115-2048-1230-BZ-Z-CW-R-02</a>                       |                                  |
| <a href="#">L/XWF500-5-BZ-C-100-4-CL-R</a>                         | Encoder                          |
| <a href="#">I/Z59C15-150-824-BZ-CV-R-03</a>                        | encoder                          |
| <a href="#">I/Z0B80EXS5-1024-18285-BZ-N-CV1-R-05 Z=CUSC.STAGNI</a> | EXPLOSION-RESISTANT ENCODER      |
| <a href="#">I/64C-5000-5-BZ-N-CD-R</a>                             |                                  |
| <a href="#">I/X68-500-5-BZ-N-CD-R</a>                              |                                  |
| <a href="#">I/V466-2500-5-BZ-N-CV-R-01</a>                         |                                  |
| <a href="#">I/115-1000-815 BZ-Z-CL-R</a>                           | Incremental encoder              |
| <a href="#">I/A7210-5-1230-BZ-Z-CL-R</a>                           | Encoder                          |
| <a href="#">L/23RPC-100-05</a>                                     | Potentiometric Linear Transducer |
| <a href="#">I/X46P6-125-1828-BZ-B-CV-R-07</a>                      | Incremental Encoder              |
| <a href="#">I/X90A-1400-5-BZ-Z-VG-R-0.50</a>                       | Encoder                          |
| <a href="#">I/59C12-50-824-B-B-CV-R-05</a>                         | Encoder                          |
| <a href="#">I/30-100-1224-BZ-H-CVK-03</a>                          | Encoder                          |
| <a href="#">I/X115-1024-5-BZ-N-CL-R</a>                            |                                  |
| <a href="#">I/72R10-3600-5-BZ-Z-CL-R</a>                           | Encoder                          |
| <a href="#">I/45CC-10000-5-BZ-N-CD</a>                             | Encoder                          |
| <a href="#">I/59C15-10-1030-M-B-CV-R-01</a>                        | encoder                          |
| <a href="#">I/38-1200-5-B-N-CV-R-02</a>                            | Encoder                          |
| <a href="#">A/X MM58H3-G-4096-1030-S-CV-01</a>                     | encoder                          |
| <a href="#">I/A115T-50-1230-BZ-Z-CL-R</a>                          | Incremental encoder              |
| <a href="#">115T-1000-1230-BZ-C-CL-R</a>                           | Incremental encoder              |

| Product  | Description         |
|--|---------------------|
| <a href="#">I/115T-1000-1230-BZ-Z-CL-R</a>         |                     |
| <a href="#">I/7210-50-824-B-B-CM-R</a>             | ENCODER             |
| <a href="#">I/58H-6000-824/5-BZ-N-CL-R</a>         |                     |
| <a href="#">I/115-1024-1230-BZ-Z-CL-R</a>          | Incremental encoder |
| <a href="#">I/58S-2500-5-BZ-N-VS-01</a>            | Encoder             |
| <a href="#">I/90K-10000/10000-82/82-9Z-Z-LL-R</a>  | encoder             |
| <a href="#">I/X486-100-824/5-BZ-N-CV-R-02</a>      | Incremental Encoder |
| <a href="#">9601129 1 01/15</a>                    | encoder             |
| <a href="#">I/58S-900-5-BZ-N-CW-R-01</a>           |                     |
| <a href="#">L/XWFK200-5-BZ-N-100-4-CL-R</a>        | Encoder             |
| <a href="#">I/X64-1500-824-BZ-U-CD</a>             | encoder             |
| <a href="#">E6-500-1030-B-B CV-01</a>              |                     |
| <a href="#">I/90D-5000-1828-BZ-Z-CL</a>            | Encoder             |
| <a href="#">I/115-1250-1230-BZ-Z-CL-R</a>          |                     |
| <a href="#">I/115R-360-824-BZ-B-CL-R</a>           | Encoder             |
| <a href="#">I/90D-5000-1828-BZ-L-CL</a>            | Encoder             |
| <a href="#">I/63-1000-824/5-B-N-CM</a>             | Encoder             |
| <a href="#">I/115-1000-1230-BZ-Z-CL-R</a>          | Encoder             |
| <a href="#">I/80-360-1030-B-B-CP-R</a>             | Incremental encoder |
| <a href="#">I/59Z12-1000-1030-BZ-B-CV-R-01</a>     | Encoder             |
| <a href="#">ESM6-6-20</a>                          | Propeller joint     |
| <a href="#">I/X46P6-140-1828-BZ-B-CV-R-07</a>      | Incremental encoder |
| <a href="#">I/C115R-1000-815-B-Z-CL-R</a>          | Encoder             |
| <a href="#">I/115TB-1024-1230-BZ-Z-CV-R-01</a>     | Encoder             |
| <a href="#">I/115R-1000-5-B-Z-CL-R</a>             | Incremental encoder |
| <a href="#">I/45CC-200-5-BZ-N-CD</a>               | Encoder             |
| <a href="#">I/XYM63-500-1828-BZ-B-CM</a>           | Encoder             |
| <a href="#">I/XYM63-1000-5-BZ-Z-CL-R</a>           | Encoder             |
| <a href="#">I/63S-1024-1828-BZ-L-CH-R</a>          |                     |
| <a href="#">I/63S-360-1828-BZ-L-CH-R</a>           | incremental encoder |
| <a href="#">I/A7210-10-1230-BZ-Z-CL-R</a>          | encoder             |
| <a href="#">I/Z115-720-824-B-B CW-R-01</a>         | Incremental encoder |
| <a href="#">I/38C6-2500-5-BZ-N-CV-R-02</a>         | encoder             |
| <a href="#">I/X47RC8-500-824-M-U-CQ1-R</a>         | Incremental encoder |
| <a href="#">I/40Z635-1000-5-BZ-N-CVK-R-02</a>      | Encoder             |
| <a href="#">L/EFK300-1030-P-6-P-P-CD</a>           |                     |
| <a href="#">VDF female flying connector</a>        |                     |
| <a href="#">I/XYM63-500-5-BZ-Z-CL-R</a>            | incremental encoder |
| <a href="#">I/115-1000-1828-BZ-B-CM-R</a>          | encoder             |
| <a href="#">I/ X59ZMA15-5000-824/5-B-N-CV-R-05</a> |                     |
| <a href="#">I/Z115-2000-824-B-B CW-R-01</a>        |                     |
| <a href="#">I / 115-500-824 / 5-BZ-N-CW-R-01</a>   |                     |
| <a href="#">A/XZ390-G-3600-824-B-CD4-R</a>         | encoder             |

| Product   | Description              |
|---|--------------------------|
| <a href="#">I/W59C12-2880-5-BZ-N-CL-R</a>               | Incremental encoder      |
| <a href="#">I/7210-100-5-BZ-H-CM-R</a>                  | Encoder                  |
| <a href="#">I/XLA90A-1024-1828/5-BZ-N-CW-R-05</a>       | Incremental encoder      |
| <a href="#">I/45CC-1000-5-BZ-N-CD</a>                   | Incremental encoder      |
| <a href="#">I/E6-120-1828-BZ-B-CD</a>                   | Incremental Encoder      |
| <a href="#">I/63-150-824-BZ-B-CM-R</a>                  | encoder                  |
| <a href="#">I/63-300-824-BZ-B-CM-R</a>                  | encoder                  |
| <a href="#">I/63-230-824-BZ-B-CM-R</a>                  | encoder                  |
| <a href="#">A/XMM901-G-1024-1828-KP-CV-01</a>           | Encoder                  |
| <a href="#">A/390-G-4096-1828-KP-CV-01</a>              | Encoder                  |
| <a href="#">I/X90A-1400-5-BZ-N-VG-R-0.50</a>            | Incremental encoder      |
| <a href="#">I/45CC-1000-5-BZ-N-VL-R-0.30</a>            | incremental encoder      |
| <a href="#">10 m long Cable</a>                         | wired                    |
| <a href="#">I/59C10-14400-5-BZ-N-VL-R-01</a>            | Encoder                  |
| <a href="#">I/4610-360-1828-BZ-P-CV-R-07</a>            |                          |
| <a href="#">I/63-1500-824-B-B-CM-R</a>                  | Encoder                  |
| <a href="#">I/H6310-1024-528-B-Z-CW-R-03</a>            | Incremental encoder      |
| <a href="#">I/Z115-720-824-B-B-CM-R</a>                 | Incremental Encoder      |
| <a href="#">I/59C15-10-1230-BZ-Z-VL-R-01</a>            |                          |
| <a href="#">I/58H-25-1030-B-B-CE-R</a>                  | Encoder                  |
| <a href="#">L/XF5C075-N-24-I-CV-03</a>                  |                          |
| <a href="#">A/958HC12-12-10-B-C2-W-3PG</a>              | CANopen absolute encoder |
| <a href="#">21004095 2 04/21</a>                        | Encoder                  |
| <a href="#">I/63S-5000-5-BZ-N-CL-R</a>                  | Incremental encoder      |
| <a href="#">I/68-2500-5-BZ-N-CV-R-03</a>                | Incremental encoder      |
| <a href="#">I/115TB-2000-824/5-BZ-N-CL-R</a>            | Encoder                  |
| <a href="#">A/390-D-360-1828-KP-L-CM5-R</a>             | Absolute encoder         |
| <a href="#">cable for (A/390-D-360-1828-KP-L-CM5-R)</a> | Encoder cable            |
| <a href="#">I/Y90A-1000-1230-BZ-Z-CL-R</a>              | Incremental encoder      |
| <a href="#">I/7210-500-5-BZ-Z-CL-R</a>                  |                          |
| <a href="#">L/CR80-200-824-BZ-B-100-1-CV-01</a>         | Linear transducer        |
| <a href="#">115TB-1024-1230-BZ-C-CL-R old code/ I/</a>  |                          |
| <a href="#">I/Z115-720-824-B-B CW-R 09</a>              | Encoder                  |
| <a href="#">I/115TB-1024-1230-BZ-Z-CL-R</a>             | centrifugal relay        |
| <a href="#">I/80-2500-5-B-N-CL-R</a>                    | Incremental encoder      |
| <a href="#">59C15-150-815-B-C--CM-R</a>                 | encoder                  |
| <a href="#">I/59C15-150-815-B-Z-CM-R</a>                | ENCODER                  |
| <a href="#">L/YEFK300-1030-BZ-L-100-4-CL-R</a>          | Encoder                  |
| <a href="#">L/XWF500-5-BZ-Z-100-4-CL-R</a>              |                          |
| <a href="#">I/X59ZP15-25-1828-B-B-VL-R-01</a>           |                          |
| <a href="#">I/63S-10000-815-BZ-Z-CL-R</a>               | Incremental encoder      |
| <a href="#">I/115T-500-5-BZ-N-CL-R</a>                  |                          |
| <a href="#">I/Y90A-1024-1230-BZ-Z-CL-R</a>              |                          |

| Product  | Description                     |
|--|---------------------------------|
| <a href="#">I/115TB-1024-10305-BZ-Z-CV-R-02</a>  |                                 |
| <a href="#">1/115-1024-10305-BZ-Z-CL-R</a>   |                                 |
| <a href="#">I/80EXS5-500-5-BZ-N-CV1-R-01</a>   |                                 |
| <a href="#">L/XWFK200-5-BZ-N-100-4-CL</a>  |                                 |
| <a href="#">I/W59C12-2400-5-BZ-N-CL-R</a>  |                                 |
| <a href="#">I/58S-360-5-BZ-N-CW-R-01</a>   |                                 |
| <a href="#">I W90-3000-1828-b-l-cl-r</a>   | Incremental encoder             |
| <a href="#">I/ZM115-1024-1030-B-L-CM-R</a>   |                                 |
| <a href="#">I/38C6-2500-5-BZ-N-CV-R-01</a>   |                                 |
| <a href="#">I/QZD63-8192-5-BZ-N-SL-R</a>   | Encoder                         |
| <a href="#">I/X63S-256-824-MZ-B-CV-R-01</a>  | INCREMENTAL ENCODER             |
| <a href="#">L/XEF500—P-W-P-P-CV4-R-0,75 X=9405018</a>                                    | INCREMENTAL/ANALOG WIRE ENCODER |
| <a href="#">VEF</a>  | Female steering wheel connector |
| <a href="#">S.A.C. 1420</a>  | Signal converter                |
| <a href="#">58796</a>  | Cavo                            |
| <a href="#">I/63-5000-5-M-N-CL-R</a>   |                                 |
| <a href="#">1/115-1000-1030-B-L-CL-R</a>   | ENCODER                         |
| <a href="#">I/115-1024-824-BZ-B-CM-R</a>   | ENCODER                         |
| <a href="#">I/63-50-824-B-CM</a>   | Incremental encoder             |
| <a href="#">I/M50S-600-530-BZ-R-CV-02</a>  | Incremental Encoder             |
| <a href="#">I/M50-600-1224-BZ-R-CVK-02</a>   | Incremental Encoder             |
| <a href="#">I/XZH638-1000-824-BZ-B-VJ-2,50</a>   | Incremental encoder             |
| <a href="#">I/XLA59ZMA15-1024-824-BZ-L-CV</a>  | ENCODER                         |
| <a href="#">I/XLA59ZMA15-1024-824-BZ-L-CV-R-01</a>                                       | Incremental encoder             |
| <a href="#">I/63S-10000-18285-B-N-CM-R</a>   | Incremental encoder             |
| <a href="#">A/368-G-1024-824-KP-CM5-R</a>  | Absolute encoder                |
| <a href="#">1/115-1024-1230-BZ-Z-CL-R</a>  | Incremental encoder             |
| <a href="#">I/56QE-1000-1828-B-B-CE-R</a>  | Incremental encoder             |
| <a href="#">I/K90CBB20-1024-1030-BZ-Z-CH6-R</a>  | Incremental encoder             |
| <a href="#">I/115T-2048-5-BZ-N-CL-R</a>  |                                 |
| <a href="#">A7210-1024-1230-BZ-C-CL-R old code/ I/A7210-1024-1230-BZ-Z-CL-R new code</a> | Incremental encoder             |
| <a href="#">I/A7210-1024-1230-BZ-Z-CL-R</a>  | Incremental encoder             |
| <a href="#">I/58H-1024-1828-BZ-B-CM-R</a>  | Incremental encoder             |
| <a href="#">I/X46P6-140-1828-BZ-B-CV-R-07 X = 9509149</a>                                | Incremental encoder             |
| <a href="#">I/64C-2000-824-BZ-P-CD</a>   | Incremental encoder             |
| <a href="#">I/115-1024-18305-BZ-C-CL-R</a>   | Encoder incrementale            |
| <a href="#">I/Z59C15-1024-18285-BZ-N-CW-R03</a>  | encoder                         |
| <a href="#">I/X115T-1024-5-BZ-N-CL-R</a>   | Incremental encoder             |
| <a href="#">I/115TB-1024-10305-BZ-N-CV-R-03</a>  | Increment Encoder               |
| <a href="#">I/Z 59C15-100-1230-BZ-Z-VL-R</a>   | Incremental encoder             |
| <a href="#">I/115T-1024-5-BZ-N-CL-R</a>  |                                 |
| <a href="#">Dynamo BRB11/6</a>   |                                 |
| <a href="#">I/X59C15-500-5-BZ-N-CL-R</a>   |                                 |

| Product   | Description         |
|---|---------------------|
| <a href="#">I/Z115-200-824/5 B-N-CM-R</a>         |                     |
| <a href="#">I/63-300-5-BZ-N-CL-R</a>              | Incremental encoder |
| <a href="#">1/X 46P6 140-1828-BZ-B-CV-R-07</a>    | Incremental encoder |
| <a href="#">I/115-1024-1030-BZ-L-CW-R-02</a>      |                     |
| <a href="#">I/115-720-824-BZ-B-CM-R</a>           |                     |
| <a href="#">I/635005BZNCLR</a>                    | Incremental encoder |
| <a href="#">I/115T-600-824-B-B-CM-R</a>           | Incremental encoder |
| <a href="#">I/X59ZP15-25-1828-B-B-VL-R-02</a>     |                     |
| <a href="#">I/115T-3600-1828-B-B-B-CV-R</a>       | ENCODER             |
| <a href="#">I/LM159A-5000-824/5-BZ-N-CV-B-02</a>  | Encoder             |
| <a href="#">I/115-1024-1230-B-Z-CM-R</a>          | Incremental Encoder |
| <a href="#">I/E6-320-1828-BZ-B-CD</a>             |                     |
| <a href="#">I/E6-120-1828-M-B-CD</a>              | Incremental Encoder |
| <a href="#">mod. I/E6-120-1828-M-B-CD</a>         | Incremental Encoder |
| <a href="#">I/115-1000-815-bz-c-cl-r</a>          | Incremental Encoder |
| <a href="#">I/X63S-5000-815-BZ-Z-CL-R</a>         | Incremental Encoder |
| <a href="#">I/115R-1000-815-BZ-Z-CL-R</a>         |                     |
| <a href="#">I/58S-256-5-BZ-N-SL-R</a>             |                     |
| <a href="#">MS3108A18-1S</a>                      |                     |
| <a href="#">I/W59C12-2400-5-BZ-N-CL</a>           |                     |
| <a href="#">I/30 -100 -1224 -BZ - H -CVK-03</a>   |                     |
| <a href="#">I/X115-1000-815-BZ-C-CM-R-X</a>       | Encoder             |
| <a href="#">I/X115-1000-815-BZ-C-CL-R X</a>       | Encoder             |
| <a href="#">L/F5C100-N-24-6-CV-03</a>             | Wire encoder        |
| <a href="#">L/EF500-1830-P-6-P-P-CW-R-01</a>      | Wire encoder        |
| <a href="#">I/Y115-1000-1828-BZ-B-CM-R</a>        |                     |
| <a href="#">I/115K-1024/1024-45/45-9C-C-LL-R</a>  | Incremental encoder |
| <a href="#">I/59Z12-600-1030-BZ-B-CV-R-03</a>     | PULSE ENCODER       |
| <a href="#">I/63SC-1024-18285- BZ-N-CL</a>        |                     |
| <a href="#">A/X363-G-360-1828-KP-CM5</a>          | Absolute encoder    |
| <a href="#">I/115-1024-10305-BZ-N-CL-R</a>        | Incremental Encoder |
| <a href="#">I/59ZP15-500-1828-BZ-B-CV-R-01</a>    | encoder             |
| <a href="#">I/63-1000-824/5-B-N-CM-R</a>          |                     |
| <a href="#">I/7210-600-5-BZ-C-CL-R</a>            |                     |
| <a href="#">I/7210-1000-824-BZ-B-CM-R</a>         | Encoder             |
| <a href="#">I/115R-2000-5-BZ-C-CL-R</a>           |                     |
| <a href="#">I/58S-6000-5-BZ-N-CL-R</a>            |                     |
| <a href="#">I/X59CA14-1024-85/85-5N-N-CC-R-01</a> |                     |
| <a href="#">I/63-360-824-BZ-B-CM-R</a>            | Encoder             |
| <a href="#">I/XE6-500-815-BZ-C-CV-R-01</a>        | Encoder             |
| <a href="#">I/58H-5-1030-B-B-CE-R</a>             | Encoder             |
| <a href="#">I/100D-18000-5-BZ-N-CV-R</a>          |                     |
| <a href="#">I/63S-1000-1828-BZ-L-CH-R</a>         | Incremental encoder |



| Product   | Description               |
|---|---------------------------|
| <a href="#">I/X63-3000-824-BZ-Z-CL-R</a>                  | Encoder                   |
| <a href="#">V/JMVP51S-100-5-B-N-V5A-08S</a>               | Portable handwheel        |
| <a href="#">I/X47RC8-500-824-B-B-CQ1-R</a>                | Encoder                   |
| <a href="#">I/X115T-1000-815-BZ-C-MS-R</a>                |                           |
| <a href="#">I/115-1024-10305-BZ-C-CL-R</a>                |                           |
| <a href="#">I/X59ZP10-512-1828-BZ-B-CV-R-05</a>           | Encoder                   |
| <a href="#">I/170C50-90000-5-BZ-N-CL-R</a>                | encoder                   |
| <a href="#">I/115T-500-824-BZ-B-CM-R</a>                  | Incremental encoder       |
| <a href="#">A/9115P13-12-11-B-DP-0-3PG</a>                |                           |
| <a href="#">I/58H-1000-824-B-B-CM-R</a>                   | Encoder                   |
| <a href="#">I/XA59CA12-1024 1828-BZ-L-CV-R-10</a>         | Encoder- Rotational       |
| <a href="#">I/468-50-5-B-CV-R-01</a>                      | INCREMENTAL ENCODER       |
| <a href="#">I/63SC-36000-5-BZ-N- CM-R</a>                 | Incremental encoder       |
| <a href="#">VME</a>                                       | Connector                 |
| <a href="#">1548</a>                                      | Servo-mount pawl          |
| <a href="#">I/56CJ8-500-1828-BZ-B-CV-R01</a>              | Incremental encoder       |
| <a href="#">I/40Z12 2500-1224-BZ-CVK-R02</a>              | Incremental encoder       |
| <a href="#">I/58S-2500-1828-BZ-P-CW-03</a>                | Encoder                   |
| <a href="#">I/40Z12 2500-1224-BZ-H-CVK-R02</a>            | Incremental encoder       |
| <a href="#">I/S58S-2000-5-BZ-N-SL-R</a>                   | Encoder                   |
| <a href="#">I/63-3600-824-BZ-B-CW-01</a>                  | Incremental encoder       |
| <a href="#">I/7210-1024-824-B-B-CV-R-01</a>               |                           |
| <a href="#">I/XS59CA15-10000-815-BZ-Z-VL-R-0.30</a>       | encoder                   |
| <a href="#">P/XPMV63X-10-24-6-CM-R</a>                    | Absolute encoder          |
| <a href="#">M/M56CJ8-256-5-B-B-CV-R-01</a>                | Encoder                   |
| <a href="#">I/115-1024-10305-B-Z-CM-R</a>                 | Incremental encoder       |
| <a href="#">958HP12-12-10-B-DP-W-3PG</a>                  | Profibus absolute encoder |
| <a href="#">A/958HP12-12-10-B-DP-W-3PG</a>                | Encoder                   |
| <a href="#">I/XYM63-1000-5-BZ-C-CL-R</a>                  | Encoder                   |
| <a href="#">115R-2000-5-BZ-N-CL-R</a>                     | ENCODER                   |
| <a href="#">L/MEFK300-1828-BZ-Q-100-1-SM-R</a>            | Encoder                   |
| <a href="#">I/58-1000-824-BZ-B-CM-R</a>                   |                           |
| <a href="#">I/XAL59ZMA15-1024-824-BZ-L-CV-R-01</a>        | ENCODER                   |
| <a href="#">I/Z59C15-100-1230-BZ-Z-VL-R-01</a>            | encoder                   |
| <a href="#">I/LY90A-1024-1230-BZ-Z-CL-R</a>               | encoder                   |
| <a href="#">I/W59C12-2000-5-BZ-N-CL-R</a>                 | Incremental encoder       |
| <a href="#">X59ZMA15-5000-824-BZ-CV-R-05 X=MOLLA 81CM</a> | Encoder                   |
| <a href="#">90D-10000-824-BZ-B-VM-R-01</a>                | Encoder                   |
| <a href="#">I/X45CC-400-1828-BZ-B-CV-08</a>               | Incremental encoder       |
| <a href="#">XF6-500-815-BZ-C-CV-R-01 / 612175 5</a>       | Encoder                   |
| <a href="#">M/M56CJ8-500-1828-BZ-B-CV-R-01</a>            | Encoder incrementale      |
| <a href="#">I/X47RC8-60-824-M-CQ1-R</a>                   | Incremental encoder       |
| <a href="#">I/63S-1024- 1030-BZ-Z</a>                     |                           |

| <b>Product</b>                                 | <b>Description</b>  |
|--|---------------------|
| <a href="#">I/63/180/824/B/CM</a>              | Incremental encoder |
| <a href="#">I/A 90A-200-18285-BN-CW-R-01</a>   | Incremental encoder |
| <a href="#">I/59C15-1024-1230-BZ-C-VL-R-03</a> | Incremental encoder |
| <a href="#">I/159-500-824-B-B-CM-R</a>         | Incremental encoder |
| <a href="#">L/F3C075-N-24-6-CV-02</a>          | Wire transducer     |
| <a href="#">I/63-720-824-BZ-B-CM-R</a>         | Incremental encoder |
| <a href="#">I/X 64-2000-824-BZ-B-CD</a>        | Incremental encoder |
| <a href="#">I/59C12-1500-5-B-Z-CV-R05</a>      | Incremental encoder |
| <a href="#">1/115-1024-10305-BZ-N-CW-R-03</a>  | Incremental encoder |