



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Fatek

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">FBs-40MCT2-AC</a>	Controller PLC
<a href="#">PLC FBs-60MCR2-AC</a>	Controller
<a href="#">PLC FBs-CM55</a>	Module PLC
<a href="#">FBS-CBE</a>	Ethernet Communication Board
<a href="#">FBs-60MCR2-D24</a>	Relay
<a href="#">PLC FBs-4A2D</a>	PLC Module
<a href="#">FBs-CM55E</a>	Module PLC
<a href="#">PLC FBs-40MCT2-AC</a>	Controller
<a href="#">FBS-60MAR</a>	Basic Main Unit PLC
<a href="#">FBs-40MAR2-D24</a>	PLC Controller
<a href="#">FBs-8XYR</a>	PLC Module
<a href="#">FBs-8YR</a>	Module PLC
<a href="#">FBs-2DA</a>	PLC Module
<a href="#">FBS-60MCR</a>	High-Performance Main Unit PLC
<a href="#">FBs-14MCR2-D24</a>	Controller PLC
<a href="#">FBs-CB5</a>	COMMUNICATION MODULES
<a href="#">FBs-32MAR2-AC</a>	PLC Controller
<a href="#">FBs-CBEH-8</a>	PLC module
<a href="#">FBs-60MAT2-D24</a>	Advanced Compact PLC
<a href="#">P5070S</a>	Interface
<a href="#">FBS-10MCT</a>	Micro Economical PLC
<a href="#">FBS-60MCT</a>	PLC Controller
<a href="#">FBs-24X</a>	PLC Module
<a href="#">FBS-CM25E</a>	PLC Module
<a href="#">FBs-CB25</a>	PLC Module
<a href="#">FBs-40XYR</a>	Digital I/O Expansion Module
<a href="#">FBs-40MCR2-AC</a>	PLC Controller
<a href="#">FBS-40MAR2-AC</a>	Basic PLC Controller
<a href="#">FBs-232P0-9F-150</a>	Cable
<a href="#">FBs-10MCT2-AC</a>	PLC driver
<a href="#">FBS-16RTD</a>	RTD Temperature Input Module
<a href="#">FBs-8YT</a>	Digital Output Module
<a href="#">FBS-8YJ</a>	Digital Output Module
<a href="#">FBs-20MCR2-AC</a>	Advanced PLC Controller
<a href="#">PLC FBs-40XYR-AC</a>	Module

Product	Description
<a href="#">HMI 4.3" / TFT / 16.7M COLOURS / RESOLUTION 480x272</a>	Panel
<a href="#">PLC B1-8XYJ-S</a>	modulus
<a href="#">FBS-40MCT2-D24</a>	Advanced PLC Controller
<a href="#">FBs-8EY</a>	PLC DIO Expansion Module
<a href="#">Fbs-40MC</a>	Automat PC
<a href="#">FBs-40MCJ2-AC</a>	PLC
<a href="#">FBs-10MCR2-AC</a>	Sterownik PLC
<a href="#">ADP-24V-4A</a>	Switching Power Supply
<a href="#">FBS-24MAR2-D24</a>	PLC driver
<a href="#">FBs-20MAT2-AC</a>	PLC Controller
<a href="#">ADP-24V-2A</a>	Power Supply
<a href="#">P5102S</a>	HMI
<a href="#">FBS-44MNT2-AC</a>	NCPositioningMainUnit
<a href="#">FBs-24MCJ2-D24</a>	controller
<a href="#">PLC FBs-16RTD</a>	Temperature Input Module
<a href="#">FBS-20MCT/J</a>	Thrust direction indicator
<a href="#">FBs-20X</a>	PLC Module
<a href="#">FBS-44MNR2-AC</a>	PLC Controller
<a href="#">FBS-3SSI</a>	Synchronous Serial Interface Module
<a href="#">B1-14-MT2-D24-S</a>	Compact PLC Main Unit
<a href="#">B1-8YTS</a>	Digital Output Module
<a href="#">B1-L4AD-S</a>	Analog Input Module
<a href="#">B1-CM25E</a>	Module PLC
<a href="#">B1-16XYTS</a>	Digital Input/Output Module
<a href="#">communication cable for FBs-60MA PLC</a>	communication cable
<a href="#">B1-20MR2-D24-S</a>	PLS Controller
<a href="#">FBS-20MNR2-AC</a>	Ladder programming tool
<a href="#">FBs-20MNT2-AC</a>	Advanced PLC Controller
<a href="#">B1z-14MR25-D24-S</a>	Controller PLC
<a href="#">FBS-20MCJ2-D24</a>	Advanced PLC Controller
<a href="#">B1-24M4T2-D24</a>	Compact PLC Main Unit
<a href="#">P5043S</a>	Human-Machine Interface (HMI)
<a href="#">B1-16XY</a>	Digital Input/Output Expansion Module
<a href="#">FBs-PACK</a>	Module PLC
<a href="#">FBS-20MCR2-D24</a>	Controller PLC
<a href="#">FBs-6RTD</a>	PLC module
<a href="#">FBs-24MCR2-D24</a>	PLC Controller
<a href="#">FBS-40MCR2-D24</a>	Advanced PLC Main Unit
<a href="#">FBS-20MAR2-AC</a>	Controller
<a href="#">FBs-10MAT2-AC</a>	PLC Controller
<a href="#">PLC FBs-40MCR2-AC</a>	Controller
<a href="#">FBs-U2C-MD-180</a>	programming cable
<a href="#">FBs-40MCT2-AC 230V 50Hz</a>	Advanced PLC Controller

Product	Description
<a href="#">FBS-10MAR2-D24</a>	Basic PLC Controller
<a href="#">FBs-B2A1D</a>	Analog Input/Output Module
<a href="#">FBs-60MAR2-D24</a>	PLC driver
<a href="#">FBs-232P0-9FR-200</a>	Cable
<a href="#">FBs-32MNT2-AC</a>	Controller
<a href="#">FBS-14MCR2-AC</a>	PLC Controller
<a href="#">FBs-60MAR2-AC</a>	PLC Contoler
<a href="#">PLC FBs-24XYR</a>	Module
<a href="#">FBS-16YR</a>	PLC Module
<a href="#">FBS-16XYR</a>	Digital Input/Output Expansion Module
<a href="#">FBs-CB2</a>	PLC Module
<a href="#">HMI P5070SA</a>	Panel
<a href="#">PLC FBs-10MAT2-AC</a>	Controller
<a href="#">PLC FBs-2TC</a>	Modul
<a href="#">HMI P2043SA</a>	Panel
<a href="#">FBs-32MAR2-D24</a>	PLC Controller
<a href="#">FBS-40MAJ2-D24</a>	Controller
<a href="#">P5102N</a>	Panel
<a href="#">P5070NA</a>	Panel HMI
<a href="#">PLC FBs - 24MAR - AC</a>	PLC Main Unit
<a href="#">FBs-EPW-D24</a>	Module PLC
<a href="#">HMI P5070ZA</a>	panel
<a href="#">B1-10MR2-D24-S</a>	PLC Controller
<a href="#">PLC FBs-32MAT2-AC</a>	logic controller
<a href="#">B1Z-32MJ25-D24S</a>	PLC driver
<a href="#">FBs-24MAT2-AC</a>	PLC Controller
<a href="#">FBs-1LC</a>	PLC Module
<a href="#">FBs-CBES</a>	PLC Module
<a href="#">FBs-24MAR2-AC</a>	Controller
<a href="#">HMI P2070SA</a>	Panel/Interface
<a href="#">FBs-1HLC</a>	Precision Load Cell Module
<a href="#">FBs-MAR2-AC</a>	PLC Main Unit
<a href="#">FBS-14MCT2-AC</a>	Controller
<a href="#">P5101SA</a>	Panel HMI
<a href="#">B1-40MR2-D24</a>	PLC Controller
<a href="#">FBs-20MNJ2-D24</a>	Sterownik PLC
<a href="#">P5070SB</a>	Panel HMI
<a href="#">FBs-60MCT2-D24</a>	PLC controller
<a href="#">FBs-2A4RTD</a>	PLC module
<a href="#">FBs-20MAJ2-D24</a>	Controller PLC
<a href="#">FBs-20MAR2-D24</a>	Controller PLC
<a href="#">B1-24MR2-D24-S</a>	Controller PLC
<a href="#">B1-L4NTC-S</a>	Module PLC

<b>Product</b>	<b>Description</b>
<a href="#">FBs-CM25</a>	Module PLC
<a href="#">FBs-40XYT</a>	Module PLC
<a href="#">FBs-24YT</a>	Module PLC
<a href="#">FBs-24XYT</a>	Module PLC
<a href="#">FBs-8XYT</a>	Module PLC
<a href="#">FBs-6AD</a>	PLC Module
<a href="#">FBs-60MAT2-AC</a>	PLC Controller
<a href="#">P5150ZB</a>	Panel HMI
<a href="#">FBs-CM22</a>	Module PLC
<a href="#">HD30-22AWG-200</a>	Cable
<a href="#">HMI P2070NA</a>	Panel HMI
<a href="#">FBs-CM55</a>	Moduł PLC
<a href="#">FBs-10MAR2-AC</a>	PLC driver
<a href="#">PLC FBs-40XYR</a>	Module
<a href="#">FBs-7SG2</a>	LED display control module
<a href="#">FBs-8X</a>	PLS Module
<a href="#">FBs-40MCJ2-D24</a>	PLC Controller
<a href="#">FBs-CMGSM</a>	PLC Module
<a href="#">FBs-232P0-9M-400</a>	Cable
<a href="#">FBs-40XYJ-D24</a>	PLC Module
<a href="#">DB.8LEDR(PCB+8LED)</a>	Display
<a href="#">PLC FBs-RzR</a>	Module
<a href="#">B1-L2DA</a>	Analog Output Module
<a href="#">B1-L2DA-S</a>	PLC Module
<a href="#">FBs-32MCJ2-AC</a>	PLC driver
<a href="#">B1-8XYR-S</a>	PLC Module
<a href="#">P5101NA</a>	Panel HMI
<a href="#">FBs-60XYR-AC</a>	PLC module
<a href="#">FBs-32MCR2-AC</a>	PLC driver
<a href="#">FBs-40MAT2-AC</a>	PLC driver
<a href="#">B1-10MR2-D24</a>	Sterownik PLC
<a href="#">B1-L4AD</a>	Module PLC
<a href="#">FBs-6TC</a>	PLC Module
<a href="#">wrong code FBS-RTD6, correct code FBs-6RTD</a>	Temperature Measurement Module
<a href="#">B1-24MR2-D24</a>	PLC Main Unit
<a href="#">FBS-232PO-9F-150</a>	Communication Cable
<a href="#">FBs-24MCJ2-AC</a>	controller
<a href="#">FBs-60MCT2-AC</a>	PLC Controller
<a href="#">FBs-4DA</a>	PLC Module
<a href="#">FBs-60XYR</a>	Moduł PLC
<a href="#">FBs-CB55</a>	Moduł PLC
<a href="#">FBs-16TC</a>	PLC HEAT MODULE
<a href="#">P5043SA</a>	Panel HMI

Product	Description
<a href="#">FBS-60MCJ2-D24</a>	Controller
<a href="#">FBS-CBEH</a>	PLC Module
<a href="#">FBs-32MCT2-D24</a>	PLC Controller
<a href="#">SC306AAF00</a>	Servo drive
<a href="#">SC308AAG00</a>	Servo drive
<a href="#">SC310AAH00</a>	Servo drive
<a href="#">M71075CKBSC00</a>	Servo drive
<a href="#">M51150CKNSC00</a>	Servo drive
<a href="#">M51200CKNSC00</a>	Servo drive
<a href="#">LA6-PAH0F0-N1F03</a>	Cable
<a href="#">LA6-EXH03E-N2F03</a>	Cable
<a href="#">LA6-PAH1F0-N2F03</a>	Cable
<a href="#">LA6-EXH13E-N2F03</a>	Cable
<a href="#">LA6-PNH2F4-N5F03</a>	Cable
<a href="#">FBs-SK20MCJ2-AC</a>	Starter Kit
<a href="#">B1z-10MR2-D24</a>	PLC Main Unit
<a href="#">B1-20MT2-D24-S</a>	PLC Controller
<a href="#">HMI P2070PA</a>	Human-Machine Interface (HMI)
<a href="#">FBS-16YT</a>	Digital Output Expansion Module
<a href="#">FBS RTD16</a>	Temperature Measurement Module
<a href="#">FBS-TC16</a>	PLC Module
<a href="#">PLC Module FBs-CB55</a>	Communication Expansion Board
<a href="#">Cable FBs-U2C-MD-180</a>	Communication Cable
<a href="#">FBs-14MAT2-AC</a>	PLC Controller
<a href="#">FBs-14MAR2-AC</a>	Basic PLC Main Unit
<a href="#">HMI P5070NA</a>	Human-Machine Interface (HMI)
<a href="#">B1-CM5-S</a>	RS485 MODULE
<a href="#">B1-L2A2D-S</a>	2A+2AO ANALOG MODULE
<a href="#">B1-2DA-S</a>	2AO ANALOG MODULE
<a href="#">FBs-CBCAN</a>	gateway module
<a href="#">FBs-32MAR-D24</a>	PLC Controller
<a href="#">FBs-24MAT2-D24</a>	PLC controller
<a href="#">FBs-24MAJ2-D24</a>	PLC controller
<a href="#">B1z-20MR25-D24-S</a>	PLC Controller
<a href="#">FID-B20-2S1.5G</a>	Fiber Optic Sensor
<a href="#">FBs-16XYT</a>	PLC Module
<a href="#">HMI P2043NA</a>	
<a href="#">FBS-24MC</a>	
<a href="#">FBS-CBEH2A</a>	
<a href="#">FBs-60MCJ2-AC</a>	
<a href="#">FBs-B2C</a>	PLC Module
<a href="#">B1-CM5</a>	
<a href="#">FBs-14MCJ2-D24</a>	programmable controller

Product	Description
<a href="#">FBS-60MCTJ2-D24</a>	
<a href="#">FBS-CM5R</a>	PLC Module
<a href="#">FBs-CB22</a>	
<a href="#">FBS-60XYJ</a>	PLC Module