



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## FEMA

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">A4021A1002</a>	
<a href="#">1030418 / DCM10</a>	Pressure switch (Honeywell) DCM 10 (1-10 bar)
<a href="#">DCM025</a>	Pressure Switches
<a href="#">DWR 3</a>	Pressure switch
<a href="#">DWR16</a>	Pressure switch
<a href="#">M6284F1078-F (M6284F1078-F/U)</a>	motor
<a href="#">M6284F1078FU</a>	Modutrol motor
<a href="#">M7284Q1106/U</a>	Actuator
<a href="#">ML7420A6025</a>	Electric linear valve
<a href="#">PTHDB0032V3</a>	ELECTRIC PRESSURE SENSOR
<a href="#">R7861A1026/U</a>	FLAME AMPLIFIER, DYNAMIC SELF CHECK, USE WITH FLAME SENSORS
<a href="#">T7460A1001</a>	Room sensor
<a href="#">DCM6</a>	Pressure switch for positive pressure
<a href="#">VCM4156-513</a>	Unterdruckschalter
<a href="#">ST12-5-A</a>	Cable connector
<a href="#">TX150</a>	Stabthermostat
<a href="#">DCM1000-301</a>	Pressure Switches
<a href="#">ML6425A3006</a>	ACTUATOR
<a href="#">DCM1</a>	pressure switch
<a href="#">DCM3-513</a>	Industrial Pressure Switch
<a href="#">DCM40</a>	pressure switch
<a href="#">DCM63</a>	
<a href="#">DCM6-301</a>	pressure switch
<a href="#">DCM6-513</a>	
<a href="#">DCMV6</a>	pressure switch
<a href="#">DDCM16</a>	DIFFERENTIAL PRESSURE SWITCH
<a href="#">DGM06A-301</a>	FEMA
<a href="#">DGM310A-213</a>	
<a href="#">DGM325A-213</a>	Industrial pressure sensor
<a href="#">DNM025</a>	Pressure switches
<a href="#">2072344 / DNS1-351</a>	Pressure and vacuum switches
<a href="#">DWAM32</a>	pressure switch
<a href="#">DWR625-301</a>	
<a href="#">Ex-DDCM1</a>	Ex-differential pressure monitor
<a href="#">EX-DDCM4</a>	Ex-Differenzdruckwächter

Product	Description
<a href="#">EX-DNS10</a>	pressure switch
<a href="#">EX-DNS6</a>	
<a href="#">EX-DWR625</a>	FEMA
<a href="#">EX-TX490</a>	FEMA
<a href="#">PST002AG12S-R</a>	FEMA
<a href="#">PST010RG12S-R</a>	Electronic pressure switch/ transmitters
<a href="#">PST025RG34F-R</a>	FEMA
<a href="#">PST100RG12S-R</a>	FEMA
<a href="#">PTHRB0161V3</a>	FEMA
<a href="#">PTSRB0101V3</a>	pressure transmitter
<a href="#">TRMV40</a>	Industrial thermostat
<a href="#">TX150 - obsolete</a>	FEMA
<a href="#">VCM301</a>	Vacuum Switches
<a href="#">VNM111</a>	Vacuum Switch
<a href="#">DCM10-307-S</a>	PRESSURE SWITCH
<a href="#">VCM4156</a>	
<a href="#">DWR625</a>	Alerton Pressure monitor
<a href="#">DGM1A</a>	Pressure monitors for fuel gases
<a href="#">DGM06A</a>	
<a href="#">SDBAM16</a>	Switch
<a href="#">PTSRB0251V3</a>	
<a href="#">PTHRB0251V3</a>	
<a href="#">ML7430E1005</a>	electrical actuator
<a href="#">U430B</a>	
<a href="#">ST12-4-A</a>	Cable connector
<a href="#">TH-D26</a>	pressure switch
<a href="#">1004899/ PST010RG12S-R</a>	pressure switch
<a href="#">Nr. 1004434 Type DCM6-301</a>	Pressure limiter
<a href="#">P/N: 1003865 Type: DCM1000</a>	Pressure switch
<a href="#">DGM325A</a>	pressure switch
<a href="#">DPS200</a>	differential pressure switch
<a href="#">DWR06</a>	Pressure switch
<a href="#">DGM506</a>	Fuel gas pressure switch
<a href="#">DCM025-307-S</a>	PRESSURE SWITCH
<a href="#">5806W3</a>	smoke detector
<a href="#">DPTE502</a>	Differential pressure transmitter without digital display
<a href="#">DCM3</a>	pressure switch
<a href="#">VCMV095</a>	Vacuum Switches
<a href="#">FT6961-60</a>	Antifreeze thermostat
<a href="#">DWR16-203</a>	Air/steam pressure switch
<a href="#">EX-DWR25</a>	Pressure switch
<a href="#">DCM 16</a>	pressure switch
<a href="#">DWR6</a>	pressure switch

Product	Description
<a href="#">DDCM6</a>	DIFFERENTIAL PRESSURE SWITCH
<a href="#">T7460B1009</a>	
<a href="#">S6040A1003</a>	Air Flow Switch
<a href="#">1001869</a>	pressure switch
<a href="#">1001784</a>	pressure switch
<a href="#">DDCM6002</a>	differential pressure switch
<a href="#">DNS10-203</a>	pressure switch
<a href="#">M40-A-H-R1</a>	Panel Meter for Electrical AC Signals in Voltage & Current
<a href="#">ML6425A3048</a>	actuator
<a href="#">PTHDB0012V3</a>	
<a href="#">EX-DWR1</a>	Industrial pressure sensors
<a href="#">M40-A-H-R1-R1</a>	Digital panel indicator
<a href="#">DWR 6-203</a>	
<a href="#">DCMV63</a>	Pressure switch
<a href="#">DWR40 / 1032267</a>	pressure monitor,
<a href="#">DCMV16</a>	
<a href="#">DWR16-576</a>	
<a href="#">DWR25-576</a>	
<a href="#">EX-DNS025</a>	Mechanical Pressure Switch, Ex For Aggressive Liquid, Gas (Ex-dns)
<a href="#">DCM10 1-10</a>	
<a href="#">9999997 / DPS500</a>	DIFFERENTIAL PRESSURE TRANSMITTER
<a href="#">C40-D-U</a>	MULTIPURPOSE DIGITAL COUNTER
<a href="#">C40-D-U.1442</a>	
<a href="#">B44-C1-H-R-0-0</a>	Large display,4 digits,100mm+impulse counter, red colour
<a href="#">DCM1000-301-S + ZF1978 (---)</a>	
<a href="#">M7284Q1098/U</a>	Modutrol actuator
<a href="#">R151045G</a>	Federriegel
<a href="#">110560</a>	Valve
<a href="#">32004-SN-001</a>	Valve
<a href="#">SWF62L</a>	
<a href="#">ASL453/24</a>	Evaluation device
<a href="#">EX-DNS16-S</a>	
<a href="#">M40-D-L-S4</a>	
<a href="#">C40-A-H-A1-A2</a>	
<a href="#">EX-DNM10</a>	
<a href="#">DCM1000</a>	Pressure switch
<a href="#">DCM4016</a>	
<a href="#">I/Z59C15-150-5-BZ-N-CV-R-01</a>	
<a href="#">DDCM6002-301</a>	
<a href="#">VCM 095</a>	vacuum switch
<a href="#">I/W59C12-2000-5-BZ-N-CL-R</a>	
<a href="#">SLF3</a>	airflow monitor
<a href="#">DWR06-513</a>	

Product	Description
<a href="#">M40-D-H-AO</a>	
<a href="#">M40-D-H-AO-G</a>	
<a href="#">DNS6-201</a>	
<a href="#">DCM6-307-S</a>	
<a href="#">DCM6-307-S + ZF1972</a>	
<a href="#">PTHDB0032V3 100°</a>	
<a href="#">KED 3R/ESE/150°C/G½</a>	
<a href="#">DWR625-S + ZFV185-50</a>	
<a href="#">PTSDB0032V3</a>	
<a href="#">ASW454</a>	evaluation device
<a href="#">SWF62</a>	flow sensor
<a href="#">DCM25</a>	PRESSURE SWITCH