







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Page 1 / 24

## Gutekunst

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

## **BRAND'S PRODUCTS**

Product	Description
<u>D-042J-02</u>	Compression Springs
<u>D-063Q-01</u>	compression spring
<u>D-090U-11</u>	Compression springs
<u>D-090W-02</u>	COMPRESSION CYLINDER SPRING
<u>D-095A-11</u>	Compression spring
<u>D-099</u>	compression spring
<u>D-100A-07</u>	Compression spring
<u>D-110</u>	Compression spring
<u>D-116</u>	Spring
<u>D-128</u>	Compression spring
<u>D-135</u>	Compression spring
<u>D-142AD</u>	G5415B_0607_AA_SCHRAUBENFEDER
<u>D-143A</u>	Druckfeder
<u>D-145DG</u>	Compression spring
<u>D-145H</u>	Compression spring
<u>D-145H-10</u>	1.00x13.00x30.00x3.50
<u>D-147</u>	SPRING
<u>D-151</u>	Spring ends
<u>D-180Q-03</u>	1.20x9.80x46.70x8.50 DRUCKFEDER 1.1200 C18827
<u>D-200C</u>	(1.25x.80x36.00x13.50, COMPRESSION SPRING, 1.1200, C18412)
<u>D-206A</u>	Compression springs
<u>D-206B</u>	Compression springs
<u>D-207JL</u>	compression springs
<u>D-207M-01</u>	1.60x26.40x130.00x8.50
<u>D-209</u>	SPRING
<u>D-229A</u>	Compression spring
<u>D-232</u>	compression spring
<u>D-235</u>	Compression spring
<u>D-248</u>	Compression springs
<u>D-263O-01</u>	Compression spring
<u>D-263P</u>	Compression Spring
<u>D-288Z-52</u>	precompressed spring
<u>D-304</u>	Compression spring
<u>VD-090W-01</u>	Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Gutekunst





Product	Description
<u>VD-090W-02</u>	Compression Spring
<u>VD-180M-22</u>	Compression spring 1.2X13.8X40
<u>VD-180Q-03</u>	Compression spring
<u>VD-207J-35</u>	Compression Spring
<u>VD-207JQ</u>	1.50x20.50x30x3.50 DRUCKFEDER
<u>VD-207K-04</u>	Spring 1.50X10.00X38.00X8.50, C17332
<u>VD-223</u>	Compression springs
<u>VD-263V-19</u>	Compression Spring
<u>Z-105</u>	13.70x1.25x50.5
<u>Z-162CX</u>	Extension spring
T-16346L 0.70x7.70x9.50 389898 1.4310 Art. 389898	Schenkelfeder links
<u>VD-207JO</u>	Druckfeder
<u>D-143C</u>	compression spring
<u>Z-078DI</u>	Zugfeder
<u>D-288Z-06</u>	Druckfeder
<u>D-232A-07</u>	Compression spring
<u>Z-1731</u>	Zugfeder
<u>D-044A</u>	Compression spring
<u>VD-122A-11</u>	Compression spring
<u>G0003007</u>	Spring clip
<u>Z-153EI</u>	Zugfeder
<u>VD-203</u>	Compression springs
<u>D-232F</u>	Compression Spring
<u>D-257B</u>	Compression spring
<u>Z-141FX</u>	Extension Spring
<u>D-207D</u>	Druckfeder
<u>D-262A-15</u>	Druckfeder
<u>VD-263Q-O3</u>	Druckfeder
<u>Z-100PI</u>	Zugfeder
<u>D-180-10</u>	compression spring
<u>D-278</u>	Druckfeder
<u>Z-051FI</u>	Extension Springs
<u>VD-294</u>	Compression Springs
<u>D-150B</u>	compression spring
<u>VD-181</u>	compression spring
<u>VD-339R-01</u>	Druckfeder
<u>D-018</u>	Druckfeder
<u>VD-331</u>	compression spring
<u>D-207JF</u>	compression spring
<u>VD-095C</u>	Compression spring
<u>VD-150C</u>	Druckfeder
<u>D-236D</u>	Compression Spring
<u>D-239A-05</u>	Compression Spring

Gutekunst





Product	Description
<u>VD-120</u>	Spring 0.80X10.00X45,58X8.50, C12463
<u>D-063H-13</u>	Compression spring
<u>D-118</u>	Compression spring
<u>D-122B</u>	Compression spring
<u>D-207M</u>	Compression spring
<u>D-080A</u>	Druckfeder
<u>D-263Q-08</u>	compression spring
<u>D-165E</u>	Compression Springs
<u>D-173H</u>	compression spring
<u>D-204</u>	compression spring
<u>D-178B</u>	compression spring
<u>D-085G</u>	compression spring
<u>D-200A</u>	Compression Spring
<u>VD-047D</u>	Compression Springs
<u>D-127E-09</u>	Compression Spring
<u>D-090M</u>	Compression Springs
<u>VD-097</u>	Compression Springs
<u>D-115H-12</u>	Compression Springs
<u>D-085C</u>	Compression Springs
<u>D-063B</u>	Compression Spring
<u>VD-121</u>	Compression Springs
<u>D-180-11</u>	Compression springs
<u>D-273</u>	Compression Springs
<u>D-090</u>	Compression Springs
<u>D-085E</u>	Compression Springs
<u>D-085D</u>	Compression Springs
<u>VD-127D</u>	Compression Springs
<u>D-180D-05</u>	Compression Springs
<u>D-090L</u>	Compression Springs
<u>D-069A</u>	Compression Springs
<u>D-117K</u>	Compression Springs
<u>D-156</u>	Compression Spring
<u>RZ-094CX</u>	Extension Springs
<u>D-180S</u>	Compression spring
<u>D-166</u>	Compression Springs
<u>D-078A</u>	Compression Spring
<u>D-026R-03</u>	Compression Springs
<u>D-143F</u>	Compression Springs
<u>D-143G</u>	Compression Springs
<u>D-162</u>	Compression Springs
<u>D-319</u>	Compression Springs
<u>T-18880L</u>	Torsion Springs
<u>T-18880R</u>	leg spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 3 / 24





Product	Description
<u>D-090M-02</u>	Compression springs
<u>VD-136</u>	compression spring
<u>D-179J-04</u>	Compression Springs
<u>VD-322</u>	Compression Springs
<u>VD-364K</u>	Compression Springs
<u>D-285</u>	Compression Springs
<u>Z-160X</u>	Extension Springs
<u>VD-263V-16</u>	Compression Springs
<u>VD-247A</u>	Compression Springs
<u>D-207J</u>	Compression Spring
<u>D-179M</u>	compression spring
<u>D-105</u>	Compression Springs
<u>D-143L</u>	Compression Spring
<u>KM-3671</u>	Endless compression springs
<u>KM-3368</u>	Endless compression springs
<u>D-263G</u>	Compression Springs
<u>D-068A-12</u>	Compression Springs
<u>D-050A</u>	spring
<u>D-068A-16</u>	Compression Spring
<u>VD-123</u>	Compression Spring
<u>D-206G</u>	COMPRESSION CYLINDER SPRING
<u>D-073</u>	Compression Spring
<u>Z-0921</u>	Tension spring
<u>RZ-0961</u>	Zugfeder
<u>RZ-093HI</u>	tension spring
<u>RZ-1391</u>	tension spring
<u>D-217D</u>	Compression Springs
<u>D-243</u>	Compression Springs
<u>D-232K</u>	Compression Springs
<u>D-207J-08</u>	Compression Springs
<u>D-155</u>	Compression Spring
<u>D-180D-01</u>	Druckfeder
<u>T-18915L</u>	Schenkelfeder
<u>T-16819L</u>	Schenkelfeder
<u>RZ-057GX</u>	Zugfeder
<u>RZ-147RI</u>	Zugfeder
<u>D-115H-10</u>	Druckfeder
<u>D-117S</u>	Compression spring
<u>D-207K-04</u>	Druckfeder
<u>D-232Q</u>	Compression spring
<u>D-263J</u>	Compression Spring
<u>D-351</u>	Compression spring
<u>KM-3345</u>	Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 4 / 24

Enapart





Product	Description
<u>D-173E (30 pcs)</u>	spring
<u>D-173E (75 pcs)</u>	Compression spring
<u>D-173E (100 pcs)</u>	Compression spring
<u>D-180L</u>	Compression Spring
<u>D-232N</u>	Compression Spring
<u>D-212E</u>	Compression Spring
<u>D-237A</u>	Compression Spring
<u>D-234A</u>	Compression Spring
<u>D-222</u>	Compression Spring
<u>VD-219A</u>	Compression Spring
<u>D-153A</u>	Compression Spring
<u>D-228</u>	COMPRESSION SPRING
<u>D-249</u>	compression spring
<u>D-329</u>	Druckfeder
<u>D-207</u>	Druckfeder
<u>D-210</u>	Druckfeder
<u>D-180R</u>	Druckfeder
<u>D-232M</u>	Compression spring
<u>D-240</u>	Druckfeder
<u>D-277</u>	Druckfeder
<u>VD-263Q-03</u>	Druckfeder
<u>D-237</u>	Compression spring
<u>D-236</u>	Compression spring
<u>D-313A-13</u>	Druckfeder
<u>D-173G</u>	Compression spring
<u>D-233B</u>	Compression spring
<u>Z-087 CI</u>	Compression spring
<u>D-310</u>	Compression spring
<u>X380-20L</u>	spring pin
<u>VD-313A-10</u>	Compression spring
<u>D-193</u>	Compression spring
<u>D-098</u>	Compression spring
<u>D-207J-04</u>	Compression spring
<u>D-252A-07</u>	COMPRESSION SPRING
<u>D-313K-01</u>	Compression spring
<u>D-155A</u>	Compression Spring
<u>D-206</u>	Compression Spring
<u>D-262</u>	compression spring
<u>VD-209</u>	Compression spring
<u>D-180J</u>	Compression spring
<u>D-180U</u>	Compression Spring
<u>D-044</u>	Pressure Spring
<u>D-090W-11</u>	Compression Spring





Product	Description
<u>Z-066MX</u>	Zugfeder
<u>Z-066MI</u>	Zugfeder
<u>D-288Z-53</u>	Compression springs
<u>D-301</u>	Compression springs
<u>D-222A</u>	Compression springs
<u>D-219</u>	Compression spring
<u>D-074D</u>	Compression Spring
<u>D-090K</u>	Compression springs
<u>D-090J</u>	Compression spring
<u>D-126A</u>	Compression Spring
<u>D-121</u>	Compression spring
<u>D-015</u>	Compression Spring
<u>D-036</u>	Compression Spring
<u>D-068A-02</u>	Compression Spring
<u>D-109</u>	Compression Spring
<u>D-063N</u>	Compression spring
<u>D-071</u>	Druckfeder
<u>VD-263V-12</u>	Compression Spring
<u>D-079</u>	Compression Spring
<u>D-263V-08</u>	compression spring
<u>D-042J</u>	Compression spring
<u>D-207J-02</u>	Compression spring
<u>D-232R</u>	SPRING
<u>D-275</u>	Compression spring
<u>D-313J</u>	Compression spring
<u>D-119</u>	Compression spring
<u>D-207JQ</u>	Compression spring
<u>D-268E</u>	PRESSURE SPRING
<u>VD-117H-50</u>	Compression spring
<u>D-071A</u>	Compression Spring
<u>Z-066YI</u>	Extension Spring
<u>D-090W-01</u>	Compression spring
<u>VD-291</u>	Compression Spring
<u>D-049A</u>	spring
<u>Z-048CI</u>	Extension Spring
<u>VD-207AA</u>	Compression Spring
<u>VD-364E-02</u>	Compression spring
<u>VD-129</u>	Compression Spring
<u>VM-018</u>	Compression Spring
<u>D-055A</u>	Compression springs
<u>D-070</u>	Pressure Spring
<u>D-110A</u>	Compression springs
<u>D-080F</u>	Compression springs

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 6 / 24





Product	Description
<u>D-040A</u>	Compression springs
<u>D-003</u>	Compression spring
<u>VD-075B</u>	Compression spring
<u>T-18509L</u>	Torsion springs
<u>D-179J-01</u>	Compression Spring
<u>D-068A-10</u>	Compression springs
<u>VD-189A</u>	Compression springs
<u>D-127E-06</u>	Compression springs
<u>RZ-066PI</u>	Extension Springs
<u>D-063O</u>	compression spring
<u>D-090Q</u>	Compression springs
<u>D-080</u>	Compression spring
<u>D-030</u>	Druckfeder
<u>D-103</u>	spring
<u>VD-063H-05</u>	Compression springs
<u>D-142C</u>	Compression springs
<u>RZ-051NI</u>	springs
<u>VD-063G</u>	Compression spring
<u>VD-135</u>	Compression spring
<u>T-16703L</u>	Torsion Spring
<u>D-288Z-54</u>	Compression spring
<u>D-126</u>	springs
<u>D-068</u>	Compression spring
<u>D-046</u>	Compression spring
RTEMPB7	ir thermometer 31 tp 689f
TEC1503L	torq
<u>VD-364J-20</u>	Compression Spring
<u>D-389K</u>	Compression Spring
<u>VD-207K-01</u>	Compression Spring
<u>D-145D-01</u>	Compression Spring
<u>D-093</u>	Compression Spring
<u>D-145DB</u>	Compression Spring
<u>D-134</u>	Compression Spring
<u>D-062B</u>	Compression spring
<u>D-173A-01</u>	Compression Spring
<u>D-145F</u>	COMPRESSION SPRING
<u>Z-142X</u>	Extension Spring
<u>T-18834L</u>	Torsion Spring (Left-Hand Wound)
<u>T-18834R</u>	Torsion Spring (Right-Hand Wound)
<u>VD-137</u>	compression spring
<u>VD-173CK</u>	Compression Spring
<u>VD-271</u>	springs
<u>D-117H-30</u>	Compression Springs

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk





Product	Description
<u>D-117J</u>	Compression spring
<u>D-104</u>	Compression Spring
<u>VD-142B</u>	Compression Spring
<u>D-208</u>	compression spring
<u>VD-122A-12</u>	Compression Spring
<u>D-194</u>	Compression spring
<u>D-191</u>	compression springs
<u>D-207J-03</u>	Compression Spring
<u>D-269</u>	Compression Spring
<u>D-313J-06</u>	Compression Spring
<u>D-145</u>	Compression Spring
<u>D-265</u>	Compression Spring
<u>D-207C</u>	Compression Spring
<u>VD-394A</u>	Compression Spring
<u>C130-20L</u>	Rounded spring clip
<u>VD-364J-11</u>	Compression Spring
<u>VD-152A</u>	Compression Spring
<u>VD-207J-21</u>	Compression Spring
<u>D-151B</u>	Compression spring
<u>Z-0601</u>	Extension Spring
<u>D-063H-04</u>	Compression Spring
<u>VD-190G</u>	Compression spring
<u>D-190G</u>	Compression spring
<u>Z-091X</u>	Extension Springs
<u>VD-090Y</u>	Compression springs
<u>D-179J-02</u>	Compression Spring
<u>D-414A</u>	Compression Spring
<u>VD-313B</u>	Compression Spring
<u>T-18450L</u>	Torsion Spring (Left-Hand Wound)
<u>D-144C</u>	Compression spring
<u>D-173F</u>	Compression Spring
<u>D-115</u>	Compression Spring
<u>D-072</u>	Compression spring
<u>D-234C</u>	Compression Spring
<u>D-075F</u>	Compression Spring
<u>Z-081HI</u>	Extension spring
<u>D-090AD</u>	Compression spring
<u>D-061</u>	Compression spring
<u>D-040</u>	Compression spring
<u>D-152A</u>	Compression spring
<u>D-115E</u>	Compression spring
<u>VD-115E</u>	Spring Compression
<u>VD-031</u>	Compression spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 8 / 24





Product	Description
<u>VD-2070</u>	Compression spring
<u>D-078</u>	Compression springs
<u>Z-036UI</u>	Extension spring
<u>D-054</u>	Compression spring
<u>RZ-060E-011</u>	Tension spring
<u>D-198</u>	Compression spring
<u>VD-063H-12</u>	Compression Spring
<u>DSF-100</u>	Double torsion spring
<u>D-173B</u>	Compression Spring
23522	Compression Spring
<u>D-127</u>	Compression spring
<u>D-094</u>	Compression spring
<u>D-090F</u>	Compression Spring
<u>VD-108</u>	Compression Spring
<u>D-1660</u>	Compression Spring
<u>D-173CH</u>	Compression spring
<u>RZ-109HI</u>	Extension Spring
<u>D-043</u>	Compression spring
<u>D-339R-10</u>	Compression Spring
<u>D-122A-13</u>	Compression Spring
<u>D-300</u>	compression springs
<u>PTIM5</u>	pk-up tl
<u>VD-115H-02</u>	Compression Spring
<u>D-124</u>	Compression spring
<u>D-164</u>	Compression Spring
<u>D-180K</u>	Compression Spring
<u>D-190B</u>	compression spring
<u>D-180M-11</u>	Compression Spring
<u>D-195A-11</u>	Compression Spring
<u>D-206A-21</u>	Compression Spring
<u>D-095D</u>	Compression spring
<u>D-120</u>	Compression spring
<u>D-142B</u>	Compression spring
<u>D-143H</u>	Compression Spring
<u>D-155A-10</u>	Compression spring
<u>D-234G</u>	Pressure Spring
<u>KM-3275</u>	Compression Spring
<u>VD-117C</u>	Compression Spring
<u>D-127B</u>	Compression Spring
<u>D-127E-01</u>	Compression Spring
<u>VD-154B</u>	Compression Spring
<u>D-179J-03</u>	compression springs
<u>D-117P</u>	Compression spring





Product	Description
<u>D-160</u>	Compression spring
<u>D-173J</u>	Compression spring
<u>D-218A</u>	Compression Spring
<u>D-166D</u>	compression spring
<u>D-115D</u>	Compression Spring
<u>D-180G</u>	Compression Spring
<u>Z-094AI</u>	Compression Spring
<u>D-190D</u>	Compression Spring
<u>D-180M-12</u>	compression springs
<u>RZ-094CI</u>	Extension Spring
<u>Z-094CI</u>	Extension Springs
<u>D-029</u>	Spring
<u>D-232P</u>	Compression springs
<u>D-090T</u>	compression springs
<u>D-303B</u>	Compression springs
<u>D-168</u>	Compression springs
<u>D-212D</u>	Compression Spring
<u>D-232D</u>	Compression Spring
<u>D-115A</u>	Compression springs
<u>D-049</u>	Compression spring
<u>D-115H-03</u>	Compressed spring
<u>D-019</u>	Spring
<u>VD-090</u>	Compression springs
<u>Z-162K-011</u>	tension springs
<u>Z-162K-01X</u>	Extension Springs
<u>D-125</u>	0.80x8.00x32.00x8.50
<u>D-117A</u>	Compression spring
<u>D-029A</u>	Compression Spring
<u>D-063J</u>	compression spring
<u>D-214</u>	Compression Spring
<u>D-234L</u>	Spring
<u>D-313F</u>	PRESSURE SPRING
<u>D-143J</u>	Compression springs
<u>T-19560R</u>	Torsion Springs
<u>D-080B-04</u>	compression springs
<u>Z-039AX</u>	Extension Springs
<u>D-207J-90</u>	Compression springs
<u>D-207JV</u>	Compression springs
<u>VD-117D</u>	Compression springs
<u>D-182</u>	Compression springs
<u>D-165D</u>	Compression springs
<u>D-083</u>	Compression springs
<u>D-016</u>	Compression springs

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 10/24





Product	Description
<u>Z-130JI</u>	Extension Spring
<u>Z-115V-111</u>	SPRING
<u>Z-081KX</u>	Extension Spring
<u>D-179N</u>	SPRING
<u>D-313J-04</u>	Compression Spring
<u>VD-239A-02</u>	compressive spring
<u>VD-145DB</u>	Compression Spring
<u>D-080C</u>	Compression Spring
<u>RZ-146X</u>	Extension Spring
<u>VD-207J-72</u>	Compression spring
<u>VD-234A</u>	Compression Spring
<u>D-115M</u>	Compression spring
<u>VD-090U-13</u>	Compression Spring
<u>VD-195</u>	Compression Spring
<u>VD-227</u>	Compression Spring
<u>VD-380</u>	Compression Spring
<u>D-389E-10</u>	Compression spring
<u>D-344B</u>	Compression spring
<u>D-227</u>	compression springs
<u>D-220</u>	Compression Spring
<u>VD-102</u>	Compression Spring
<u>D-149</u>	Compression Spring
<u>D-252A-04</u>	Compression Spring
<u>D-252</u>	Compression sprin
<u>D-157</u>	spring
<u>D-213</u>	1.60x16.00x34.0x3.50
<u>D-045A</u>	Pressure Spring
<u>D-166E</u>	Pressure Spring
<u>D-166M</u>	Pressure Spring
<u>D-257</u>	Compression Spring
<u>Z-081J1</u>	Tension Spring
<u>Z-115V-301</u>	Tension Spring
<u>Z-1551</u>	Tension Spring
<u>D-179B-10</u>	Compression Spring
<u>D-150</u>	Spring steel
<u>D- 042J-03</u>	Spring
<u>D-217C</u>	compression spring
<u>D-197A</u>	spring compresion
<u>VD-151A</u>	compression springs
<u>D-305</u>	SPRING
<u>D-288X-06</u>	SPRING
<u>D-226</u>	SPRING
<u>VD-155</u>	springs

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 11/24





Product	Description
<u>D-303A-10</u>	Spring
<u>D-339M</u>	Spring
<u>D-389N-01</u>	spring
<u>VD-288Z-41</u>	compression spring
<u>VD-241A</u>	Compression spring
<u>VD-252A-20</u>	Spring
<u>VD-321</u>	Spring
<u>VD-310</u>	Spring
<u>RZ-115JI</u>	SPRING
<u>D-230</u>	Compression spring
<u>D-108</u>	Compression Spring
<u>D-354B</u>	bows
<u>Z-380HI</u>	spring
<u>VD-142AD</u>	Compression Spring
<u>VD-179C</u>	Compression spring
<u>D-239A-04</u>	Compression spring
<u>D-013</u>	Compression springs
<u>D-057</u>	COMPRESSION SPRING
<u>D-057C</u>	SPRING
<u>D-080D</u>	COMPRESSION SPRING
<u>D-084</u>	Compression spring
<u>D-090H</u>	COMPRESSION SPRING
<u>D-115H-04</u>	Compression springs
<u>D-123</u>	compression spring
<u>D-150C</u>	Compression spring
<u>D-257E-02</u>	Compression Spring
<u>D-288Z-11</u>	COMPRESSION SPRING
<u>D-166L</u>	Compression spring
<u>VD-256</u>	Compression Spring
<u>D-180B</u>	Compression spring
<u>VD-092</u>	Compression spring
<u>VD-166</u>	Spring
<u>VD-095D</u>	Compression spring
<u>VD-115H-11</u>	Spring
<u>VD-115H-12</u>	Spring
<u>VD-143H-10</u>	Spring
<u>VD-143J</u>	Spring
<u>VD-166C</u>	Spring
<u>VD-065</u>	Pressure spring
<u>D-255</u>	Compression springs
<u>VD-063H-21</u>	Spring
<u>VD-163A</u>	Spring
<u>VD-115H-01</u>	Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 12/24





Product	Description
<u>VD-143F</u>	Compression spring
<u>VD-147</u>	Compression spring
<u>VD-042J-01</u>	Compression spring
<u>VD-143B</u>	Spring
<u>D-247B</u>	Compression spring
<u>D-1170</u>	Compression spring
<u>D-179J-11</u>	Compression spring
<u>VD-090W-03</u>	Compression spring
<u>D-180D</u>	compression spring
<u>VD-118</u>	Compression Springs
<u>D-268</u>	PRESS SPRING
<u>D-257C</u>	Compression Spring
<u>D-180Y-02</u>	spring
<u>D-207JZ</u>	Pressure spring
<u>VD-142AA</u>	Compression spring
<u>VD-179L</u>	Compression spring
<u>VD-207J-01</u>	Compression spring
<u>KM-3294</u>	compression spring
<u>D-199A</u>	Compression Spring
<u>VD-180K</u>	Compression Spring
<u>VD-218</u>	Compression spring
<u>VD-180-01</u>	SPRING
<u>VD-260</u>	Compression Spring
Spring identical to KM-3294 with Lo=1500 mm	Endless Compression Spring
<u>D-163</u>	Compression spring
<u>D-313A-10</u>	Compression Spring
<u>VD-236</u>	Compression Spring
<u>VD-153</u>	Compression Spring
<u>VD-207</u>	Compression Spring
<u>VD-180J</u>	Compression spring
<u>VD-313R-01</u>	Compression spring
<u>VD-364R-60</u>	Compression Spring
<u>D-239A-03</u>	Compression spring
<u>D-241</u>	compression spring
<u>RZ-115GI</u>	Extension Spring
<u>D-057D</u>	Compression Spring
<u>Z-036AAX</u>	Tension spring
<u>D-309</u>	SPRING
<u>VD-220</u>	Compression Spring
<u>VD-207JL</u>	Compression Spring
<u>D-140</u>	compression spring
<u>D-127C</u>	Compression Spring
<u>Z-0441</u>	Extension Spring





VD-150DCompression springVD-179J-02Compression SpringD-117CCompression springsD-129Compression SpringZ-051DIExtension SpringVD-207J-09Compression SpringsD-131Compression SpringsD-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression SpringVD-326HBW;compression spring
D-117CCompression springsD-129Compression SpringZ-051DIExtension SpringVD-207J-09Compression SpringsD-131Compression SpringsD-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression Springs
D-129Compression SpringZ-051DIExtension SpringVD-207J-09Compression SpringsD-131Compression SpringsD-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression Springs
Z-051DIExtension SpringVD-207J-09Compression SpringsD-131Compression SpringsD-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression Spring
VD-207J-09Compression SpringsD-131Compression SpringsD-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression Spring
D-131Compression SpringsD-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression Spring
D-026R-12Compression springsD-039Compression springsD-100Compression springsD-263VCCompression Spring
D-039 Compression springs   D-100 Compression springs   D-263VC Compression Spring
D-100     Compression springs       D-263VC     Compression Spring
D-263VC Compression Spring
<u>vD-szo</u> now, compression spring
D-090U-14 Compression Spring
D-263E Compression Spring
D-263T Compression Spring
VD-142A Compression Spring
VD-166L Compression Springs
Z-045HX Extension Spring
<u>D-090M-05</u> spring
D-349A-10 spring
VD-165E spring
D-197 Compression spring
D-085 Compression spring
Z-2331 tension spring
VD-080D Compression Spring
D-284 SPRING
D-252AC PRESSURE,SPRING
D-263P-01 PRESSURE,SPRING
D-222F PRESSURE,SPRING
D-115H-01 Compression spring
D-272 SPRING,COMPRESSION
X130-8L SPRING,CLAMP
VD-386 Compression spring
Z-121JI EXTENSION,SPRINGS
D-117L SPRING,COMPRESSION
VD-045 PRESSURE,SPRING
KM-2288 PRESSURE,SPRING
RZ-177QI SPRING, TENSION
D-179J-13 SPRING,HELICAL,COMPRESSION
D-288ZC pressure spring
VD-161 pressure spring
D-276A pressure spring
VD-217F-10 Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 14/24





Product	Description
<u>T-18700L</u>	Spring
<u>T-18700R</u>	Spring
<u>D-165</u>	Compression Spring
<u>D-101</u>	Pressure Spring
<u>VD-085F</u>	Compression Spring
<u>D-028</u>	Compression Spring
<u>VD-117H-20</u>	SPRING
<u>Z-1371</u>	Extension Spring
<u>Z-162RI</u>	Extension Spring
<u>RZ-1301</u>	Extension Spring
<u>D-145C</u>	Compression Spring
<u>D-180M-23</u>	Compression Spring
<u>D-180-03</u>	Compression spring
<u>T-18833R</u>	Torsion spring
<u>D-097</u>	Compression spring
<u>D-332</u>	PRESSURE SPRING.
<u>Z-1471</u>	TRACTION SPRING
<u>D-207J-05</u>	PRESSURE SPRING
<u>D-263L</u>	Compression spring
<u>Z-118I</u>	TRACTION SPRING
<u>D-117H-51</u>	Compression spring
<u>D-206D</u>	PRESSURE SPRING
<u>D-339</u>	pressure spring
<u>RZ-036HX</u>	spring
<u>RZ-042HX</u>	spring
<u>D-091</u>	Compression spring
<u>G152187</u>	compression spring
<u>T-19106L</u>	SPRING
<u>T-19106R</u>	Spring
<u>M-035</u>	SPring
<u>D-180C</u>	compression spring
<u>VD-170</u>	spring
<u>RZ-0531</u>	Spring 0,63x8,60x28,10
<u>D-239A-01</u>	Spring
<u>D-192</u>	Compression spring
<u>D-207J-21</u>	Compression Spring
<u>VD-071A</u>	Compression spring
<u>VD-164</u>	Compression spring
<u>VD-063H-20</u>	Compression spring
<u>VD-217D</u>	Compression Spring
<u>D-095B</u>	Compression Spring
<u>D-263V-07</u>	Compression Spring
<u>D-142</u>	Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 15/24





Product	Description
<u>D-207J-34</u>	Compression Spring
<u>VD-287</u>	SPRING
<u>VD-288</u>	SPRING
<u>VD-288K-11</u>	compression spring
<u>D-232L-01</u>	SPRING
<u>D-207JS</u>	compression spring
<u>Z-066QX</u>	Spring
<u>D-288Z-12</u>	Spring
<u>Z-153AI</u>	Spring
<u>D-263U-09</u>	Compression Spring
<u>D-090W-07</u>	COMPRESSION SPRING
<u>D-180M-13</u>	PRESSURE SPRING
<u>D-179H</u>	COMPRESSION SPRING
<u>D-063P</u>	SPRING, COMPRESSION, EN 10270-1 CLOSED AND GROUND
<u>D-117H</u>	SPRING, COMPRESSION, EN 10270-1 CLOSED AND GROUND
<u>RZ-066RI</u>	Extension Spring
<u>D-143M</u>	SPRING, COMPRESSION, EN 10270-1 CLOSED AND GROUND
<u>D-180Q-04</u>	compression spring
<u>D-196</u>	Compression spring
<u>D-207J-20</u>	Compression springs
<u>D-242</u>	compression spring
<u>Z-115LI</u>	SPRING, EXTENSION
<u>D-233E-10</u>	SPRING, COMPRESSION
<u>D-506</u>	Compression spring
<u>D-263F</u>	Compression spring
<u>D-313J-07</u>	SPRING
<u>D-313N-10</u>	SPRING
<u>Z-162U-30I</u>	SPRING
<u>D-117H-41</u>	SPRING
<u>D-217B</u>	SPRING
<u>D-270</u>	compression springs
<u>D-306</u>	SPRING
<u>D-335</u>	SPRING
<u>D-339A-01</u>	SPRING
<u>RZ-072BI</u>	SPRING
<u>RZ-162MI</u>	SPRING
<u>T-19109R</u>	SPRING
<u>VD-085E</u>	SPRING
<u>D-173C</u>	Compression spring
<u>Z-093CI</u>	Extension Spring
<u>RZ-0491</u>	Extension Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Enapart





Product	Description
<u>D-207JR</u>	Compression Spring
<u>D-206H</u>	Compression spring
<u>D-186</u>	Compression Spring
<u>VD-195A-10</u>	pressure spring
<u>D-180P</u>	Compression spring
<u>D-218</u>	COMPRESSION SPRING,
<u>Z-0571</u>	Extension spring
<u>VD-026R-04</u>	PRESSURE SPRING
<u>D-145H-11</u>	Compression spring
<u>D-095C</u>	Compression spring
<u>VD-075F</u>	COMPRESSION SPRING
<u>D-181</u>	Compression spring
<u>D-068A-14</u>	Compression spring
<u>D-207JY</u>	Compression spring
<u>D-189</u>	Compression spring
<u>Z-130LI</u>	TRACTION SPRING
<u>VD-115L</u>	Compression spring
<u>D-045</u>	Compression Spring
<u>VD-063N</u>	Compression spring
<u>M-022A</u>	Endless extension spring
<u>D-288Z-42</u>	Compression spring
<u>D-327</u>	Compression spring
<u>D-268A-05</u>	Pressure spring
<u>D-052F</u>	
<u>D-267</u>	Spring 2,5x32x245
<u>D-216</u>	Compression spring 1,6x16x110
<u>D-207JC</u>	Spring
<u>D-130</u>	pressure spring
<u>VD-234N-10</u>	Stainless Steel Compression Spring
<u>D-152B</u>	Compression spring
<u>D-207N</u>	Compression Spring
<u>RZ-115V-10X</u>	Extension Spring
<u>D-150E</u>	Compression spring
<u>D-132A-12</u>	Spring
<u>VD-116</u>	Compression Spring
<u>D-100A-04</u>	Compression Spring
<u>D-145D-02</u>	Compression Spring
<u>D-077</u>	compression spring
<u>D-207KH</u>	Spring
<u>VD-340</u>	Compression Spring
<u>VD-145E</u>	Spring
<u>D-207JJ</u>	compression spring
<u>D-127D</u>	Compression spring





Product	Description
D-042D	Compression Spring
 D-115F	Compression spring
 D-263B	Compression Spring
VD-145DA	Compression Spring
 D-145DJ	COMPRESSION SPRING
<u>D-145DK</u>	COMPRESSION SPRING
D-288L	COMPRESSION SPRING
 D-288P	COMPRESSION SPRING
<u>D-326</u>	COMPRESSION SPRING
 VD-249	COMPRESSION SPRING
<u>VD-090M-01</u>	Compression spring
VD-207L	Compression Spring
<u>VD-207J-05</u>	Compression Spring
<u>VD-180M-23</u>	Stainless Steel Compression Spring
<u>T-18455L</u>	leg bow
<u>D-263M-05</u>	COMPRESSION SPRING
<u>D-207K-03</u>	COMPRESSION SPRING
<u>D-364J-22</u>	COMPRESSION SPRING
<u>Z-115F-111</u>	EXTENSION SPRINGS
<u>RZ-130AI</u>	EXTENSION SPRINGS
<u>D-252AG</u>	COMPRESSION SPRING
<u>D-331</u>	compression springs
<u>VD-190D</u>	COMPRESSION SPRING
<u>VD-288B</u>	compression spring
<u>VD-132</u>	COMPRESSION SPRING
<u>Z-162U-43I</u>	ZUGFEDER
<u>D-288X-04</u>	COMPRESSION SPRING
<u>D-283A-10</u>	DRUCKFEDER
<u>Z-097BI</u>	TENSION SPRING
<u>D-220A</u>	compression springs
<u>D-195A-10</u>	Compression spring
<u>VD-274</u>	Pressure Spring
<u>VD-248</u>	compression spring
<u>VD-190C</u>	Pressure Spring
<u>D-090X</u>	compression springs
<u>VD-130</u>	COMPRESSION SPRING
<u>VD-044</u>	compression spring
<u>VD-090J</u>	Compression spring
<u>VD-074B</u>	Compression spring
<u>VD-389N-03</u>	Compression Spring
<u>Z-120X</u>	Tension spring
P/N:G0004804; Type:C130-10L	Spring clip
<u>D-180Q-05</u>	COMPRESSION SPRING

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 18/24





Product	Description
<u>VD-180N</u>	compression springs
<u>VM-015</u>	Tension spring set
<u>D-282</u>	Compression spring (dxDexLo)
<u>Z-162K-21I</u>	Extension Spring
<u>Z-100LX</u>	Extension Spring
<u>M-014A</u>	
<u>VD-192</u>	Compression Spring
<u>T-19126L</u>	torsion spring
<u>T-19126R</u>	torsion spring
<u>D-154A</u>	compression spring
<u>Z-081E-06I</u>	Extension Spring
<u>RZ-097CX</u>	Spring
<u>D-274</u>	Compression Spring
<u>D-307</u>	Compression Spring
<u>D-276B</u>	Compression Spring
<u>D-249A</u>	COMPRESSION SPRING
<u>VD-026R-03</u>	Compression Spring
<u>VD-145DF</u>	Printing spring
P/N: 113143,Type: CET3-AR-CRA-AH-50X-SH-C2354- <u>113143</u>	SICHERHEITSSCHALTER UNICODE
<u>D-096</u>	SPRING
<u>D-180Q</u>	spring
<u>VD-288U</u>	Stainless Steel Compression Spring
<u>D-238</u>	COMPRESSION RING
<u>D-207J-39</u>	COMPRESSION SPRING
<u>D-188</u>	COLLAR BUSH
<u>D-239</u>	PRESSURE SPRING
<u>D-317A</u>	PRESSURE SPRING
<u>VD-409B</u>	BOW
<u>VD-323</u>	PRESSURE SPRING
<u>VD-2320</u>	COMPRESSION SPRING
<u>D-179G</u>	COMPRESSION SPRING
<u>D-486</u>	PRESSURE SPRING D-486
<u>D-400</u>	FRESSURE SFRING D-400
<u>D-398</u>	PRESSURE SPRING D-398
<u>D-398</u>	PRESSURE SPRING D-398
<u>D-398</u> <u>D-142A</u>	PRESSURE SPRING D-398 COMPRESSION SPRING
<u>D-398</u> <u>D-142A</u> <u>T-18811R</u> <u>T-18660R</u> <u>RZ-130K-02I</u>	PRESSURE SPRING D-398 COMPRESSION SPRING SPRING
<u>D-398</u> <u>D-142A</u> <u>T-18811R</u> <u>T-18660R</u>	PRESSURE SPRING D-398 COMPRESSION SPRING SPRING SPRING
<u>D-398</u> <u>D-142A</u> <u>T-18811R</u> <u>T-18660R</u> <u>RZ-130K-02I</u>	PRESSURE SPRING D-398 COMPRESSION SPRING SPRING SPRING TENSION SPRING
D-398     D-142A     T-18811R     T-18660R     RZ-130K-02I     D-180X     VD-265     D-313A-05	PRESSURE SPRING D-398 COMPRESSION SPRING SPRING SPRING TENSION SPRING compression spring
<u>D-398</u> <u>D-142A</u> <u>T-18811R</u> <u>T-18660R</u> <u>RZ-130K-02I</u> <u>D-180X</u> <u>VD-265</u>	PRESSURE SPRING D-398 COMPRESSION SPRING SPRING SPRING TENSION SPRING compression spring Compression Spring
D-398     D-142A     T-18811R     T-18660R     RZ-130K-02I     D-180X     VD-265     D-313A-05	PRESSURE SPRING D-398 COMPRESSION SPRING SPRING SPRING TENSION SPRING compression spring Compression Spring Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom





Page 20 / 24

Product	Description
<u>D-263M-01</u>	Compression Spring
<u>T-18733L</u>	Torsion Spring
<u>RZ-1221</u>	Extension Spring
<u>D-288Z-24</u>	Compression Spring
<u>VD-124</u>	Stainless Steel Compression Spring
<u>VD-143A</u>	Stainless Steel Compression Spring
<u>D-207JU</u>	Compression Spring
<u>D-313L-03</u>	Compression Spring
<u>Z-115W-21I</u>	Extension Spring
<u>Z-106GI</u>	Extension Spring
<u>Z-087HI</u>	Extension Spring
<u>VD-250</u>	Compression Spring
<u>D-234BD</u>	Compression Spring
<u>D-364R-05</u>	Compression Spring
<u>D-364R-48</u>	Compression springs
<u>RZ-11501</u>	Extension Spring
<u>D-207J-73</u>	Compression spring
<u>D-288K-13</u>	Compression Spring
<u>Z-1150X</u>	Extension Spring
<u>VD-225</u>	Compression Spring
<u>VD-270</u>	Compression Spring
<u>D-288J</u>	Compression Spring
<u>D-207J-85</u>	Compression Spring
<u>D-288Z-33</u>	Compression springs: D-288Z-33   Spring steel Ø 3 x 25 x 97 mm
<u>D-252A</u>	Compression spring
<u>VD-207J-08</u>	Spring
<u>VD-261A</u>	Spring
<u>T-18558R</u>	Torsion spring
<u>D-166J</u>	compression spring
<u>D-283A-07</u>	Compression Spring
<u>D-288X-12</u>	Compression Spring
<u>D-011Y</u>	Compression Spring
<u>Z-024NI</u>	Extension Spring
<u>D-303</u>	Compression Spring
<u>D-207K-02</u>	Compression springs
<u>D-145DC</u>	Compression spring
<u>D-122</u>	Compression Spring
<u>D-256</u>	Compression Spring
<u>VD-179J-11</u>	Compression Spring
<u>D-234B-08</u>	Compression Spring
<u>D-232G</u>	Compression Spring
<u>D-239A-12</u>	Compression Spring
<u>D-1800</u>	Compression Spring

Enapart Group ! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk





Product	Description
<u>D-288X-05</u>	Compression Spring
<u>VKM-12278</u>	Shape springs
<u>D-180Q-01</u>	spring
<u>D-180U-10</u>	compression spring
<u>VD-450</u>	Compression Spring
<u>D-200</u>	Compression Spring
<u>D-268D</u>	Compression Spring
<u>D-199B</u>	Compression Spring
<u>D-180-13</u>	Compression Spring
<u>24076</u>	Spring belt steel
<u>D-232T</u>	Compression Spring
<u>WF-130</u>	Compression Spring
<u>D-154B</u>	PRESSURE SPRING
<u>D-173C-10</u>	Compression Spring
<u>D-142D</u>	PRESSURE SPRING
<u>D-183</u>	PRESSURE SPRING
<u>D-184</u>	PRESSURE SPRING
<u>D-348A</u>	Compression Spring
<u>D-384A</u>	Compression Spring
<u>D-063H</u>	Compression Spring
<u>D-196A</u>	Compression Spring
<u>D-2630</u>	Compression Spring
<u>VD-219</u>	spring
<u>T-18585R</u>	Torsion Spring
<u>T-18585L</u>	Torsion Spring
<u>G0004804 (G0309771)</u>	Spring clip
<u>D-232J</u>	Compression Spring
<u>D-361</u>	Compression Spring
<u>D-257E-13</u>	compression spring
<u>RZ-081GI</u>	bows
<u>VD-062</u>	Compression Spring
<u>VD-338</u>	spring
<u>D-198A</u>	Compression Spring
<u>D-042F-05</u>	Compression Spring
<u>D-042G</u>	COMPRESSION SPRING
<u>VD-080C</u>	compression spring
<u>RZ-072F-011</u>	CLUTCH BELL TENSION SPRING
<u>D-355</u>	SPRING COMPRESSION
<u>VD-083</u>	COMPRESSION SPRING
<u>Z-036PI</u>	SPRING TENSION
<u>D-034</u>	COMPRESSION SPRING
<u>D-090P</u>	EXTENSION SPRING
<u>D-117B</u>	COMPRESSION SPRING

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Enapart Group





Product	Description
<u>VD-080B-02</u>	Compression spring
Druckfeder D- 249	Compression Spring
<u>VD-168</u>	Pressure spring
<u>VD-169</u>	Compression Spring
<u>VD-180-10</u>	Compression Spring
<u>VD-180Q-01</u>	Compression Spring
<u>D-145G</u>	Spring
<u>D-261</u>	compression springs
<u>D-313J-09</u>	Compression Spring
<u>VD-364R-12</u>	Compression spring
<u>Z-162U-40I</u>	tension spring
<u>D-207J-25</u>	Compression Spring
<u>VD-188</u>	Compression Spring
<u>D-250</u>	Compression spring
<u>VD-180Y-01</u>	Compression Spring
<u>D-090E</u>	compression spring
<u>D-180-14</u>	Compression Spring
<u>RZ-024WI</u>	Extension Spring
<u>D-207J-31</u>	Compression Spring
<u>D-288Z-20</u>	Compression Spring
<u>Z-159AX</u>	extention spring
<u>RZ-0671</u>	Extension Spring
<u>VD-185E</u>	Compression Spring
<u>D-180M-10</u>	pressure spring
<u>VD-207J-90</u>	Compression Spring
<u>D-132B</u>	Compression Spring
<u>VD-115D-01</u>	Compression Spring
<u>VD-206D-12</u>	Compression Spring
<u>D-102</u>	Compression Spring
<u>VD-090X</u>	compression spring
<u>D-115J</u>	Compression spring
<u>D-207J-70</u>	Compression Spring
<u>D-143D</u>	compression spring
<u>VD-227D</u>	Compression spring, dd.1.6mm, da.11mm, Lo.22.8mm
<u>VD-217E</u>	Compression Spring
<u>D-259</u>	Compression Spring
<u>RZ-106BI</u>	Compression Spring
<u>D-288X-02</u>	Compression spring
<u>VD-313K-01</u>	Compression Spring
<u>D-090W</u>	Compression spring
<u>VM-032</u>	Compression Spring
<u>VM-031</u>	Compression Spring
<u>D-080B</u>	Compression Spring

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom ! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk Page 22 / 24





Product	Description
<u>D-232E</u>	pressure spring
<u>T-17021L</u>	Torsion spring
<u>T-17021R</u>	Torsion spring
<u>T-17031L</u>	Torsion spring
<u>T-17031R</u>	Torsion spring
<u>D-185E</u>	compression spring
<u>D-232H</u>	Compression spring
<u>D-263K</u>	compression spring
<u>Z-115V-17I</u>	Extension Spring
<u>D-239A-06</u>	Compression spring
<u>D-238A</u>	compression spring
<u>D-180-07</u>	compression spring
<u>D-095E</u>	Compression spring
<u>D-207J-30</u>	compression spring
<u>D-008A</u>	compression spring
<u>D-263V-06</u>	compression spring
<u>D-387</u>	compression spring
<u>D-318C</u>	compression spring
<u>D-251</u>	compression spring
<u>D-092</u>	compression spring
<u>D-145DF</u>	Compression spring
<u>VD-187</u>	compression spring
<u>VD-180O-01</u>	compression spring
<u>RZ-0851</u>	Tension spring
<u>D-180Y-08</u>	Spring
<u>VD-179J-13</u>	Spring
<u>VD132C</u>	Compression Spring
<u>VD-099</u>	compression springs
<u>D-207J-10</u>	Compression springs
<u>D-207JG</u>	compression spring
<u>D-067</u>	compression spring
<u>VD-142D</u>	Compression Spring
<u>D-7000-068- RZ-100FX</u>	tension spring
<u>RZ-051HI</u>	extension spring
<u>D-445</u>	COMPRESSION SPRING
<u>VD-232P</u>	compression springs
<u>D-180P-01</u>	Compression Spring
<u>D-090U-10</u>	Compression Spring
<u>Z-015DI</u>	Extension Spring
<u>D-400</u>	compression spring
<u>D-279</u>	compression spring
<u>D-202</u>	compression spring
<u>D-339E-01</u>	Compression springs





Product	Description
<u>RZ-147K-041</u>	extension spring
<u>Z-115V-33I</u>	Extension Spring
<u>Z-109CI</u>	Extension Spring
<u>Z-1011</u>	Extension Springs
<u>KM-3350</u>	compression spring
<u>D-180P-02</u>	compression spring
<u>RZ-115V-311</u>	Extension Springs
<u>D-199</u>	compression spring
<u>RZ-177MX</u>	Extension Springs
<u>VD-252A-30</u>	compression spring
<u>VD-295</u>	compression spring
<u>Z-056X</u>	extension spring
RZ-024AGI	extension spring
<u>VD-117R</u>	compression spring
<u>VD-148</u>	Compression springs
<u>D-239B</u>	compression spring
<u>VD-252A-05</u>	compression spring
<u>D-195</u>	compression spring
<u>VD-207J-11</u>	compression spring
<u>VD-180Q-02</u>	compression spring
<u>RZ-1401</u>	mainspring
<u>VD-300A</u>	compression spring