



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Hahn Gasfedern

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
G14-28ST-30650	Parts designator
G 14 28 0150 1 0400 AU27 AB16 01500N	End fitting piston rod
1095689 900N	
G 08 19 0150 1 0362 GZ10 GZ10 00300N (1241189 800N)	
G10-23ST-33691	gas spring
G 06 15 0150 1 0335 GZ07 GZ07 00145N	gas spring
G 08 19 0100 1 0300 AU19 AB11 00300N	
G14-28ST#32664	gas spring
G10-23ST-36589	gas spring
G06-15ST-10710	gas spring
28-039HJ	Stah door holder
G 08 19 0100 1 0332 WG30 GA32 00500N /5/Si/V2	
ART NR:1090158 Teilebezeich. : G 08 19 0120 1 0330 AU19 AB11 00500N	
G 10 23 0080 1 0266 WG18 WG18 00300N (Baugleich 1271222)	
1271222	gasfered
G 10 23 0080 1 0266 WG18 WG18 00300N (1321032)	Gas Spring
D 08 23 0080 2 0240 AR16 AR16 00000N /6	GAS SPRING
1096977	
G 06 15 0120 1 0310 WG22 WG22 00170N /5/V2	
372014 70N	gas springs
G08-19ST-28459	Gas spring
Z 10 28 0080 0 0298 AR19 AR19 00600N /5	
G 14 28 0200	G 14 28 0200 1 0500 AK21 AB16 01900N
880N Art.-Nr.1197836	
Z10-28ST-07543	GASFEDERN
1168638 200N	Gas spring
1097367 150N	Gas spring
G 06 15 0080 1 0245 GA20 AB09 00130N	GAS SPRING
Z 10 28 0130 0 0420 WG30 WG30 00650N /5	
370132 700N	
396790 -1250N V2A	Gas federn
Z10-28V4-00419	tension gas spring
G 10 23 0100 1 0270 AU19 AB11 01000N	
1271990	
G 10 23 0250 1 0598 WG30 WG30 00500N	

Product	Description
197255 350N	
G 06 15 0080 1 0235 WX22 WX22 00040N	Gas spring
G 14 28 0200 1 0500 AK21 AB16 01300N	Gas spring
G 14 28 0200 1 0500 AK21 AB16 01700N	
G06-15ST-20095	Gas spring
G 10 23 0200 1 0483 AU19 AU19 00800N	Gas spring
210090-600N	Steel gas springs
210093-400N	Steel gas springs
1232024	
G20-40ST-04470	gas spring
G 10 23 0040 1 0150 GZ10 GZ10 00700N /6	Shock Absorber
D 06 19 0150 1 0379 WX22 WX22 00000N	OIL- DAMPER TYPE D6-19
G14-28ST-12490	Gas spring
G 10 23 0450 1 0992 KG10 WX30 00400N /5	compression cylinder
TF06-15ST-0108	
Z 10 28 0350 0 0871 WG35 WG35 00900N /5/6/Si / Z10-28ST-08157	tension gas spring
13952.1	
G10-23ST-32204	Steel gas spring
G 14 28 0700 1 1577 WG35 WG35 00500N /5/Si	Steel gas spring
G08-19ST-34332	Gas spring
G10-23ST-39768	Gas spring steel
Z 28 40 0150 0 0614 AG57 AG57 02400N /5	GASFEDERN
Z10-28ST-07268	Tensile gas spring
G 10 23 0400 1 0900 AU19 AB11 00430N	Gas Spring
G06-15ST-26260	
253674 620N	Gas spring
G14-28ST-25305	GAS SPRING
G 14 28 0350 1 0850 WG35 WG35 00400N /4	
Art.-Nr 2 304 74	
328218	
107831.1	gas spring
51525.3	gas spring
31340 600N	Gas spring
G14-28ST-26594	piston
X10-23-40-0-225 AU19 AU19 1000 N /1	
S10-23V2-00121	Gas spring, lockable
Art. Nr. 1197840 (830N)	Gasfedern
1104259 450N	
G08-19ST-34482	Steel gas spring
Z 10 28 0180 0 0669 WG30 GA32 00550N /5	
Z 10 40 0350 0 0912 AU42 AZ20 01200N /5	
S 10 28 0120 1 0419 BD35 AU19 00550N /7/9	gas spring
G 20 40 0350 1 0928 WG45 WG45 02750N /1/4/5/V4	

Product	Description
G 20 40 0350 1 0928 WG45 WG45 01730N /1/4/5/V4	
G 14 28 0180 1 0537 WG35 WG35 01550N /1/4/5/V4	
122344.1 5000N	Gas spring
G 10 23 0200 1 0919 WG30 AU19 00850N	gas spring steel
G06-15ST-18186	gas spring
300632 (G 14 28 0200 1 0485 AU27 AB16 00500N)	
325208	
G06-15ST-19406	Gas Strut 06-15 Steel
G 14 28 0200 1 0535 GA40 GA40 01700N	GASFEDERN
G14-28ST-23747 (G 14 28 0250 1 0548 GZ12 GZ12 01600N /5)	GASFEDERN
Z 10 40 0168 0 0584 WG35 WG45 01600N /5 / Z10-40ST-00605	tension gas spring
Art. Nr. 300632 , type G 14 28 0200 1 0485 AU27 AB16 00500N	GAS SPRINGS
G 14 28 0200 1 0485 AU27 AB16 01000N	GASFEDER
314223-185N	
G08-19ST-30089	
G 14 28 0300 1 0750 AU27 AB16 01300N	gas spring
87558.2	gas spring
X10-23-40-0-225 AU19 AU19 750N/1/	Piston
G14-28ST-25140	gas spring
G14-28V2-06491	
G04-12ST-07170	gas spring steel
H001G5	GAS SPRING, STEEL, SIL
1082045 600N	gas spring
61809.1	
G 06 15 0150 1 0399 WG22 WG22 00220N	gas spring
G10-23ST-41753	
146925.1 280N	Shock absorber
G 06 15 0080 1 0225 AU16 AB09 00140N (G06-15ST#25125)	
T06-15ST-00255	gas springs
G 14 28 0600 1 1350 GZ12 GZ12 00700N /5 Sickenausführung	Gas Shock for machine door
G 08 19 0200 1 0500 WG30 WG30 00200N /1/4/5/V4 (144030.2)	
G 14 28 0060 1 0175 GZ12 GZ12 02500N /5 (1-5 pieces)	
G 14 28 0060 1 0175 GZ12 GZ12 02500N /5 (6-10 pieces)	
G 06 15 0100 1 0299 WG22 WG22 00250N	
Z 10 28 0250 0 0675 PF30 PF30 00800N /1/4/5/V4	
G 06 15 0050 1 0180 AS20 AS20 00400N	Seat piston
G 10 23 0150 1 0386 WG18 WG18 00600N	
100373.1	gas spring
G 08 19 0250 1 0630 WG30 WG30 00320N	
G 08 19 0120 1 0350 AU19 AB11 00400N	
G 10 23 0100 1 0302 AR16 AR16 00XX0N (500N)	
G 10 23 0100 1 0302 AR16 AR16 00XX0N (250N)	
G 14 28 0250 1 0600 WG35 GZ12 00650N	Gasfeder

Product	Description
1053433	
1155679	
1058178	
S 10 23 0060 1 0260 GZ18 WG18 00250N /5/7	
ANS/M08/WIG/005 WG18 M8 CS1	
G08-19V2-03223 old No. / new No. G08-19V2#04386	
G 06 15 0050 1 0183 AG27 AB09 00150N	
G 14 28 0150 9 0420 WG35 WG35 02020N / 28-022YP	gas spring steel
G 10 23 0250 1 0650 WG30 WG30 01250N	Gas spring
G 08 19 0100 1 0300 AU19 AB11 00700N	
341535 (800N)	Shock absorber
G 08 19 0200 1 0445 GZ10 GZ10 00200N /5/V2	gas spring
G 14 28 0180 1 0815 WG35 AB16 00550N (383259-550N)	gas spring
G 10 23 0200 1 0500 GA32 AB11 00250N (54919 - 250N)	gas spring
1418948-1900N	GAS SPRING
G 06 15 0100 1 0280 WG22 WG22 00200N	
G06-15ST-24180	GAS SPRING
113362.1 - 350N	piston
344482 - 600N	
56121.1 -1200N	Gas spring
G 06 15 0100 1 0280 AU16 AU16 00180N /5	gas spring
1400193- 400N (G 10 23 0120 1 0345 WG30 WG30 00400N)	gas spring
G 08 19 0250 1 0585 WG18 WG18 00600N	gas spring
G 08 19 0120 1 0350 AU19 AB11 00600N	piston
Z 28 40 0300 0 0875 GZ18 GZ18 03000N /5/V2	
G 14 28 0200 1 0544 WG35 WG35 01900N	gas cylinder
G10-23ST-41548 / G 10 23 0100 1 0331 WG30 WG30 01000N	Steel gas spring
80.94K40-9644 Type:G06-15ST-20019	gas spring
80.94K40-9612	Gas Spring
G10-23V2-06886	Gas spring V2A
31809 - 500N \ G10-23ST-40781	Gas spring
G 08 23 0140 0 0355 AU19 AB11 00600N	Steel gas spring
G 10 23 0100 1 0331 WG30 WG30 01000N 15pc-set	Gas spring
Art.-Nr.: 1236956 -500N	Sick execution
Z 10 28 0150 0 0470 WG35 WG35 00250N /5/Si (Z10-28ST-06985)	Tension gas spring
G 08 19 0080 1 0267 AU19 AB11 00250N / 28-013WX	Steel gas spring
G 14 28 0250 1 0585 AU19 AU19 01150N /5/V2	gas spring
326534 (G 08 19 0120 1 0330 AU19 AB11 00650N)	gas spring
Z 10 40 0060 0 0372 AG57 WG45 02000N /5	spring
G20-40ST#05058	Shock absorber
256498- 650N	gas spring
G 06 15 0080 1 0245 GG20 AB09 00130N	Gas spring
G 14 28 0100 0 0380 AU27 AB16 01300N (G14-28ST-25140)	gas spring

Product	Description
G 14 28 0120 1 0350 AU27 AU27 01500N /5/SI/V2 / G14-28V2-07704	gas spring V2A
102275.1.	
198084	
1 083 10 9	Shock Absorbers
1 076 16 0	shock absorbers
137790 620N (G 14 28 0090 1 0323 AG43 GG40 00620N)	compression gas spring
122257.1	
158007.2	Piston
132129.1 (F 10 23 0120 1 0331 GZ18 AU19 01000N /1/4/5/V4.)	Gas spring
136331.2	High pressure gas spring
094k962340	gas spring
S 10 28 0100 1 0336 GZ18 AB16 00500N /7	Gas cylinder
G 08 23 0120 1 0480 WG30 WG30 00500N /5	gas spring
Art.No.351164 - 620N	strut
G14-28ST-19342	
1358349 400N	
D 06 19 0170 1 0419 WG22 WG22 00000	
G 20 40 0100 1 0400 AU42 AZ20 02000N /5 (G20-40ST-05691)	Gas Spring
G 14 28 0120 1 0345 AU27 AU27 01500N /5/V2	
G 14 28 0250 1 0610 AU27 AB16 01500N	
113362.1 - 150N	Piston
Z 06 19 0150 0 0436 WG18 WG18 00080N /5	Gas spring
113362.1 - 120N	Piston
G 14 28 0200 1 0500 AK21 AB16 01900N	Gas spring
113362.1 - 1000N (100kg.)	Piston
G04 12 0060 1 0152 Gz05 Gz05 00180N/5	Gas Spring
G 06 15 0120 0 0276 GZ11 GZ07 00225N	
G14-28ST-23382	Gas spring
63542.1	Spring
G 14 28 0300 0 0710 AG43 AG43 02000N (Art.Nr.315135)	GAS SPRING
G 06 15 0200 1 0450 GA20 AB09 00050N	Gas Spring
G 06 15 0060 1 0200 WG22 WG22 00110N /5	GAS PISTON
G06-15ST-19459 (1283260)	Shock absorber
G08-19ST-27314	gas spring
6 15 80 1 245 WG22 WG22 200N	GAS SPRING
G10 23 130 1 558 WG30 WG30 400N	SPRING GAS
N 4500 Art. Nr. 1222017	cylinder
94702.1 - 800N	pull type gas spring
G06-15ST-19689	GAS PISTON
G14-28ST-25306	gas shock
G08-19ST-16572	
G08-19V2-03178 (p/n.1210459) L=400mm	stainless steel cylinder
G06-15ST-19758	

Product	Description
G08-19ST-27680	shock absorber
G08-19ST-27681	shock absorber
G06-15ST-19769	shock absorber
G06-15ST-19770	shock absorber
G06-15ST-19771	shock absorber
G14-28ST-25383	
G10-23ST-23508	
G10-23ST-27385	Shock absorber
G 08 19 0080 1 0265 WG30 WG30 00400N /5	
D08-23ST-00824	Piston
1343516 (Type G14-28ST-25579)	gas cylinders
Z10-28V4-00341	gas spring
G 14 28 0200 9 0541 AU27 AU27 02000N /5/Si/V4	stainless steel gas strut
Z10-28ST-06855	Tension gas spring
G14-28ST-25645	cylinder
G14-28ST-25649	
100N 1320992	gas spring
Z10-28ST-06882	Tensile gas spring
1164317	Piston
G20-40ST-06074	gas spring
G14-28ST-18399	
346222	Usable stroke less than nominal stroke
G14-28ST-21130	Gas spring
G06-15ST-20258	shock absorber
G10-23ST-35726	
G10-23ST-35727	
G 08 19 0060 1 0184 AU19 AB11 00300N (G08-19ST-28404)	Gas spring
1128360 750N(Art.Nr.G14-28ST-25944)	shock absorber
1034191	Gas spring
G06-15ST-18403	Gas spring
G06-15ST-22610	Steel gas spring
G06-15ST-20417	Gas spring
31995.2 (Hahn P/N:G14-28ST-12530)	Gas spring
S10-28ST-03517 (1356777)	Gas spring, lockable
G06-15ST-20442	gas shock
G08-19ST-28626 / H001VN	Gas spring
305274 (1400N)	gas spring
G08-19ST-28627	
S10-28ST-03802	cylinder
T06-15ST-00282	gas spring
G14-28ST-26345	cylinder
G08-19V2-02874	
229441.1	gas spring

Product	Description
AK150594050	Gas spring
G10-23V4-LC-00354	Spring
BA01/Z08/V4	Bracket
G08-19ST-28865	Gas spring
G06-15V4-00831	Gas spring
G14-28V4-LC-00280	Gas spring
G06-15ST-19931 (1425797)	Gas spring
G14-28V2-03796	Gas spring
G14-28-28ST-00307	AMASEUR
Z10-28V2-01291 / 28-03AVB	gas piston
G06-15V2-02178 / 28-00MPC	gas piston
X 10 23 0078 1 0399 GZ18 GZ10 00330N /3/4/V2	
G08-19ST-28544	Gas Spring
G20-40ST-06130	Gas Spring
G14-28ST-24966	Gas Spring
G10-23ST-18967	Piston
X10 23 78 1 399 GZ18 GZ10 200N/3/4/V2 12/17	
G10-23V2-05145	gas spring
142585.10 - 450N	Pull gas spring
G14-28ST-26721 (# 81437.1 -2200N)	Gas Spring
G10-23ST-39706	
G08-19ST-29225	
G10-23ST-17812	Gas spring
S10-23ST-01235	gas spring
G06-15ST-12265	
G14-28ST-19712	Gas spring
Art.Nr.Z10-28V4-00366 (100493.1 ,800N)	Tension gas spring
D10-28ST-00336 (1424910)	Oil brake
G14-28ST-25972	shock absorber
Spare part for 1900 2/68 45 0503	
G14-28ST-22157	Gas spring
G14-28ST-26453	
G08-19ST-17193	Gas spring
1213968	Gas spring
G14-28ST-26453 3	Gas spring
G14-28ST-22916	
701100A	
701101A	
804032A	gas spring
G10-23ST-35458	gas spring
G06-15ST-20203	gas spring
G10-23ST-39125 / Art.Nr. 85764.1	Steel gas spring
H0022T / G 10 23 0150 1 0430 WG30 WG30 00650N	gas spring

Product	Description
G08-19ST-17055	
G14-28ST-28215	Gas Pressure Spring
G14-28ST-24479	gas spring
G14-28ST-20971	
G08-19ST-25611	gas spring
G10-23ST-33125	gas spring
G14-28ST-27330 (28-02635)	gas spring
G14-28ST-27331	
G14-28ST-27332	
G14-28V2-03748	gas spring
G14-28ST-26445	gas spring
G10-23ST-36331	gas spring
G14-28ST-26871	gas spring
G14-28ST-27453	
G06-15ST-19846	gas spring
G08-19V2-02783	
G14-28ST-27565	gas spring
G14-28ST-23433	
G08-19ST-17260	gas spring
G14-28ST-13311	gas spring
G08-19ST-28684	
G20-40ST-06672	gas spring
G20-40-40ST-00240 / 1015494	gas spring
G20-40-40ST-00383	
G10-23ST-31847	gas spring
G14-28ST-22975	gas spring
G08-19ST-30384	gas spring
G10-23ST-34851	gas spring
G14-28ST-25359	Gas Strut
G08-19ST-26314	gas spring
G14-28ST-18233	gas spring
G06-15ST-20788	Gas strut
G14-28ST-22923	gas spring
G08-19ST-30486	gas spring
G06-15ST-12209	gas spring
G06-15ST-17566	Gas spring
G06-15V4-00882	gas spring
G14-28ST-27908	Gas Spring
G10-23ST-31276	
G06-15V2-02524	gas spring
G04-12ST-06472	gas spring
135330.3	shock absorbers
G06-15ST-14795	Gas spring

Product	Description
G06-15V2-02600	gas spring
G14-28ST-28050	gas spring
Z10-28ST-07280	Train Thumb
G20-40-40ST-00232	Gas spring
G08-19ST-15586	
G10-23ST-31991	gas spring
G10-23ST-37723	gas spring
G04-12ST-06439	gas spring
G10-23ST-31419	gas spring
G06-15ST-21886	Gas Spring
G10-23ST-38123	gas spring
G22-40ST-01073	gas spring
G10-23ST-34541	gas spring
G08-19ST-27591	
G10-23ST-38478	Gas spring
G08-19ST-30937	gas spring
G06-15V2-02418	gas spring
G14-28ST-25941	gas spring
Z10-40ST-00672	gas spring
Z10-28ST-07374	Train Thumb
G14-28ST-20678	gas cylinder
Z10-28ST-07134	Train Thumb
G10-23ST-37037	gas spring
G08-19ST-16990	gas spring
G10-23ST-31668 (373100)	gas piston
G14-28ST-19039	gas spring
G14-28ST-25297	
G10-23ST-35027	gas spring
Z10-28ST-06572	gas piston
G08-19ST-31106	
G08-23ST-01443	gas piston
1277528	
80308.1	
1281939	gas spring
1224188	gas spring
G14-28ST-27701	
G10-23ST-38901	gas spring
G14-28ST-28397	gas spring
G14-28ST-25846	Gas spring
G08-19ST-29389	gas spring
G10-23ST-38980	Gas spring
G14-28ST-22872	Gas spring
48295.1	gas strut 06-15 steel

Product	Description
Z10-28V4-00411	Pull-type gas spring
G10-23ST-30337	gas spring
G14-28ST-24797	Gas spring
G04-12ST-06728	gas spring steel
G06-15ST-22300	
G14-28ST-28801	gas spring
G 10 23 0150 1 0408 AU19 AU19 00800N	Gas spring, steel
G10-23ST-30075	
G 04 12 0030 9 0115 AU11 AB07 00060N	gas spring
122849.1	gas spring
G04-12STLA0001	gas spring
G10-23ST-38953	
G14-28ST-28211	
G14-28ST-22815	Gas spring
G20-40ST-06828	Gas spring
G 04 12 0050 1 0160 AU11 AB07 150N	Gas spring
1159359	Gas spring
G10-23ST-36573	
G10-23ST-39458	gas spring steel
G14-28ST-19918	Gas spring
G10-23ST-28404	Piston
G10-23ST-19056	
G08-19ST-31787	GAS-FILLED SPRING
G06-15ST-18990	gas spring
S10-28ST-03923	Lockable gas spring
G06-15ST-19219	Gas spring steel
303090, G14-28ST-23382	Gas strut
Z10-28ST-05941	Gas Spring N:650
Z10-28ST-06337	
Z10-28V4-00606	Pull-type gas spring
G10-23ST-31671	Gas spring
G10-23V2-05819	Gas Spring V2A
G10-23ST-33313	gas piston
G06-15V2-02748	
33452.1 5200N / G25-55ST-00293	Gas spring steel
G20-40ST-07183	
G14-28ST-23374	Gas spring steel
G08-19ST-30069	Gas spring
G14-28ST-28684	Gas spring steel/2500N
G04-12ST-06966	
G14-28ST-27652	Gas spring
G14-28ST-26562	gas spring
G10-23ST-24568	lifting piston

Product	Description
G08-19ST-32167	jack
S 10 28 0120 1 0384 GZ18 AU19 00550N /7/9	Gas spring block. (rigid) ST
G10-23ST-39951	Gas spring steel
G06-15ST-11975 70N	Gasdamper
G06-15ST-11975 100N	
G14-28ST-28639	gas spring
G08-19ST-24724	
G08-19ST-27293	gas strut
G14-28ST-23282	
Z10-28ST-06035	
Z10-28ST-05905	
G14-28ST-13400	Gas spring
Z10-28ST-05976	gas molla
G14-28ST-18265	damper
Cylinder filling case	cylinder inflation case
G06-15ST-18056	gas strut
Z10-28STU-00160	Pull gas spring
G 06 15 0080 1 0226 GZ07 GA20 00170N	Steel gas spring
Z10-28ST-05743	gas spring
S10-28ST-04667	
G14-28ST-25188	Assembly with piston rod
G14-28ST-25346	Gas spring
G08-19ST-32369 (61468.2)	Piston and rod assembly
G08-19ST-15667	Gas spring steel
G08-19ST-24179	
47G10-23ST-40211789.2	Gas spring steel
G20-40V2-00968	Gas spring V2A
G08-19ST-16510	Gas spring
G08-19ST-26490	Gas spring steel
G08-19ST-32413	gas spring
G08-19ST-17570	gas spring
G10-23ST-40249	Gas spring steel
G08-19ST-27355	Gas spring
G10-23V2-05069	
G06-15ST-17870	Gas strut
G06-15ST-10971	gas spring
G06-15ST-22680	
G08-19V4-01145	gas spring
G06-15ST-23024	Gas spring steel
G08-19ST-30320	gas spring
G10-23ST-40176	gas spring
G14-28ST-29440	Gas spring steel
G14-28ST-28035	gas spring

Product	Description
G14-28ST-29431	Gas spring steel
G20-40-40ST-00486	Gas spring steel
G08-19ST-32667	Gas spring steel
G06-15ST-11530	gas spring
G10-23ST-31126	Gas spring steel
G08-19ST-22439	gas spring
G10-23ST-35011	gas spring
G06-19V2-00049	Gas spring V2A
G 08 19 0250 1 0630 WG30 WG30 00700N/5	Gas spring
G04-12ST-07216	Gas spring steel
G14-28ST-22504 / G 14 28 0200 1 0500 AK21 AB16 02000N	gas spring
G06-15ST-23120	Gas spring steel
G 14 28 0200 1 0500 AK21 AB16 02000N	
G10-23ST-32147	Gas spring steel
G14-28ST-25125	gas spring
G14-28ST-25597	gas spring
G06-15ST-19642	gas spring
G10-23ST-21285	Gas spring steel
G10-23ST-35276	gas spring
Z10-40V2-00083	tension gas spring
G20-40ST-04083	gas spring
G8 19 80 1 255 WG18 WG18 300N	gas spring
Z10-28V4-00366	tension gas spring
G06-15ST-23200	Gas spring steel
G10-28ST-02738	gas spring
G03-10ST-00865 1pcs	Gas spring steel
G10-23ST-40850	Gas spring steel
G03-10ST-00865 (6 pcs)	
G03-10ST-00865 (11 pcs)	
G03-10ST-00865 (101 pcs)	
G06-15ST-21469	gas spring
Z10-28ST-06654	dampers
G06-15ST-23280	Gas spring steel
G14-28ST-13312	gas spring
G14-28ST-30166	Gas spring steel
G14-28ST-29021	Gas spring steel
G10-23ST-40965	
G14-28V4-01199	
G14-28ST-25997	Gas spring
G06-15ST-23362	
G22-40STLA0002	gas spring
G10-23ST-41051	Gas spring steel
Z10-28ST-07850	Tension gas spring steel

Product	Description
SDD04-12ST- S0034	
G10-23ST-41070	Gas spring steel
G14-28ST-16234	
G06-15ST-14750	Gas spring steel
G10-23ST-41129	gas spring
G14-28ST-28592	
G10-23ST-41181	Gas spring steel
G10-23ST-41216	
G10-23ST-41215	
G14-28V2-07965	Gas spring V2A
G10-23ST-19195	Gas spring steel
G06-15ST-13270	Gas spring steel
G08-19ST-32397	Gas spring steel
G08-19ST-27805	GAS SPRING
538-43025-0400G6	
G06-15ST-23497	Gas spring steel
G14-28ST-29272	Gas spring steel
Z10-28ST-07018	gas shock absorber
G06-15ST-23498	Gas spring steel
G14-28V2-07787	stainless steel spring
G14-28ST-30241	Gas spring steel
G10-23ST-31482	gas piston
G08-19V4-01125	gas piston
G06-15V2-02948	Gas spring V2A
G06-15ST-23532	Gas spring steel
G14-28ST-21489	Gas spring steel
G10-23ST-24983	Gas spring steel
G14-28ST-30586	Gas spring steel
G10-23ST-41457	Gas spring steel
G10-23ST-41484	gas spring steel
G14-28V2-08023	
G08-19V4-01324	gas spring V4A
G14-28V2-08030	Gas Spring
G04-12ST-06902	gas spring steel
G14-28ST-30645	gas spring steel
G14-28ST-30670	
G10-23ST-41610	gas spring steel
SDD06-15ST- S0007	Sliding door damper
G20-40ST-07567	
G04-12STLA-ZBH0001	gas spring
G14-28ST-30779	gas spring steel
G 20 40 0100 1 0400 AU42 AZ20 02000N /5/Si (G20-40-07576)	Gas spring, steel
G4 140 1 330 AU 11 AB 07 40 (G04-12STLA-ZBH0001)	damper

Product	Description
G10-23ST-39488 (204337.I)	gas spring steel
G06-15ST-23698	Steel gas spring
G06-15ST-23700	Gas spring
G 14 28 0200 1 0500 AK21 AB16 01900N (G14-28ST-25297)	gas spring
138976.7 2500N / G14-28V2-08055	gas spring
G20-40ST-07607	GAS SPRING
G 14 28 0100 1 0350 AU27 AU27 01300N /5/Si/V2 / G14-28V2-06632	gas spring
G 14 28 0200 1 0500 AK21 AB16 01100N / G14-28ST-30989	gas spring steel
G14-28ST-31022 / 212794	gas spring steel
G14-28ST#31018	gas spring
G25-55ST-00327	damper
X 10 28 0035 9 0256 GZ18 AB1600475N/4/7	gas spring
G14-40ST-00923	
G14-28ST-31037	
X 10 28 0035 9 0256 GZ18 AB16 00475N /4/7 Lange=240	
G10-23ST-37638	piston
G20-40ST-07649	gas spring steel
G20-40ST-07652	cylinder
G14-28ST-22504	gas spring
Z 10 28 0350 0 0865 AG36 AU19 00900N /5/Si / Z10-28ST-08069	tension gas spring
G10-23ST-42280	
154668.2 / H-Z10 28 0020 0 0200 WG30 WG30 00350N/5	Traction piston
5696636529	gas spring
102839.1	
24409.1 / G08-19ST-28644	gas spring
G 06 15 0080 1 0226 GZ07 GA20 00200N /5 / G06-15ST-24069	gas spring steel
G08-19ST-34217	gas spring steel
G14-28ST-22267	gas spring
G10-23ST-38569	gas spring
G06-15ST-24152	gas spring steel
G 14 28 0120 1 0350 AU27 AU27 01300N /5/Si/V2 / G14-28V2-08274	gas spring V2A
G 08 19 0050 1 0195 WG18 AU19 00100N /5/Si/V2	Gas Spring
G08-19ST-30566	gas spring
Z10-28ST-08146	Tension gas spring
ART-NR 72658.1 / G10-23ST-33691	gas spring
11.11171 - 0007	Shock Absorber
Z10-40ST-00819	tension gas spring steel
G08-19ST-28391	gas spring
G08-19ST-34479	Gas spring
G08-19ST-30084	gas spring
G04-12ST-07730	spare part
G14-28V2-08205	gas spring
G08-19V4-01382	V4A gas spring

Product	Description
G 10 23 0200 1 0458 KG10 GZ10 00700N / G10-23ST-42866	Steel gas spring
S 10 28 0100 1 0330 GZ18 AB16 00900N /7 / S10-28ST-04997	Gas spring block. (rigid) ST
G08-19V2-04214	V2A gas spring
Gas spring 14-28 Stroke 200 Long	Gas spring
G 06 15 0080 1 0245 GG20 AB09 00300N / G06-15ST-24320	Steel gas spring
G20-40V4-00413	V4A gas spring
M10 Eye (8.1mm)	Mounting part
G08-19V2-04248	V2A gas spring
G10-23ST-42944 /	Steel gas spring
28-022KX	Steel gas spring
G 14 28 0200 1 0500 AK21 AB16 01500N / G14-28ST-29272	Steel gas spring
123118.2	Gas Spring
SDG04-12ST- V0001	
G10-23ST-42866	Steel gas spring
G 08 19 0200 1 0500 AR16 AR16 00500N /5/Si/V2	
G14-28ST-31602	
G14-28V2-04999	V2A gas spring
G10-23ST-43100	Steel gas spring
G20-40ST-07898	Steel gas spring
G10-23ST-42869	Steel gas spring
G06-15ST-23291 / 106140.2	Steel gas spring
218820.1	
G08-19ST-34811 / Art.Nr. 381339	Steel gas spring
G08-19ST#34858 / G 08 19 0120 1 0315 AU19 AB11 00220N	Steel gas spring
G14-28ST-29645	Gas spring
T06-15ST-00237	Steel door lock
G 14 28 0100 0 0380 AU27 AB16 01300N	gas spring
SDD04-12ST- V0001	damper
G08-19ST-34929	Steel gas struts
G14-28ST-31919	gas piston
8-19-220	Gas Spring
G08-19ST-33520	gas spring steel
H001W1	Gas Spring
G14-28ST-28679	gas spring steel
G14-28ST-28734	gas spring steel
G08-19ST-35073	gas spring steel
G10-23ST-43401 / G 10 23 0400 1 0919 WG30 AU19 00850N	gas spring steel
1033185 / G10-23ST-38111	gas spring
G10-23ST-43384 / G 10 23 0150 1 0442 AG36 AG36 00900N	gas spring steel
80.94K40-9533 / G06-15ST-23701	Steel gas spring
G08-19ST-35141	Steel gas spring
G06-15ST-24685 / G 06 15 0100 1 0280 AU16 AB09 00100N	Steel gas spring
G14-28ST-32054 / G 14 28 0100 9 0360 AU27 AB16 02020N	gas spring

Product	Description
G10-23ST-37638 / 87184.3	piston
G14-28ST-32139	
G10-23ST-36827	gas spring
G08-19ST-35259	Steel gas spring
G10-23V2-06477	V2A gas spring
G10-23ST-41692	Steel gas spring
G10-23ST-43358	Steel gas spring
G08-19ST#25191/ G 08 19 0100 0 0290 AU19 AR16 00500N	
G08-19ST#25191 / G 08 19 0100 0 0290 AU19 AR16 00700N	
G 08 19 0100 1 0300 WG18 WG18 00150N / G08-19ST-33341	Steel gas spring
G 08 19 0100 1 0300 WG18 WG18 00200N / G08-19ST-33372	Steel gas spring
G 08 19 0060 1 0230 WG18 WG18 00350N / G08-19ST-27533	gas spring
G 10 23 0200 1 0530 WG30 WG30 00300N / G10-23ST-43290	Steel gas spring
G 10 23 0200 1 0530 wg30 wg30 00250 / G10-23ST-35512	gas spring
G08-19ST-33946 / G 08 19 0060 1 0200 PF18 WG18 00240N	Steel gas spring
G06-15ST-22841 / G 06 15 0110 1 0300 WG22 PF22 00070N	Steel gas spring
G08-19ST-34130 / G 08 19 0120 1 0330 WG30 WG30 00800N /5	Steel gas spring
G06-15ST-24764 / 1111971 300N	Steel gas spring
S10-23ST-01991	Gas spring block.
G10-23V2-06517	V2A gas spring
G06-15ST-23360	Steel gas spring
G10-23ST-35766	gas spring
G10-23ST-37739	gas spring
Z10-28ST-07562	Tension gas spring
F06-19ST-00124	Gas spring block.
Z10-28ST-08157	
G14-28ST-26637	gas spring
G14-28ST-27992	gas spring
G10-23V2-06535	V2A gas spring
T6 15 215 525 px22 px22 00n	gas spring
57742.1	Steel gas spring
G10-23ST-35737	gas spring
G10-23V2-06545	V2A gas spring
G10-23V2-06544	V2A gas spring
G08-19ST-31590 / G 08 19 0120 1 0345 AS30 AS30 00400N	Steel gas spring
G10-23ST-43929	tension spring
G08-19ST-33043	Steel gas spring
G6 15 80 1 260 WG 22 WG 22 50 N	gas spring
G 10 28 0040 1 0210 WG30 WG30 00500N	gas spring
G10-23ST#32377	gas spring
G08-19V2#04386	
P/N:G14-28ST#2514, G 14 28 0100 0 0380 AU27 AB16 01300N	Gas spring
G20-40V4#00440	

Product	Description
G06-15ST#25034	gas spring
Z 10 28 0150 0 0470 WG35 WG35 00250N /5/S	gas spring
G10-28ST#03065	
1223681 4000N / P/N: G20-40ST#07847	gas spring
G 10 23 0200 1 0500 AU19 AB11 01200N	gas spring
G08-19ST#16703	
G14-28ST#32693	
Z10-28STU#00352	
G08-19ST#35895	gas spring
G10-23ST#2991	
790.19.1 / X10-23ST20365#0037	
Z10-28ST#08484	traction cylinder
G08-19V2#01789	gas spring
G06-15ST#22277	Shock absorber
G14-28ST#32805	
G10-23ST#39988	gas spring
G10-23ST#44429	gas spring
G14-28ST-30892	
G10-23ST-44530	
G14-28ST-32951	Gas Piston
Z06-19ST#03063	damper
G10-23ST#35680	
G 06 15 0080 1 0226 GZ07 GA20 00170N (G06-15ST#22255)	
Z10-28ST-08526	Gas Tension Spring
G06-15ST-15378	Gas spring
G10-23ST#44667	
G10-23ST#43884	
Z10-28ST#08535	
D10-28ST#00585	
G10-23ST-44643	
G14-28ST-30717	
G14-28ST-23889 /1427871	
Z 10 28 0350 0 0871 WG35 WG35 00600N /5/6/Si	
G 10 23 0100 1 0330 WG30 WG30 01100N / G10-23ST#36622	
G22-40ST#00893	
G08-19V2-04481	V2A gas spring
G20-40ST#08341	Gas spring
G 10 23 0140 1 0405 GZ10 GZ10 01000N /5	
AG43	
G04-12ST-08146	
288433 / G08-19ST-36679	
G08-19ST-36696.	
ZD10-28ST-00183	

Product	Description
TF06 15 0225 0 0545 PS18 PS18 00000N / PN: TF06-15ST#0082	gas spring
Z10-28V4#00560	Tension Spring
G14-28ST#33491	
G 14 28 0200 1 0500 AK21 AB16 01500N / G14-28ST#22267	
G25-55ST#00180	
G14-28V2#08940	
G08-19ST#25563	
G08-19ST#23336	
G20-40V2-01136	Gas strut
G20-40V2-01137	Gas strut
G14-28ST-17470	
G20-40ST#08437	
G10-23ST-34598	gas spring
189485.2 / G06-15ST-24567	Steel gas spring
D04-12ST-0527	
G14-28ST#28526	gas spring
G04-12ST#06988	spring
G14-28ST#33141	pistons
Z28-40ST#01510	
G10-23ST#45516	Telescopic shock absorber
G10-23ST#36622	pair of pistons
G08-19ST#31212	
G04-12ST#07200	
G20-40ST#06471 G 20 40 0200 1 0620 AG50 AG50 02400N	Gas spring
G 10 23 0100 1 0314 GG32 GG32 01200N	
G14-28V2#06871	
G08-19ST-32106	Steel gas spring
121341.1	Steel gas spring
G20-40ST-07878	Steel gas spring
S10-23ST-02081	
G06-15ST-22925	Gas spring steel
G08-19V2-04601	
G10-23ST-45969	Gas spring steel
G10-23ST-46013	Gas spring steel
G10-23ST-46012	Gas spring steel
ZD10-28ST-00192	
80 94K40-9571	
G 14 28 0200 1 0500 AK21 AB16 01800N / G14-28ST-28215	gas spring
G08-19ST-37601	Gas spring steel
G08-23ST-01904	Gas spring steel
G20-40V4-00468	
3540 17 - G06-15ST-26214	Steel gas spring
G 08 19 0150 0 0400 AU19 AB11 00145N	

Product	Description
294129 / G14-28ST-28526	gas spring
G10-28ST#03354	
G10-28ST#03353	
G08-19ST-37775	Steel gas spring
1122089	piston
1160684	
1133944	piston
1160887	piston
1160885	piston
G14-28ST#22267 - 1500N	
G14-28ST#34407	Gas Strut
G14-28ST#34413	
G08-19ST-34067	Steel gas spring
G06-15ST-26354	
G14-28V2-09225	
Z10-28ST-08815	Tensile gas spring steel
G06-15ST-26370	Steel gas spring
G06-15ST-26379	Steel gas spring
G10-23ST-46480	Gas spring
Z10-40ST-00899	Tensile gas spring steel
G06-15ST-26416	
ZD10-28ST-00198	
G20-40ST-08727	
G 06 15 0150 0 0335 GZ07 GZ07 00145N	gas spring
881.055.013.033	gas spring
H-G10 23 0231 1 0515 GZ10 GZ10 00150N /1/4/5/Si/V4	piston
G20-40ST-08745	Steel gas spring
Z10-28ST-08857	
1124397	
G10-23ST-46779	Steel gas spring
G14-28V4-01434	gas spring
G10-23ST-46803	
G08-19ST-38197	
Z10-28ST-08869	gas spring
S10-28ST-05577	gas spring
S10-28ST-05581	
Z10-28ST-08808	Throttle spring
G14-28ST-34850	damper
G14-28ST-34896	
06-15ST-22255	
TF06-15ST-0110	
D06-19ST-00641	
BA30/K10/002	Fitting

Product	Description
G08-19ST-25329	Gas piston
Z 10 28 0350 0 0870 WG35 WG35 00900N /5/6/Si	Tensile gas spring
14-28V2LA0002	
G20-40-40ST-00691	Steel gas spring
G08-19V2-04726	V2A gas spring
G10-23ST-46834	
G 10 23 0080 1 0302 AG36 AG36 01100N /5/Si/V2	V2A gas spring
G10-23ST-32302	
G10-23V2-05311	
Z10-28ST-07267	
G14-28ST-33021	
192764.2	Spring
G10-23ST-47335	
G08-19ST-38439	
G10-23ST-47421	Steel gas spring
G14-28ST-35184	Steel gas spring
G14-28ST-35220	Gas spring
SDG04-12STL-00002	
SDD06-19STL-00004	
SDD06-15STL-00003	
SDD04-12STL-00007	
1106467 / G08-19ST-34848	Steel gas spring
G10-23V2-07173	V2A gas spring
G 08 19 0200 1 0500 GZ10 GZ10 00250N	Steel gas spring
G 06 15 0150 0 0335 GZ07 GZ07 00145N / G06-15ST-26694	Steel gas spring
G 08 19 0110 1 0318 WG18 WG18 00600N /5	Steel gas spring
G08-19ST-38356	Steel gas spring
G14-28ST-30325	
89023.4 - G 10 23 0200 1 0447 GZ10 GZ10 01000N /5	Steel gas spring
T06-15ST-00309	Steel door retainer
G10-23ST-46635	Steel gas spring
G 14 28 0285 1 0687 AU27 AU27 00800N /5/Si/V2	V2A gas spring
G08-19ST-35425	gas cylinder
G14 28 200 1 500 AK21 AB16 1900N / G14-28ST-28526	gas springs
208190.1 / G10-23ST-46849	gas spring
G14-28V2-06517	gas spring
S10-28ST-05702	
G22-40ST-02158	
G22-40ST-02162	
G06-15ST-27081	
G 06 15 0100 1 0257 WG22 GA20 00063N / G06-15ST-25389	Steel gas spring
G08-19ST-27278	gas spring
G 14 28 0285 1 0687 AU27 AU27 01000N /5/Si/V2	V2A gas spring

Product	Description
TF06-15ST-0082	
G10-23ST-32552	gas spring
28-014SF	
G 14 28 0200 1 0500 AK21 AB16 01800N	Gas pressure spring
28-036YV	
28-021WI	Steel gas spring
1343558 / 28-01W5M	V2A gas spring
419.84 750N / 28-03A4L	Steel gas spring
28-020JP	
28-03A42	Tensile gas spring
G 14 28 0200 1 0500 AK21 AB16 01100N	
28-020QJ	Steel gas spring
28-039WC	
28-036KR	Tensile gas spring
28-00J6V	-
28-00758	GAS SPRING
28-024R4	Pistons
G8 19 250 1 589 AU19 AR16 300N	Steel gas spring
28-029LP	Steel gas spring
28-02JJB	V2A gas spring
28-03AVD	
28-019QQ	Steel gas spring
28-02S5S	
G14 28 0100 1 0330 WG35 WG35 01700N	Steel gas spring
G 14 28 0120 1 0417 WX35 WX35 02500N	Steel gas spring
PN: 28-00A47 / Type: 252783 - 250N	Steel gas spring
28-03BDO	V2A gas spring
G 06 15 0200 1 0471 WG22 GZ07 00150N	Gas spring
28-02UET	Gas Strut
G 08 19 0200 1 0445 GZ10 GZ10 00400N	gas spring
28-039IR	gas strut
28-01U3G	Gas spring
KT1001 1413119 40N	gas spring
28-031LK	Tensile gas spring steel
28-00WJK	gas spring
28-003KS	Gas spring
Z 10 28 0200 0 0496 GZ12 GZ12 00150N /4/5/Si	Gas spring