



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Halstrup Walcher

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

| Product | Description |
|--|-----------------------------------|
| 9003.00.71 | PS 10 pressure sensor |
| 9031.0064 | Pressure transducer PIZ sensor |
| 9302.0239 | Helical gears |
| 9400.0087 | Special transmissions |
| 0775150004E | Differential Pressure Transmitter |
| 9007.0001 | Digital pressure gauges |
| 9001.0044/EMA84-10-5-1-0 | portable digital pressure gauge |
| P26 9612.0030 | Differential pressure transmitter |
| P 26 9612.0164 | differential pressure transmitter |
| P29 Erdgas (Art.nr. 9614.0002) | Differential pressure transducer |
| PS10, 9276/347 (9003.0777) (9003.0778) | pressure sensor |
| PSE312-8-DP-T-0-0-54 | positioning system |
| PSE312-8-DP-0-0 | Positioniersystem |
| PSE 3125-VG 14 DP-0 9435.0025 | Positioniersystem |
| P-14-0...5kPa-05-24D-5-0 | Differential pressure transmitter |
| PUC24 (100 Pa) | Prozessüberwachungsgerät |
| PUC24 (250 Pa) | Prozessüberwachungsgerät |
| PK 11 | Differenzdruckmeßumformer |
| 9071.0818 | Pressure converter |
| 9071.3153 | Druckaufnehmer P92 |
| 9276/659 | Pressure Transducer |
| 9613.0173 | Differential pressure transmitter |
| PSE212-8-CAA-W-1 / 9421.0014 | Positioniersystem |
| 9003.0323 | Drucksensor PS 10 |
| 9071.3029 | differential pressure transmitter |
| 9030 | Druckaufnehmer PI-Sensor |
| 9030.2510 | Druckaufnehmer PI-Sensor |
| 9031.0016 | PIZ sensor pressure transducer |
| 9031.0226 | Druckaufnehmer PIZ-Sensor |
| 9002 | Druckaufnehmer PU-Sensor |
| P 92 (9071.0711) | Differential Pressure Transmitter |
| P 92 | Druckaufnehmer |
| 9031. | Druckaufnehmer PIZ-Sensor |
| 9029. | Elektronisches Barometer BA1000 |
| 9003.0688 | PS 10 pressure sensor |

| Product | Description |
|---|-------------------------------------|
| 9071.1535 | Druckaufnehmer P 92 |
| PSE3125VG-14-CA-0 (9435.0046) | Positioning system |
| PS18 | Differenzdruckmeßumformer |
| 9612.0007 | Differenzdruck-Messumformer P26 |
| 9071.0764 / P 92 | Druckaufnehmer |
| 9071.1281 | Druckaufnehmer P 92 |
| PS11 | Differenzdruckmeßumformer |
| 9506.0006 EC12 | HIPERDRIVE HUB EC12 |
| 9030.1938 | Sensor |
| PSE423DP (9442.0079) | Positioning system |
| 9421.0014 | Positioniersystem PSE212-8-CA-A-W-1 |
| P/N: 9612.0752, Type: P26-4-24ACDC--10...50Pa-2-0-0-0-0 | Differential pressure transmitter |
| 9030.0784 | Differential Pressure Transmitter |
| 9604.0035 | Differenzdruckmeßumformer |
| PSE4210-DP-DO / 9442.0073 | Positioniersystem |
| 9442.0091 | Positioniersystem |
| 9440.0105 | Positioning system PSE40 |
| 9442.0082 | Positioniersystem |
| 9440.0106/PSE405DP | Positioniersystem |
| 9442.0073/PSE4210DP | Positioniersystem |
| PSE328-14-EC-0-0-0-54 (9432.0389) | positioning system |
| PSE325-14-EI-0-0-0 | positioning system |
| PSW305-14-PN-0-0-0 | Differential Pressure Switch |
| HDA70-EI-L-S-S | Hiperdrive |
| PSE325-14-DP-T-M-O | Positioniersystem |
| 9071.2826 | Pressure transducer |
| 9095.0059 | Mobile calibration device |
| 9071.0994 | Differential Pressure Transmitter |
| Typ: PSE231-8-CAO-W-0 | |
| 9612.P26 (0,2%, +0,3Pa) | Differential pressure |
| 9612.P26 (0,5%, +0,3Pa) | Differential pressure |
| 9612.0338.P26 +/-0,2%(+0,3Pa) + LCD | Differential pressure |
| 9612.0338 P26 (0.5%; LCD display) | Differential pressure transmitter |
| PS27-4-AC/DC-0...500Pa-0-0-1-S-0 (9613.0561) | differential pressure transmitter |
| HDA70-PN-L-S-S | engine |
| PSE3210-14-EL-0-0 | Integrated Positioning System |
| 9613.0117 / PS 27 | Differential Pressure Transmitter |
| PS 10 / 9003.0114 | Pressure sensor Delta_P |
| 9071.3062 (P 92) | Differential Pressure Transducer |
| Differenzdruck-Messumformer P26 (9612.0042) | Differential Pressure Transmitter |
| 9601.0002 | Factory calibration certificate |
| PSE232-8/So-CA-O-W-0 14924 (9423.0012) OEM | Positioning system |
| 9421.0014 Type: PSE212-8-C-A-W-1 | Positioner System |

| Product | Description |
|--|--|
| 9030.3069 | |
| 9373.0123 | Getriebe N100/So |
| PSE3410-14- CA-0-M-0 | engine |
| PSE3418-14-EI- 0-0-0 | positioning system |
| PS11 9079.0048 | Differential Pressure |
| PSE 4210DP-DM | Positioning System |
| 9440.0106 (Type: PSE405DP) | Positioning system |
| 9003.0727 | Pressure sensor |
| 9003.0758 | Pressure sensor |
| 9030.2350 | Pressure sensor |
| KAL200-1-2A- 1 (9609.0037) | generator |
| 9601.0003 | Calibration certificate |
| 9079.0038 | Differential pressure transducers |
| 9003.0338 PS 10 | pressure transmitter |
| 9071.2736 KH21 012 | |
| 9431.0119 | |
| PS 10 | Differential pressure transmitter |
| 9327.0013 | reducer |
| 9431.0224 | Positioning system |
| 9003.0338 | PS 10 pressure sensor |
| 9030.0635 | Pressure transducer PI sensor |
| PSE335-14-IO-0-0-0 | Positioning system |
| PSE305-14-IO-0-0-0 | Positioning system |
| PSE423DP-R-M (9442.0092) | Positioning system |
| PSE4325S (9443.0114) OEM | Positioning System |
| 9003.0765 | Pressure sensor |
| PK15 9011.0499 | Differential Pressure Transducer |
| PS10 / 9003.0771 | Pressure sensor |
| PSE332 14-DP-0-M-0 | Positioning system |
| Type P 92 LT (9071.3185) | pressure transducer |
| PSE232-8-CA-O-W-0 | Positioning system |
| PSE332-14-PN-0-M-0-54 | positioning system |
| HDA70-DP-L-B-S | Hiperdrive |
| 9613.0421 | Differential pressure transmitter PS27 |
| 9003.0720 Type PS 10 | Pressure sensor |
| 9612.0012 (P26) | differential pressure transmitter |
| 9462.0058 / PSD428-14H-S-IO-0-65-1-0 | Positioning system |
| 9030.2350 (9030.2350) | pressure reader |
| 9616.0007 (P34) | Differential pressure transmitter |
| P26 (9612.0108) | differential pressure transmitter |
| PSE335-14 (9433.0122) OEM | Positioning system PSE335-14-DP- 0-0-0 |
| 9030.1960 | pressure transducer |
| PSE302-14-PN-0-0-0-54 | Positioning system |

| Product | Description |
|--|---------------------------------------|
| 9505.0007 / HDA70-I-L-H-S | Intelligent Positioning Drive |
| PSE4210-DP-DO | POSITIONER |
| PSE325-14-EI-0-0-0-54 | positioning system |
| PSE3310-14-EI- 0-0-0-54 | positioning system |
| PSE335-14-EI-0-0-0-54 | positioning system |
| PSE3218-14-EI- 0-0-0-54 | positioning system |
| 9434.0132 | positioning system |
| 9612.0303 | Differential pressure transmitter P26 |
| 9434.0133 | positioning system |
| 9434.0101 | positioning system |
| PSE405C | Positioning System |
| PSE335-14-DP-0-0-0-54 | Positioning system |
| 9003.0070 | Pressure sensor PS 10 |
| 9031.0092 | Pressure transducer PIZ sensor |
| Model: P92 | Pressure transducer |
| 9071.0675 | Pressure transducer P 92 |
| 9614.0067 Type P29 | Differential pressure transmitter |
| 9030.3116 | Pressure transducer PI-sensor |
| 9071.1431 | pressure transducer P 92 |
| 9071.3134 | pressure transducer P 92 |
| 9612.0164 | Differential pressure transmitter P26 |
| P/N: 9613.0482 Type: PS27 | differential pressure transmitter |
| P26 / 9612.0469 | Differential pressure transmitter |
| 9612.0469 | Differential pressure transmitter P26 |
| 9435.0043 | Positioning system |
| 9435.0051 | Positioning system |
| 9505.0063 | Intelligent Positioning System |
| P/N: 9003.0702, Type: PS 10 | pressure sensor |
| P/N: 9505.0037, Type: HDA70-EC-L-S-S | Hiperdrive |
| P/N: 9431.0326 Type: PSE312-8-EI-0-0-0-54 | positioning system |
| P/N: 9616.0020 Type: P34 | differential pressure transmitter |
| 9007.0003 / EMA 200-10-0 | Digital pressure gauges |
| P/N: 9613.0522, Type: PS27-4-ZWL-0...100Pa-0-0-0 | Differential Pressure Transmitter |
| 9623.0021 / PS17-4-AC/DC-1-0-0-1-16 | Differential pressure transmitter |
| PS 10 / 9003.0323 | pressure sensor |
| 9276/721 | general purposes transmitters |
| HDA70-EI-L-S-S-HF / 9505.0033 | Intelligent Positioning System |
| PSE305-8-EC-0-0-0-54 / 9430.0608 | positioning system |
| 9030.3148 | differential pressure transmitter |
| 9612.0815 / P26-4-24ACDC-0...5kPa-S-0-0-0-0 | differential pressure transmitter |
| 9612.0816 / P26-4-24ACDC-0...2,5kPa-S-0-0-0-0 | differential pressure transmitter |
| PSE312-14-DP-0-0-0-54 / 9431.0214 | positioning system |
| 9433.0119 | Positioniersystem |

| Product | Description |
|---|---------------------------------------|
| PS27-4-AC/DC-0-5kPa-0-1-1 | differential pressure transmitter |
| PSE312-8-EC-0-0-N-54 | positioning system |
| PSE322-14-SE-0-0-0-54 / 9432.0432 | positioning system |
| 9612.0164 (+/- 50 Pa) | differential pressure transmitter |
| 9623.0260 / PS17-4-VDC-4-0-0-025-16-0 | Pressure transducer |
| PSE312-8-PN-0-0-0-54 | positioning system |
| 9612.0709 | differential pressure transmitter |
| 9031.0612 | Differential pressure transmitter |
| 9613.0588 | differential pressure transmitter |
| 9612.0995 | differential pressure transmitter |
| 9002.2631 | differential pressure transmitter |
| PSE3210-14-EI-0-M-0-54 | positioning system |
| 9030.3190 | differential pressure transmitter |
| 9612.0126 | P26 differential pressure transmitter |
| 9002.0310 | pressure transducer |
| 9002.2045 | PU sensor pressure sensor |
| 9002.0458 | PU sensor pressure sensor |
| 9030.3204 | Differential pressure transmitter |
| 9030.3017 | pressure sensor |
| PI-4-+/-250Pa-02-24D-0-0-I (9030.2010) | pressure sensor |
| 9613.0521 | Differential pressure transmitter |
| 9030.1752 | PI-Sensor pressure sensor |
| 9612.1078 / P26-1-24ACDC-0...250Pa-S-LC-0-0-S-I | Differential pressure transmitter |
| 9613.0526 | Differential pressure transmitter |
| 9030.3216 | Differential pressure transmitter |
| 9612.1126 (+/- 250 Pa) | Differential pressure transmitter |
| 9625.0014 | pressure calibrator |
| PSE302-14-PN-0-0-N-54 (9430.0659) | positioning system |
| PS27 (9613.0135) | Differential pressure transmitter |
| 9003.0781 | Differential pressure transmitter |
| PSE312-8/So-DP-0-0-0-54 | positioning system |
| PSE312-8-DP-0-0-0-54 | positioning system |
| KE43093 | Differential Pressure Transmitter |
| 9623.0057 | Differential pressure transmitter |
| 9613.0222 | Differential pressure transmitter |
| 9002.2595 | Differential pressure transmitter |
| PSE328-14-DP-0-M-0-54 | positioning system |
| 9623.0250 / PS17-4-AC/DC-+/-1mbar-0-0-1-16-0 | Differential pressure transmitters |
| 9612.1252 / P26-1-230/115-0...10Pa-2-LC-0-0-S-0 | Differential pressure transmitter |
| PSE305-14-DP-0-0-0-54 | positioning system |
| LA 125 / 9390.0001 | linear actuator |
| 9030.2926 | pressure transducer |
| PSW335-14-DP-0-0-0-68 | Positioning System |

| Product | Description |
|---|---|
| 9612.1288 | differential pressure transmitter |
| 9616.0389 | Differential pressure transmitter |
| 9030.0043 | differential pressure transmitter |
| 9002.2678 | Differential Pressure Transmitter |
| 9612.0612 | Differential Pressure Transmitter |
| 9031.0336 | PIZ sensor pressure transducer |
| PSE302-8-CA-0-0-0-54 | positioning system |
| 9614.0068 | Natural gas differential pressure transmitter |
| 9030.3246 | differential pressure transmitter |
| 9030.3212 | differential pressure transmitter |
| 9030.3174 | differential pressure transmitter |
| PSE305-14-PN-0-0-N-54 | positioning system |
| 9462.0061 | Positioning System |
| 9460.0043 | Positioning System |
| 9430.0545 | positioning system |
| 9433.0305 | positioning system |
| 9434.0122/PSE3418-14-EI-0-0-0-65 | positioning system |
| 9030.0035 | differential pressure transmitter |
| 9433.0129 - PSE335-14-DP-0-M-0-54 | positioning system |
| 9612.1381 | differential pressure transmitter |
| 9002.2389 | PU sensor pressure transducer |
| 9461.0033 / PSD411-5V-S-IO-0-50-1-0 | positioning system |
| 9002.1998 | PU sensor pressure transducer |
| PSD422-8V-S-PN-0-50-1-0 | positioning system |
| 9612.1106 | differential pressure transmitter |
| 9433.0109 / PSE332-14-DP-0-M-0-54 | positioning system |
| PSE335-14-PN-0-0-0-54 / 9433.0291 | positioning system |
| 9612.1439 | Differential Pressure Transmitter |
| 9612.0003 | P26 differential pressure transmitter |
| 9505.0042 | positioning system |
| PI-4-+/-1mbar-1-230-10-0-0 / 9030.3204 | differential pressure transmitter |
| old code PSE3410-14- CA-0-M-0/ new code PSE3410-14- CA-0-M-0-65 | Integrated Positioning System |
| PSD422-8V-S-PN-0-65-1-0 // 9462.0094 | positioning system |
| 9432.0357 / PSE328-14-PN-0-M-0-54 | positioning system |
| 9420.0036 | PSE200/5-C-4U positioning system |
| KAL 84-1-1-230-D / 9095.0339 | Netzun. Pressure calibrator |
| 9030.2010 23080001 | pressure transducers |
| 9030.2010 AK091093 | pressure transducers |
| 9613.0477 | differential pressure transmitter |
| KAL200-0A-A-1-D | Pressure calibrator |
| 9612.0915 | differential pressure transmitter |
| PSE3210-14-DP-0-0-0-54 | Integrated positioning system for automatic format changeover in machines |

| Product | Description |
|--|-----------------------------------|
| 9030.3143 | Differential pressure transmitter |
| PSD401-5V-S-IO-0-50-P-0 | Positioniersystem |
| 9030.2950 | PI sensor pressure transducer |
| PSE325-14-DP-0-M-0-54 | positioning system |
| PSD401-5V-S-CA-0-65-1-0 | Servo Drive |
| P34-4-10...50mbar-5-0-A-W3-l | differential pressure transmitter |
| 9030.2878 | PI sensor pressure transducer |
| 9002.0087 | Pressure transducer |
| PU-0-100Pa-1-24A-0-0-0 / PN: 9002.2721 | Pressure transducer |
| 9508.0045 | Bus cable |
| 9508.0050 | Connector set |
| 9508.0043 | Power supply cable |
| 9612.0632 | Pressure Transmitter |
| factory calibration certificate | factory calibration certificate |
| 9613.0376 | differential pressure transmitter |
| 9612.0585 | differential pressure transducer |
| 9432.0203 / Type: PSE3210-14-DP-0-0-0-54 | positioning system |
| PSE305-14-PN-0-0-0-54 | |
| 9002.263 / PU-0...10mbar-1-230-0-0-0 | differential pressure transmitter |
| PN: 9462.0100 / Type: PSD428-14H-S-PN-0-50-1-0 | positioning system |
| KAL84-1-2-1 | Pressure Calibrator |