



ENAPART



93 S Railroad Avenue Unit C
Bergenfield NJ 07621 USA
www.enapart.com
sales@enapart.com



Via del Canneto 35,
Borgosatollo, Brescia - Italia
www.enapart.it
vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu
My Newwork No:3/15 Ataşehir / İstanbul
www.enapart.net
satis@enapart.net



PRIVADA 10 B SUR #3908 COL.
ANZUREZ, C.P. 72530, PUEBLA, PUE
www.enapart.com.mx
sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325
Frankfurt am Main, Germany
www.enapart.de
anfrage@enapart.de



4 boulevard Carnot, 95400
villiers-le-bel, Paris, France
www.enapart.fr
sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3
www.enapart.com.ua
sales@enapart.com.ua



MUNICIPIUL BUCUREȘTI, SECTOR 3,
B-DUL BASARABIA, NR.250, CORP P+5
www.enapart.ro
sales@enapart.ro



〒584-0023 大阪府富田林市若松町
東2丁目2番16号
www.enapart.co.jp
sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS
NIEVES 12 ,LOCAL ,50012,ZARAGOZA
www.enapart.es
ventas@enapart.es



Складова база „Онгъл“, Склад А2, п.к.
4006, гр. Пловдив, България
www.enapart.bg
sales@enapart.bg



3 Austin Mews, High Street, Hemel
Hempstead, HP1 3AF , United Kingdom
www.enapart.co.uk
sales@enapart.co.uk

Kissling

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
06-63-420	impact switch
07.2.2.17 933	Toggle Switch
00678722	Toggle switch
08-1-1-14	Toggle Switch
08-1-1-15 A	Toggle Switch
08-1-1-17 E	toggle switch
08-2-1-20	Toggle switch
24.34.02.902	Not-Aus-Schalter
26.02.14	Power Relay
26.56.78	relays
26-70-04	Power Relay
29.311.12.912	relays
29.311.11	relays
29-311-12	Relay
29.313.12.927 / K1060688	
30.313.11.921 OEM	relay
30.313.12	Relay
30.313.12.EC01 , 01120618	Relay
30.314.12.905	relays
54.808.101 R 53	boundary switch
65.F16.701D.DU M	
68.V16.108D1 L-14.XBGP.4	
PS1 101 301 911	SWITCH
DW 025 (300.800.063)	
G13.01.1206	Limit Switches
G 13.01.1230	Schalter
L-12 XBGP.4	sensor
MND1 023 165	Microswitch MND1 023 125
PR8 031 302 901	Micro switch
MZW1 741 150 / K1040869	Microswitch
PB1-011-304	(Microswitch)
MODEL PB1 311 302	LIMIT SWITCH
PB1 351 301	MICROSWITCH
PS1 011 204	switch
PS1 941 301	microswitch

Product	Description
PS 181 310	Microswitch
24.34.03	SAFETY SWITCH
54.808.912-M	
MZW1 191 050	microswitch
PS1 081 207 Mikroschalter	Mikroschalter
07.4.1.15 B 901	toggle switch
G13-01-1160	Bordertastert
54.808.101 K	Limit switch
54-808-702 D-939-M - K1050471	Row limit sensor
K1001369	microswitch
26.56.75.911 OEM	relay
PB1 181 310	
2979900134	Power Relay
29.211.12 A, 2979900	
Relais 29.311.12.952	Relay
29-311-12-956	Relay
54810-101 K 60-M	POSITION SWITCH
26.57.72	Power Relay
65.F16.101 K-M	Grenztaster
PB1 011 304 905	Mikroschalter
65.F16.701 R 72 906-M / K1124890	limit switches
26.50.00	dual coil relay
26.08.08	
GWU-K15-M	Limit Switch
35.521.100 R	Battery Disconnecter
08.4.1.13 Type:K1002956	Toggle Switch 08-4-1-13
08-0-0-01	Sicherheitsklappe
L-14.XBGP.4	ELEKTRONIK-SCHALTEINSÄTZE
29-311-12-915	Relay
26-56-08	relays
29-511-12	Industrial Relay
29.011.12	
29.111.12	Relais
26.05.61 (01013887)	
30.314.12	
29.321.11	Relay
PS1 351 301	relay
GWN2K13-B	Grenztaster
ESC-603 3E-n	
26.56.38.906	relay
65 B 12.105D-M	Switch
MPRKV-S01-02	MICROSWITCH
MND1 033 095	micro switch

Product	Description
01123577	
MZT1.361.209.904	Micro Switch
MN81 061 204	contactor
26.56.07.905	Relais
26.56.38.912	relays
01153799	Relais
26-70-04-900	Relais
L-19 0984 2	Electronic switch insert
29-313-12	relay
65.B12.708 R 965 (02015976)	DIN-REIHENGRENZTASTER
65.B16.108 R M (01051183)	DIN-REIHENGRENZTASTER
65.08 R 16 (02015317)	AUSTAUSCHBLÖCKE
48U120Z040	
26.71.01	Power Relay
MZX1 361 309 904	Microswitches
35-524-220-S	Batterietrennschalter
26.56.32	relay
07-2-2-17	Toggle Switch
ES-2012-T111	Emergency Stop Switch
30.313.11	bi-stable relay
30.314.12(20 pcs.)	Relais
08.1.1.17E 950	
08-2-1-14	toggle switch
08.2.1.16M	
30.313.12.901	Relay
54.810.01 K 60-M	
07.1.2.17.934	
07.1.2.10 934	switch
30.314.12(50 pcs.)	Bistable relays
L-02.XLMP.2 old PN, new PN L-02.XBBP.2	
L-02.XBBP.2	Electronic switching insert
PB1 031 304	Microswitch
PS1 081 306	Switch
PB1 011 302	MIKROSCHALTER
G13.01.1183	ENDSCHALTER
26.60.75	Relay
PB 101 308	
Cod. 26.72.21	relay
Cod. 26.28.28	
29.211.02	
29.221.12	Relay
07.1.2.16.934	
26.56.38.912, 01132047	

Product	Description
35.200.014	lever
PS1 011 204 905	MICROSWITCH
DS-211-BL2 913	rotary switch
L-10.ULGP-4	ELECTRONIC SWITCH INSERT
PS8 031 202	
MZX1 301 304 981	microswitche
65.F16.101 R-M	limit switch
9-311-04B	Relay
35-521-100-S-A2	
L408.2116.25	Switch, Electronic switch opener 10 m cable
24.34.02.A	Safety Switch
PS1 351 302	MICROSWITCHES
30.313.12 / K1006083	Relay
65.F16.701 K72-M	Limit switch
L497.XLFP.4 KM3.5	Electronic limit switch
DW045	Switch
PB1 101 302	
PS1 081 301	pressure switch
MND1 023 125	Microswitch
26.08.78 (01013578)	Series 26 Relay
65.F16.101 D 45-M	Limit switch
AL171877 oem	toggle/rocker switch
MND1 141 200	
MND1 021 150	microswitch
29-111-12A / Type: 29-111-12A	Relais
29.211.12A 200A	
MND1 021 250	
08.0.0.03	
26.08.28	relay
MND1 142 050 923	Microswitch
Batterietrennschalter 35.210.041 S 902	
29.311.12.935	Relais
K1129539	Bi-Stable Relay
54.808.103 K 935	Series limit switches
ESC 603-3E-M	Limit switch
29-314-12-900	Relay
85.220.S.270	relay
MZX1 361 309 904 (ETL-Nr.: 2979900)	ETL-Nr.: 2979900
26.05.21	Relay
MZT1 361 209	MICRO SWITCH
68.V16.110 D1 L-14.XBGP.4	Elektr.-RGT
G 13.01.1120	LIMIT SWITCH
31.311.11 i	Relais

Product	Description
ES-2003-T111	Emergency stop switch
54.810.101 K 923-M	Switch
08.2.1.15 A	toggle switch
01168892 / MZX1 361 309 904	microswitch
54.808.101 D (2979900001)	
MZX1 021 304	Mikroschalter
29.331.12.908	Relay
DS-211-GN2	Rotary switch
DW 025 , 2979900012	.
TS-213-RT12 040	Push button
TS-213-GN12 040	Push button
ES-3003-T311-025	
01156082	Symbolic foil ES
PB1 651 301 904	
MZD1 021 304	Micro Switch
DW 025	PRESSURE SWITCH
26.55.72.906	Relay
26.72.01.900	Relay
29.011.12.913	Relay
PS 011 304 #K1122716	Switch
08.4.1.13G	toggle
26.56.33	Relay
26.60.05	Relais
30.313.02.907	Relay Bi-stable
26.55.75	Relay
29.311.11AB	
ECV 600-1-300-M	Limit switch
65.05 R12	Exchange block
8-2-1-13 D 933	Toggle switch
54.808.702 D 936-M	switch
29.411.12	Relay
PS1 031 304 , 2979900058	MICROSWITCH
MZX1 021 305	Micro switch
PS1 361 309	micro switch
MZW1 793 100 900	microswitch
5930-12-176-3873	Toggle Switch
G13-01-1161	Limit switch
54.810.101 K-M	
26.60.04	Relay (100A)
28.311.99 900	relay
26.08.07	relay
26.08.01	Relais
MZX1 021 105	Micro Switch

Product	Description
MZT1 023 305	Micro Switch
29.315.12.932	relay
PB1 021 302	MICROSWITCH
35.524.100 R	Battery breaker
G13.01.1094	Limit Switches
G13.01.1555	Limit switch
44.03.003	Button switch
RGT 54.808.702 D-936-M	
08.2.2.13	Toggle Switch
65.F16.101 D	Limit switch
07.2.2.17 902	toggle
31.313.12.S	relay
EBC 602-9 E-904-M	Limit switch
PS1 121 302 909	Microswitch
PB1 081 302	Microswitch
PN8 031 211 914	Microswitch
26.60.01	relay
29.013.12.906	relays
30.313.12.EC01	Relays with electronics
35.411.100R	battery cut-off switch
07.2.1.13.920	toggle
30.314.12.913	relays
08-1-1-13	Toggle Switch
MZX1 021 302	Microswitch
35-202	battery circuit breaker
35.224.001 R 900	Batt. -Sitter switch
26.70.04 (qty. 6 pcs)	
26.70.04 (qty. 25 pcs)	
07.2.3.99 900	vividly
DS-111-BL2 913	
29.511.11 A	
MZW1 122 088 913	Microswitch
85.121.X.1200	
G13-01-1809	Limit switch
MZX1 361 306 961	Microswitch
LD08.XLBP.2-30	PU Inductive Proximity Switch
29.212.12	Relay
ESC 600-1E-M	SWITCH
PB1 351 302	MICROSWITCH
DW 040	
29.311.12A	Relay
L430.XLGP.15	proximity switch
08-2-1-13	Toggle Switch

Product	Description
08-1-1-17	Toggle Switch
PS1 081 203	Microswitch
26.73.24	relay
PJ1-081-203	
26.06.01	relays
08.4.1.27	
08.0.0.02	
TS-211-GN 32	
TS-211-RT 62	
MND1 021 300	
MZW1 741 150 902 (K1040936)	
29.111.12A	relay
29.021.12	relay
07.1.2.17 934 #K1014077	TOGGLE SWITCH
08-80-016 #K1121621	rubber grommets
57.B12.203 D - 905 - M	
60.311.12	Relay (HVR)
07.1.2.15.934	Toggle switch
54.810.101 R	Limit pushbutton
29.331.12	
MZT1 361 305	SWITCH
00711319	
35.413.141.R	Power switch
PS8 031 307	
26.56.52	angled connection
31-311-12-S-P-A	Relay
26-05-01	Relay
L-10.ULGP4 (K1002698)	ELECTRONIC SWITCHING INSERT
PS1 181 310	MICROSWITCH
31-311-11-S	Power relay
08-4-1-13 D	Toggle switch
09.1.1.10	Toggle switch
5945-12-401-0644	RELAY
29.211.12	Relay
PB1 081 301 926	switch
PB1 121 302	switch
PN7 031 211	switch
EBC 602 - 9 E-M	switch
G13-01-1812	Limit switch
26.05.71	relay
08.2.1.17	switch
EBC 602 - 9 E-M #K1050574	switch
EBC 602 - 9 E-M (ETL-Nr.: 2979900)	switch

Product	Description
LA12.2120.4	switch
26.02.14 (K1009319)	Relay
26.06.03	relay
26.08.21	Relay
26.06.56	relay
LD08-XLBP-2-30 PU	switch
07.1.3.17.934	toggle switch
07.2.2.15.935	toggle switch
MZD1 321 056 908	microswitch
30.314.12.913 / K1060691	relays
LA08.XLBP.1 30LAPU	
30.313.11 EC10-907	relay
54.808.101 D	Limit switch
PS1 031 305	microswitch
PS1 361 301	microswitch
24.34.02 /K1008489	Emergency Power Switch
07-2-2-13	Toggle Switch
29.331.12.933	relay
24.01.00.904 #K1070300	Push Button Switch
30.313.11 #K1008000	Power relay
29.011.12.918	Power relay
08-2-1-13 D	toggle switch
26.56.06 Type:K1008805	
65.B16.102 D DU-M	Series limit switch
08.2.1.15 A940	
08.2.1.11	
08.2.1.17E	
MZX1 021 302 961	microswitch
29.311.01	Relay
MZX1 021 309 904	microswitch
26.56.03.904	relays
MZX1 023 408 974	
44-02-024 904	Plunger Switch
35.521.140.R	Batt. separating. switch
07.4.1.23 E 901	Gear Switch
29.511.02	Relais
26-55-710	relays
29.114.12	Relay
35-524-231-R-901	Battery Disconnecter
35-524-231-S-900	Battery Disconnecter
08-1-1-13 D	Toggle Switch
EBC 602-9E-905-M	SWITCH
LD 090.110.12VI	sealing rings

Product	Description
26-57-01	Power Relay
26.08.50	extinguishing diodes
26.55.21.903	relays
Type 29-511-12	power relay
35-513-101-R	Battery Disconnecter
7-2-3-25 909	toggle switch
26.56.22	relay
26.56.238	relays
08.1.2.17.933	
08.1.2.13.F.932	SWITCH
24-63-029	Protection Cap
29.321.11.913	
29.312.12	
26.57.710	
35.210.041.S #K1151411	battery disconnecter
MZT1 361 302 904	
29.014.12.919	Relay
29.411.12A / K1149129	relays
24-11-00	Emergency Drive Switch
30-311-12 / K1060041	
MZX1 021202904	microswitch
26.06.11 / K1013796	Relay
35-411-151-R (K1143304)	Battery Disconnecter
08-2-1-15 E	Toggle Switch
30-314-12-908	Relay
G13-01-1190	Limit switch
29-013-12	relay
35-225-120-R (K1153136)	Battery Disconnecter
07-1-2-13	Toggle Switch
29-212-12-A-946	
24-34-02	Emergency Power Switch
G13-01-1365	Limit switch
31-311-12-S (K1136757)	relay
L408-2118-25	proximity switch
29-012-12-905	
MZX1 361 309 030 (K1042182)	Mikro Switch
EBC 111-1E-M	Limit switch
ECS 26-05-93	Relay
35-314-131-R-900	rotary switch
MZW1 121 088 918	Micro Switch
26.08.78	Relay
08.2.1.20 901	Toggle Switch
PS1 021 208	switch

Product	Description
ESC 600-1E-M (K1050655)	Limit switch
L408.2115.25	Ind.Prox.-Switch
44-01-062	Plunger limit switch
EBC 600-1E-901-M, pn K1050570	Limit Switch
K1012918	
07-1-2-73 903 (K1134313)	Switch
PS1 132 310 903	wicket
31.311.12.i.936	relay
ES-2002-T121	
EBC 600-1E-901-M	
35-313-141-R-A50-900	Disconnecter
07.2.2.10 920	toggle
543 034 947	MIKRO SWITCH MND1 SERIES
ADR / GGVS 87-3-3000	Battery electric switch
PB8 031 307	Micro switch
29.313.12.927	
08-0-0-04	Switch guard
08-2-1-20 A	toggle switch
26-72-02-900	Relay
26-72-01	Relay
MZX1 021 306 961	Snap Action Switch
54.808.101 R	Limit switch
MND1 543 034 947	
29.511.12.906	relay
29.511.12A	Relay
26-05-63	Relay
TS-111-GN52	Tactile switch
26.70.04.907	
35-413-160-R	DISCONNECTOR
29-311-04B	Relay
29.311.12.934	Relay
29.114.11.927	relay
30.211.12	Relay
PB1 081302 (D7261)	
7-1-2-13 933	Toggle Switch
31.311.11.E.933	
K1022996	
MND1 041 300 / PN K1014772	
29-212-12A	
35-524-241-R	Battery Disconnecter
PS1 181 301	MICROSWITCH
08-4-1-13 F	Toggle Switch
08-2-1-20 P	Toggle Switch

Product	Description
08-4-1-26 A	Toggle Switch
29.511.12 / K1060259	Relay
TS-221-GN11 917	
PS1 031 304 / 2979901377	Micro Switch
TS-211-RT42	Push button switch TS-211-RT42
29.312.12A	relay
TS-211-BL32	
TS-211-GN62	
29.213.12	Relais
08-2-1-13 D 933	toggle switch
K1050574/ 2979901129	Limit switch
29.315.12.918	Relay
29121 12	
Type MZW1 121 088 918	Microswitch
Type 24-01-00	Emergency Mainswitch 1000 A
07-3-3-99 916	
DS-211-GE1 913	rotary switch
MZW1 081 050	Switche
MZW1 123 150	Micro Switch
26-56-02	Relay
MZT1 361 309	
26.56.01	power relay
k1013399	
01128635	
ESV 500-903-M	Limit switch
PS1 041 301	contactor
35-525-160-R / K1148183	Battery Disconnecter
G13.01.1133	Limit switch
MZX1 301 305	Micro Switch
31.4500.0001	double sheet lock switch
26-58-39	Relay
K1133449	
29-111-12 / Type: 29-111-12	Relais
26.70.07.900	
TS-211-GN11 917	Push button switch
08-1-1-10	toggle switch
08-2-1-23	toggle switch
07.4.1.23 A	toggle Switch
MZD1 321 200 900	Micro Switch
9-315-12-918 / K1060329	
26-05-93-902 DD	Intelligent Power Relay
SW STANDAR 08-80-016	Gear shift knob
29-014-12	Relay

Product	Description
Relais 26-56-75-911 / EL-7125-NA	
K1130783	RELAY 29-211-11A
Relay-ETD 26-05-83-0-010	
TS-211-BL12	BYPASS BUTON#GHFAST2P#260672