







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Micro Detectors / Diell

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
AE1/AP-1F	Standard d.c. 3 wires inductive proximity sensor
AE1/AP-2A	Inductive sensor
AE1/CP-3A	
AES/AP-1F	
<u>AK1/AP-2H</u>	Inductive sensor
<u>AM1/AP-1H</u>	Inductive Sensor
<u>BV4/00-0E</u>	Cubic photoelectric sensor
<u>BV6/00-0E</u>	Photoelectric sensor
BX10SR/0A-HB6A	
BX10SR/0A-HB6A79	
<u>BX80A/1P-1A</u>	Sensor
<u>BX80S/10-1A</u>	Area sensor
FAI7/BP-0E	sensor
FALD/BP-1E	Photoelectric sensor
FALH/X0-1E	Photoelectric sensor
<u>H8E/1</u>	
<u>H8R/1</u>	Photoelectric sensor
<u>MS2/00-0A</u>	Diffuse sensor
<u>MS6/00-0A</u>	Lichttaster M.D.
<u>MSC/00-0E</u>	Photoelectric sensor Retroreflective
PD1/AN-1A	Inductive Proximity Sensor
<u>SB300</u>	module
SBCR03/S-AM	Control Unit
SSG/AP-0E	Photoelectric sensor
<u>SSU/00-0E</u>	Photoelectric sensor
<u>SP2/0P-0E</u>	
FARL/BP-0E	Sensor
AES/AN-1F	
SSG/AP-1H	Receiver
PMS/OP-1H	Induktiver Sensor
QMRG/0P-0F OEM	
<u>MP0/00-0E</u>	Photoelectric sensor
FAIC/BP-1EDA	Photoelectric sensor
<u>RX8/0T-3B37</u>	Photoelectric sensor
SSC/DP-1E	

Enapart Group





Product	Description
FARS/BP-1E	Photoelectric sensor
A413BX80A1P1	Detector
SS0/LP-1E	
39000011410	Sensor
A413BX80100H	
<u></u>	Emitt.
SH2/R-1K	Receiver
	Receiver
<u></u>	Emitt.
<u></u>	sensor receiver
<u>SH2/E-1H</u>	sensor
<u>CD12M/0B-050A1</u>	Cable and Plug
BX80S/10-0H	
<u>BX80S/10-1H6X</u>	Area sensor
<u>BX80B/1P-1H6X</u>	Area sensor
<u>320000000111 (SH2/E-0E)</u>	
<u>MS2/00-0E</u>	Photoelectric sensor
<u>SSC/LN-0A</u>	
<u>BX80A/1P-1H</u>	Light curtain receiver
<u>BX80A/1P-0H</u>	area sensor
<u>CF/CB1-20</u>	FIBRE TAGL.SCANNER
<u>Q50ID/0T-0A</u>	Photoelectric sensor
Q50IH/0T-0A	Photoelectric sensor
RX8/0T-1B37	Photoelectric sensor
<u>SSP/LP-1E</u>	Retro-Reflective photoelectric sensor
PK3/00-1H	
FQI7/BP-0E	
<u>LS2ER/30-090</u>	
<u>CD12M/0H-050A3</u>	
AM1/AP-2H3W	
AM1/AP-1H4W	Inductive sensor
<u>FAIC/BP-0E</u>	Photoelectric sensor
SS2/LP-0E	
<u>AE6/AN-1A</u>	
AE1/CN-1A	
AE6/CN-1A	Inductive sensor
AE1/AP-1A	Inductive sensor
AE6/AP-1A	Inductive sensor
<u>AE1/CP-1A</u>	Inductive sensor
AE6/CP-1A	sensor
<u>AE6/AN-2A</u>	
AE1/CN-2A	
AE6/CN-2A	
AEU/UN-ZA	





Product	Description
AE6/AP-2A	
AE1/CP-2A	
AE6/CP-2A	Inductive sensor
AE1/AN-3A	Inductive sensor
AE6/AN-3A	
AE1/CN-3A	
AE6/CN-3A	
<u>AE1/AP-3A</u>	Inductive sensor
SS2/LN-0A	Photoelectric sensor
AE6/CP-3A	
AE1/AN-4A	
AE6/AN-4A	
AE1/CN-4A	
AE6/CN-4A	
AE1/AP-4A	
<u>AE6/AP-4A</u>	
AE1/CP-4A	
<u>AE6/CP-4A</u>	
AE1/AN-1F	
AE6/AN-1F	
AE1/CN-1F	
AE6/CN-1F	
AE6/AP-1F	
AE6/CP-1F	
<u>AE1/AN-2F</u>	Inductive sensor
AE6/AN-2F	
AE1/CN-2F	
AE6/CN-2F	Inductive Proximity Switches
<u>AE1/AP-2F</u>	Inductive Proximity Switches
AE6/AP-2F	
AE1/CP-2F	Inductive Proximity Switches
AE6/CP-2F	Inductive Proximity Switches
AE1/AN-3E	
AE6/AN-3E	Inductive Proximity Switches
AE1/CN-3F	
AE6/CN-3F	Inductive Proximity Switches
AE1/AP-3F	Inductive sensor
AE6/AP-3F	Inductive Proximity Switch
AE1/CP-3F	
AE6/CP-3F	Inductive Proximity Switches
AE1/AN-4F	
AE6/AN-4F	Inductive Proximity Switches
<u>AE1/CN-4F</u>	





Product	Description
AE6/CN-4F	Inductive Proximity Switches
AE1/AP-4F	Inductive sensor
AE6/AP-4F	Inductive Proximity Switches
AE1/CP-4F	Inductive Proximity Switches
AE6/CP-4F	Inductive Proximity Switches
AE1/CN-1H	·
AE1/CP-1H	Inductive Proximity Switches
AE1/AN-2H	Inductive Proximity Switches
AE1/CN-2H	Inductive Proximity Switches
AE1/AP-2H	Inductive Proximity Switches
AE1/CP-2H	Inductive Proximity Switches
AE1/AN-3H	Inductive Proximity Switches
AE1/CN-3H	Inductive Proximity Switches
AE1/CP-3H	
AE1/AN-4H	Inductive Proximity Switches
AE1/AP-4H	
<u>HEE/00-3A</u>	M8 miniaturized through-beam sensors DC
HER/AP-3A	M8 miniaturized through-beam sensors DC
HER/CP-3A	M8 miniaturized through-beam sensors DC
HER/AN-3A	
HER/CN-3A	M8 miniaturized through-beam sensors DC
<u>HEE/00-4A</u>	M8 miniaturized through-beam sensors DC
HER/AP-4A	M8 miniaturized through-beam sensors DC
HER/CP-4A	M8 miniaturized through-beam sensors DC
HER/AN-4A	
HER/CN-4A	M8 miniaturized through-beam sensors DC
<u>HEE/00-3F</u>	M8 miniaturized through-beam sensors DC
HER/AP-3F	M8 miniaturized through-beam sensors DC
HER/CP-3F	M8 miniaturized through-beam sensors DC
HER/AN-3F	
HER/CN-3F	M8 miniaturized through-beam sensors DC
<u>HEE/00-4F</u>	M8 miniaturized through-beam sensors DC
HER/AP-4F	M8 miniaturized through-beam sensors DC
HER/CP-4F	M8 miniaturized through-beam sensors DC
HER/AN-4F	M8 miniaturized through-beam sensors DC
HER/CN-4F	M8 miniaturized through-beam sensors DC
DME/00-1A25	M12 cylindrical photoelectric sensors
DME/X0-1A25	M12 cylindrical photoelectric sensors
DMP/0N-1A25	M12 cylindrical photoelectric sensors
DMP/0P-1A25	M12 cylindrical photoelectric sensors
DME/00-1H25	M12 cylindrical photoelectric sensors
DME/X0-1H25	M12 cylindrical photoelectric sensors
DMP/0N-1H25	M12 cylindrical photoelectric sensors





Product	Description
DMP/0P-1H25	Photoelectric sensor
DME/00-1A	
DME/X0-1A	M12 cylindrical photoelectric sensors
<u>DM2/0N-1A</u>	M12 cylindrical photoelectric sensors
DM3/0N-1A	M12 cylindrical photoelectric sensors
<u>DM7/0N-1A</u>	M12 cylindrical photoelectric sensors
DMP/0N-1A	M12 cylindrical photoelectric sensors
DMR/0N-1A	M12 cylindrical photoelectric sensors
DM2/0P-1A	M12 cylindrical photoelectric sensors
DM3/0P-1A	
DM7/0P-1A	M12 cylindrical photoelectric sensors
DMP/0P-1A	Photoelectric sensor
DMR/0P-1A	
DME/00-1H	Photoelectric sensor
DME/X0-1H	
<u>DM3/0N-1H</u>	
<u>DM7/0N-1H</u>	M12 cylindrical photoelectric sensors
DMP/0N-1H	
DMR/0N-1H	
<u>DM3/0P-1H</u>	
<u>DM7/0P-1H</u>	Photoelectric sensor
<u>DMP/0P-1H</u>	
<u>DMR/0P-1H</u>	Photoelectric sensor
SBCR03/S-A0	
<u>AM1/AP-2A</u>	Inductive proximity sensor
<u>BV2/00-0E</u>	
<u>DM2/0N-1H</u>	M12 cylindrical photoelectric sensors
FARN/BP-1E	Photoelectric sensor
<u>UT1B/E2-0EUL</u>	Ultrasonic Sensor
UT1B/EP-0EUL	Ultrasonic Sensor
UT1B/EN-0EUL	Ultrasonic Sensor
UT1B/EW-0EUL	Ultrasonic Sensor
UT1B/EM-0EUL	Ultrasonic Sensor
UT1B/E5-0EUL	
UT1B/E6-0EUL	
UT1B/E4-0EUL	Ultrasonic Sensor
UT1B/E7-0EUL	Ultrasonic sensor
UT1B/E9-0EUL	
UT1B/E1-0AUL	Ultrasonic Sensor
UT1B/E2-0AUL	Ultrasonic Sensor
UT1B/EP-0AUL	
UT1B/EN-0AUL	
UT1B/EW-0AUL	





Product	Description
UT1B/EM-0AUL	
UT1B/E6-0AUL	
UT1B/E4-0AUL	Ultrasonic Sensor
UT1B/E7-0AUL	Ultrasonic Sensor
 UT1B/E9-0AUL	Ultrasonic Sensor
<u>AF/ER7</u>	Termin.S/R fibra core 1 mm 90° 800 mm
AK1/AN-1A	Inductive sensor M18 shielded NO/NPN cable 2m axial
AK1/AP-1A	Inductive sensor M18 shielded NO/PNP cable 2m axial
AK1/AP-2A	sensor
AK1/AP-3A	
AM1/AN-1A	Inductive sensor M12 shielded NO/NPN cable 2m axial
AM1/AN-1H	
AM1/AN-2A	Inductive sensor
AM1/AN-2H	
AM1/AN-3H	
AM1/AP-2C	
AM1/AP-4A	
AM1/CP-2A	
UT2F/E6-0EUL	
AM6/AP-2A	
AM6/AP-4A	
<u>AM6/AP-4H</u>	sensor
<u>PM3/00-1H</u>	
<u>PM3/00-2A</u>	
<u>AT1/AP-1A</u>	
BX10SR/0A-HB	Area sensor Kit
BX10SR/0A-HB6X	
CD08/0A-050A1	Connector
<u>CD08/0A-050C1</u>	Connector M8 90° CEI 2022 II 3 poles cable 5 m
<u>CD08/0A-100A1</u>	
<u>CD08/0B-050A1</u>	
CD08/0B-050C1	Connector
<u>CD08/0B-100A1</u>	
<u>CD12M/0B-020A1</u>	
<u>CD12M/0B-020C1</u>	
AM1/CP-2H	Inductive sensor
<u>CD12M/0B-100A1</u>	
CD12M/0B-100C1	
<u>CD12M/0B-150A1</u>	
CD12M/0B-150C1	
<u>CD12M/AA-050A1</u>	
<u>CD12M/AA-050C1</u>	
<u>CD12M/AA-070C1</u>	Connector





Product	Description
CD12M/AA-100A1	
CD12M/AA-100C1	
CD12M/AA-150C1	
<u>CL12/0B-00A</u>	
	Inductive sensor
<u>CV12/0B-00A</u>	Connector
CV12/0B-00B	
CF/RB6-10	
 CF/RBA-10	
FAI7/BN-0A	Photoelectric sensor
FAI7/BN-0E	sensor
FAI7/BN-1E	Photoelectric sensor
CD12M/0B-050C1	Connector Female
<u>FAI7/BP-1E</u>	
FAI8/BP-0E	Photoelectric sensor
FAIC/BN-0A	
FAIC/BN-0E	
FAIC/BP-0A	
FAIC/BP-2E	
FAID/BP-0E	
FAIM/BP-0E	
FAIZ/BN-0E	
FALN/BP-0E	Photoelectric sensor
FAR2/BN-0A	
FAR2/BN-0E	Photoelectric sensor
FAR2/BP-0A	
FAR2/BP-1E	Photoelectric sensor
FARP/BP-0E	Photoelectric sensor
FARS/BP-0E	Photoelectric sensor
FC7I/0P-M304-0F	
FGRW/0P-0E	
<u>MSC/00-0A</u>	Photoelectric sensor
<u>MSE/00-0E</u>	
<u>MSP/00-0E</u>	Photoelectric sensor
<u>MV2/A0-0A</u>	Photoelectric sensor Diffuse 100 mm plast. cable 2m axial
<u>PKS/0P-1H</u>	Inductive sensor M18 shielded PNP conn. M12
<u>PMS/0N-2H</u>	Inductive sensor M12 unshielded NPN conn. M12
<u>PMS/0P-1H</u>	Inductive sensor M12 shielded PNP conn. M12
FAIZ/BP-0E	Photoelectric sensor
QMIS/0P-0F	Photoelectric sensor
QMR7/0P-0F	Photoelectric sensor





Product	Description
<u>QMR8/0P-0F</u>	Photoelectric sensor
QMRG/0N-0A	Photoelectric sensor
QMRG/0N-0F	
QMRG/0P-0A	
QMRHD/0P-0F	
QMRL/0P-0F	Photoelectric sensor
QMRN/0P-0F	Retro-reflective photoelectric sensor
QMRS/0N-0F	·
QMRS/0P-0A	Photoelectric sensor
<u>STQMO</u>	
<u>STQMS</u>	
PMS/0P-2H	Inductive sensor
<u>RX6/0T-3B</u>	Photoelectric sensor
<u>RX8/00-3B</u>	Photoelectric sensor
<u>RX8/0T-3B</u>	Photoelectric sensor
<u>RXC/00-3A</u>	Photoelectric sensor
RXC/0T-3B	Photoelectric sensor
<u>RXL/0T-3B</u>	Photoelectric sensor
SAT/0P-0C	Photoelectric sensor
SSF/0P-0E	Optical Fibre Amplifier
SH4/E-0EIA	
SH4/E-1EIA	Safety sensor
<u>SH4/E-1KIA</u>	
SH4/R-0EIA	Safety sensor
SH4/R-1EIA	Safety sensor
<u>SH4/R-1KIA</u>	
<u>RL 106G</u>	Retroreflective
<u>SS7/0P-0E</u>	
<u>RL 110</u>	
<u>RL 111G</u>	
<u>RL 113G</u>	
<u>RL 116</u>	
<u>RX6/00-3B</u>	
<u>RX8/00-1A</u>	Photoelectric sensor
<u>RXC/00-3B</u>	Photoelectric sensor
<u>STF-12</u>	Photoelectric sensor Focalizz. 12 mm for SST
<u>STF-25</u>	
<u>STF-50</u>	Photoelectric sensor Focaliser 50 mm for SAT
<u>TH6/E-KIA</u>	
<u>TH6/R-KIA</u>	
UK1A/E1-0EUL	
UK1A/E5-0EUL	Ultrasonic sensor
UK1A/EP-0EUL	Ultrasonic sensor





Product	Description
<u>ST 03</u>	
<u>ST 101</u>	
<u>ST 102</u>	
UK1D/E1-0EUL	
<u></u>	
UK1D/E2-0EUL	
ST 18-A	
<u>ST 18-C</u>	
<u>ST 86</u>	
UK6A/H1-0EUL	
<u>VK2/A0-1B</u>	
<u>VK2/A0-2B</u>	
<u>VK2/C0-2B</u>	
<u>VM2/A0-2B</u>	Inductive sensor M12 unshielded NO cable 2m
<u>AE1/AN-1A86</u>	
AE1/AN-1A8F	
AE1/AN-1A8Q	
<u>AE1/AN-2A86</u>	
<u>AE1/AN-4A86</u>	
<u>AE1/AP-1A84</u>	
<u>AE1/AP-1A86</u>	
<u>AE1/AP-1A8F84</u>	
AE1/AP-1AAN	
AE1/AP-1FAN	
AE1/AP-1FDP	Inductive sensor
AE1/AP-1FE5	Inductive sensor
AE1/AP-1HAN	Inductive sensor
<u>AE1/AP-2A84</u>	Inductive sensor
<u>AE1/AP-2A86</u>	Inductive sensor
AE1/AP-3A4W	Inductive sensor
<u>AE1/AP-3A84</u>	Inductive sensor
AE1/AP-3A86AN	Inductive sensor
<u>AE1/AP-4A86</u>	Inductive sensor
AE1/AP-4AAN	Inductive sensor
<u>AE1/AP-4FAN</u>	Inductive sensor
<u>AE1/CN-1A84</u>	Inductive sensor
<u>AE1/CP-1A84</u>	Inductive sensor
AE1/CP-1A8R	Inductive sensor
AE1/CP-2A8R	Inductive sensor
AE1/CP-3FAN	Inductive sensor
<u>AE6/AN-1A82</u>	Inductive sensor
<u>AE6/AN-1A85</u>	Inductive sensor
AE6/AN-1A8Q	Inductive sensor





Product	Description
AE6/AP-1A848QV5	Inductive sensor
AE6/AP-1AAN	Inductive sensor
AE6/AP-1AVFAK	Inductive sensor
AE6/AP-1F4W	Inductive sensor
<u>AE6/AP-2F4W</u>	Inductive sensor
AE6/AP-2FAN	Inductive sensor
AE6/AP-3A84	Inductive sensor
AE6/AP-3A86	Inductive sensor
AE6/AP-3AAN	Inductive sensor
AE6/AP-3F4W	Inductive sensor
AE6/AP-3FAN	Inductive sensor
AE6/CN-3A86	Inductive sensor
AF/ER2	Access,Opt.fibre
AF/ER3	PLASTIC OPTICAL FIBRES
AF/ER4	Access,Opt.fibre,Focaliser AF/1F,E+R
AF/ER5	Access,Opt.fibre,Focaliser AF/1F,E+R
AF/ER9	Access,Opt.fibre,Focal. CF/RB3,E+R,90°
<u>AH1/AN-1A</u>	Inductive sensors
<u>AH1/AN-1F</u>	Inductive sensor
<u>AH1/AN-1H</u>	CYLINDRICAL INDUCTIVE SENSORS
<u>AH1/AN-2A</u>	Inductive sensor
AH1/AN-2E	Inductive sensor
<u>AH1/AN-2H</u>	CYLINDRICAL INDUCTIVE SENSORS
AH1/AN-3A	Inductive sensor
AH1/AN-3F	Inductive sensor
<u>AH1/AN-4A</u>	Inductive sensor
<u>AH1/AN-4F</u>	Inductive sensor
<u>AH1/AP-1A</u>	Inductive sensor
AH1/AP-1F	Inductive sensor
<u>AH1/AP-1H</u>	Inductive sensor
<u>AH1/AP-2A</u>	Inductive sensor
AH1/AP-2F	Inductive sensor
<u>AH1/AP-2H</u>	Inductive sensor
<u>AH1/AP-3A</u>	Inductive sensor
AH1/AP-3F	Inductive sensor
AH1/AP-3FAN	Inductive sensor
<u>AH1/AP-4A</u>	Inductive sensor
<u>AH1/AP-4F</u>	Inductive sensor
<u>AH1/CN-1A</u>	Inductive sensor
<u>AH1/CN-1F</u>	Inductive sensor
<u>AH1/CN-1H</u>	Inductive sensor D6,5 mm shielded NC/NPN plug M12
<u>AH1/CN-2A</u>	Inductive sensor
AH1/CN-2F	Inductive sensor

3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom RADWARD LTD United Kingdom Kingdom

Diell





AH1/CN-2HInductive sensorAH1/CN-3AInductive sensorAH1/CN-3EInductive sensorAH1/CN-4AInductive sensorAH1/CN-4EInductive sensorAH1/CP-1AInductive sensorAH1/CP-1FInductive sensorAH1/CP-1HInductive sensorAH1/CP-2AInductive sensorAH1/CP-2FInductive sensorAH1/CP-2BInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensor	
AH1/CN-3EInductive sensorAH1/CN-4AInductive sensorAH1/CP-4EInductive sensorAH1/CP-1AInductive sensorAH1/CP-1FInductive sensorAH1/CP-1HInductive sensorAH1/CP-2AInductive sensorAH1/CP-2EInductive sensorAH1/CP-3AInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensor	
AH1/CN-4AInductive sensorAH1/CP-4EInductive sensorAH1/CP-1AInductive sensorAH1/CP-1FInductive sensorAH1/CP-1HInductive sensoAH1/CP-2AInductive sensorAH1/CP-2FInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-4AInductive sensorAH1/CP-4AInductive sensorAH1/CP-4AInductive sensorAH1/CP-4EInductive sensor	
AH1/CP-4EInductive sensorAH1/CP-1AInductive sensorAH1/CP-1EInductive sensorAH1/CP-1HInductive sensorAH1/CP-2AInductive sensorAH1/CP-2EInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-4AInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensorAH1/CP-4EInductive sensor	
AH1/CP-1AInductive sensorAH1/CP-1EInductive sensorAH1/CP-1HInductive sensoAH1/CP-2AInductive sensorAH1/CP-2EInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH1/CP-4FInductive sensor	
AH1/CP-1FInductive sensorAH1/CP-1HInductive sensoAH1/CP-2AInductive sensorAH1/CP-2FInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH1/CP-4FInductive sensor	
AH1/CP-1HInductive sensoAH1/CP-2AInductive sensorAH1/CP-2EInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH1/CP-4FInductive sensor	
AH1/CP-2AInductive sensorAH1/CP-2FInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH1/CP-4FInductive sensorAH6/AN-1AInductive sensor	
AH1/CP-2FInductive sensorAH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH6/AN-1AInductive sensor	
AH1/CP-2HInductive sensorAH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH6/AN-1AInductive sensor	
AH1/CP-3AInductive sensorAH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH6/AN-1AInductive sensor	
AH1/CP-3FInductive sensorAH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH6/AN-1AInductive sensor	
AH1/CP-3FANInductive sensorAH1/CP-4AInductive sensorAH1/CP-4FInductive sensorAH6/AN-1AInductive sensor	
AH1/CP-4A Inductive sensor AH1/CP-4F Inductive sensor AH6/AN-1A Inductive sensor	
AH1/CP-4F Inductive sensor AH6/AN-1A Inductive sensor	
AH6/AN-1A Inductive sensor	
AH6/AN-1F Inductive sensor	
AH6/AN-2A Inductive sensor	
AH6/AN-2F Inductive sensor	
AH6/AN-3F Inductive sensor	
AH6/AN-4A Inductive sensor	
AH6/AN-4F Inductive sensor	
AH6/AP-1A Inductive sensor	
AH6/AP-1A86 Inductive sensor	
AH6/AP-1F Inductive sensor	
AH6/AP-2A Inductive sensor	
AH6/AP-2AAN Inductive sensor	
AH6/AP-2F Inductive sensor	
AH6/AP-3A Inductive sensor	
AH6/AP-3AAN Inductive sensor	
AH6/AP-3F Inductive sensor	
AH6/AP-4A Inductive sensor	
AH6/AP-4F Inductive sensor	
AH6/CP-1A Inductive sensor	
AH6/CP-1A86 Inductive sensor	
AH6/CP-4A Inductive sensor	
AH6/CP-4F Inductive sensor	
AK1/A0-1A Inductive sensor	
AK1/A0-1A86 Inductive sensor	
AK1/A0-1ANL Inductive sensor	
AK1/A0-1H Inductive sensor	
AK1/A0-2A Inductive sensor	





Product	Description
<u>AK1/A0-2A86</u>	Inductive sensor
AK1/A0-2AAN	Inductive sensor
<u>AK1/A0-2H</u>	Inductive sensor
<u>AK1/A0-3A</u>	Inductive sensor
<u>AK1/A0-3H</u>	Inductive sensor
<u>AK1/A0-4A</u>	Inductive sensor
<u>AK1/A0-4H</u>	Inductive sensor
AK1/AN-1H	Inductive sensor
<u>AK1/AN-1H4W</u>	Inductive sensor
<u>AK1/AN-2A</u>	Inductive sensor
<u>AK1/AN-2A86</u>	Inductive sensor
<u>AK1/AN-2A8R</u>	Inductive sensor M18 unshielded NO/NPN cable 10m axial
AK1/AN-2AAN	Inductive sensor
AK1/AN-2H	Inductive sensor
<u>AK1/AN-3A</u>	Inductive sensor
<u>AK1/AN-3A8T</u>	Inductive sensor
<u>AK1/AN-3H</u>	Inductive sensor
<u>AK1/AN-4A</u>	Inductive sensor
<u>AK1/AN-4A86</u>	Inductive sensor
<u>AK1/AN-4A8R</u>	Inductive sensor
<u>AK1/AN-4H</u>	Inductive sensor
<u>AK1/AP-1A84</u>	Inductive sensor
<u>AK1/AP-1A86</u>	Inductive sensor
<u>AK1/AP-1A8R</u>	Inductive sensor
<u>AK1/AP-1H4W</u>	Inductive sensor
<u>AK1/AP-2A86</u>	Inductive sensor
AK1/AP-2AAN	Inductive sensor
<u>AK1/AP-2H4W</u>	Inductive sensor
AK1/AP-2HAN	Inductive sensor
<u>AK1/AP-3A86</u>	Inductive sensor
<u>AK1/AP-3A8R</u>	Inductive sensor
<u>AK1/AP-3A8T</u>	Inductive sensor
<u>AK1/AP-3A8W</u>	Inductive sensor
AK1/AP-3AAN	Inductive sensor
AK1/AP-3AETNL	
AK1/AP-3AFGNL	Inductive sensor
AK1/AP-3HAN	Inductive sensor
<u>AK1/AP-4A</u>	Inductive sensor
<u>AK1/BP-3H</u>	Inductive sensor M18 shielded NO+NC/PNP conn. M12
AK1/BP-3HAN	Inductive sensor
<u>AK1/BP-4H</u>	Inductive sensor M18 unshielded NO+NC/PNP conn. M12
<u>AK1/CN-1A</u>	Inductive sensor M18 shielded NC/NPN cable 2m axial
<u>AK1/CN-1H</u>	Inductive sensor





Product	Description
AK1/CN-2A	Inductive sensor
AK1/CN-2H	Inductive sensor M18 unshielded NC/NPN conn. M12
AK1/CN-3A	Inductive sensor M18 shielded NC/NPN cable 5m axial
<u>AK1/CN-3A86</u>	Inductive sensor
AK1/CN-3H	Inductive sensor
<u>AK1/CN-4A</u>	Inductive sensor
AK1/CN-4H	Inductive sensor
AK1/CP-1A	Inductive sensor
<u>AK1/CP-1A86</u>	Inductive sensor
AK1/CP-1A8R	Inductive sensor
AK1/CP-1H	Inductive sensor
<u>AK1/CP-2A</u>	Inductive sensor
AK1/CP-2A8R	Inductive sensor
AK1/CP-2H	Inductive sensor
<u>AK1/CP-3A</u>	Inductive sensor
AK1/CP-3H	Inductive sensor
<u>AK1/CP-4A</u>	Inductive sensor
AK1/CP-4H	Inductive sensor
AK6/AN-3A	Inductive sensor
AK6/AN-3H	Inductive sensor
<u>AK6/AP-1A</u>	Inductive sensor
<u>AK6/AP-1H</u>	Inductive sensor
<u>AK6/AP-2A</u>	Inductive sensor
<u>AK6/AP-2H</u>	Inductive sensor
AK6/AP-3A	Inductive sensor
AK6/AP-3H	Inductive sensor
<u>AK6/AP-4A</u>	Inductive sensor
<u>AK6/AP-4H</u>	Inductive sensor
<u>AK6/BN-1A</u>	Inductive sensor
<u>AK6/BN-1H</u>	Inductive sensor
<u>AK6/BN-2A</u>	Inductive sensor
<u>AK6/BN-2H</u>	Inductive sensor
AK6/BN-3A	Inductive sensor
AK6/BN-3H	Inductive sensor
AK6/BN-4A	Inductive sensor
AK6/BN-4H	Inductive sensor
<u>AK6/BP-1A</u>	Inductive sensor
<u>AK6/BP-1H</u>	Inductive sensor
<u>AK6/BP-2A</u>	Inductive sensor
<u>AK6/BP-2H</u>	Inductive sensor
AK6/BP-3A	Inductive sensor
<u>AK6/BP-3H</u>	Inductive sensor
AK6/BP-4A	Inductive sensor





Product	Description
<u>AK6/BP-4H</u>	Inductive sensor
<u>PK3/00-1A</u>	Inductive sensor
PK3/00-1A86	Inductive sensor
PK3/00-1A8R	Inductive sensor
<u>PK3/00-2A</u>	Inductive sensor
PK3/00-2A86	Inductive sensor
<u>PK3/00-2H</u>	Inductive sensor
<u>AM1/0B-3A</u>	Inductive sensor
<u>AM1/0B-4A</u>	Inductive sensor
<u>AM1/A0-1A</u>	Inductive sensor
<u>AM1/A0-1H</u>	Inductive sensor
<u>AM1/A0-2A</u>	Inductive sensor
<u>AM1/A0-2H</u>	Inductive sensor
<u>AM1/A0-3A</u>	Inductive sensor
<u>AM1/A0-3H</u>	Inductive sensor
<u>AM1/A0-4A</u>	Inductive sensor M12 unshielded NO cable 2m axial
<u>AM1/A0-4H</u>	Inductive sensor
<u>AM1/AN-1A4W</u>	Inductive sensor
<u>AM1/AN-1A86</u>	Inductive sensor
AM1/AN-1C	Inductive sensor
<u>AM1/AN-2A86</u>	Inductive sensor
AM1/AN-2C	Inductive sensor
<u>AM1/AN-2C86</u>	Inductive sensor
<u>AM1/AN-3A</u>	Inductive sensor
<u>AM1/AN-3A4W</u>	Inductive sensor
<u>AM1/AN-3A86</u>	Inductive sensor
<u>AM1/AN-4A</u>	Inductive sensor
<u>AM1/AN-4A2Q</u>	Inductive sensor
<u>AM1/AN-4A4W</u>	Inductive sensor
AM1/AN-4H	Inductive sensor
<u>AM1/AP-1A84</u>	Inductive sensor
<u>AM1/AP-1A85</u>	Inductive sensor
<u>AM1/AP-1A86</u>	Inductive sensor
<u>AM1/AP-1A864W</u>	Inductive sensor
<u>AM1/AP-1A8T</u>	Inductive sensor
AM1/AP-1AVE80	Inductive sensor
<u>AM1/AP-1C</u>	Inductive sensor
AM1/AP-1HAN	Inductive sensor
<u>AM1/AP-2A86</u>	Inductive sensor
AM1/AP-2A8R	Inductive sensor
<u>AM1/AP-2A8W</u>	Inductive sensor
AM1/AP-2AAN	Inductive sensor
AM1/AP-2CVE80	Inductive sensor





Product	Description
AM1/AP-2CVEAK	Inductive sensor
AM1/AP-2H4W	Inductive sensor
AM1/AP-2HAN	Inductive sensor
AM1/AP-3A84	Inductive sensor
AM1/AP-3A86	Inductive sensor
AM1/AP-3A868F	Inductive sensor
AM1/AP-3A86AN	Inductive sensor
AM1/AP-3A8R	Inductive sensor
AM1/AP-3AAN	Inductive sensor
AM1/AP-3AET	
AM1/AP-3ANL	Inductive sensor
AM1/AP-3H7F	Inductive sensor
AM1/AP-4A2Q	Inductive sensor
AM1/AP-4A8R	Inductive sensor
AM1/CN-1A	Inductive sensor
<u>AM1/CN-1C</u>	Inductive sensor
AM1/CN-1H	Inductive sensor
<u>AM1/CN-2A</u>	Inductive sensor
<u>AM1/CN-2C</u>	Inductive sensor
<u>AM1/CN-2H</u>	Inductive sensor
AM1/CN-3A	Inductive sensor
AM1/CN-3H	Inductive sensor
<u>AM1/CN-4A</u>	Inductive sensor
AM1/CN-4A2Q	
<u>AM1/CN-4H</u>	Inductive sensor
<u>AM1/CP-1A</u>	Inductive sensor
<u>AM1/CP-1C</u>	Inductive sensor
AM1/CP-1H	Inductive sensor
AM1/CP-1HAN	Inductive sensor
<u>AM1/CP-2C</u>	Inductive sensor
AM1/CP-3A	Inductive sensor
<u>AM1/CP-4A</u>	Inductive sensor M12 unshielded NC/PNP cable 2m axial
<u>AM1/CP-4H</u>	Inductive sensor
<u>AM6/AN-1A</u>	Inductive sensor
AM6/AN-1C	Inductive sensor
<u>AM6/AN-1H</u>	Inductive sensor
<u>AM6/AN-2A</u>	Inductive sensor
<u>AM6/AN-2A86</u>	Inductive sensor
<u>AM6/AN-2C</u>	Inductive sensor
<u>AM6/AN-2C86</u>	Inductive sensor
<u>AM6/AN-3A</u>	Inductive sensor
<u>AM6/AN-3A87AN</u>	Inductive sensor
AM6/AN-3H	Inductive sensor





Product	Description
AM6/AN-4A	Inductive sensor
AM6/AN-4H	Inductive sensor
<u>AM6/AP-1A86</u>	Inductive sensor
AM6/AP-1AAN	Inductive sensor
AM6/AP-1C	Inductive sensor
AM6/AP-1C86	Inductive sensor
AM6/AP-1HAN	Inductive sensor
<u>AM6/AP-2A86</u>	Inductive sensor
<u>AM6/AP-2C</u>	Inductive sensor
AM6/AP-2C86	Inductive sensor
AM6/AP-2HAN	Inductive sensor
<u>AM6/AP-3A86</u>	Inductive sensor
AM6/AP-3AAN	Inductive sensor
AM6/AP-3C8F	Inductive sensor
AM6/AP-3HAN	Inductive sensor
AM6/AP-4HAN	Inductive sensor
AM6/CN-1A	Inductive sensor
AM6/CN-1C	Inductive sensor
AM6/CN-1H	Inductive sensor
AM6/CN-2A	Inductive sensor
AM6/CN-2C	Inductive sensor
AM6/CN-2H	Inductive sensor
AM6/CN-3A	Inductive sensor
<u>AM6/CN-3A86</u>	Inductive sensor
AM6/CN-3H	Inductive sensor
AM6/CN-4A	Inductive sensor
AM6/CN-4H	Inductive sensor
AM6/CP-1A	Inductive sensor
AM6/CP-1C	Inductive sensor
AM6/CP-1CVE80	Inductive sensor
AM6/CP-1H	Inductive sensor
AM6/CP-2A	
AM6/CP-2C	Inductive sensor
AM6/CP-2H	Inductive sensor
AM6/CP-3A	Inductive sensor
AM6/CP-3H	Inductive sensor
AM6/CP-4A	Inductive sensor
AM6/CP-4H	Inductive sensor
AM6/CP-4HAN	Inductive sensor
AM9/AN-3H	Inductive sensor
<u>AM9/AP-3H</u>	Inductive sensor
<u>PM3/00-1A</u>	Inductive sensor
<u>AT1/0P-1H</u>	Inductive sensor





Product	Description
<u>AT1/0P-2H</u>	Inductive sensor
<u>AT1/0P-3H</u>	Inductive sensor
<u>AT1/0P-4H</u>	Inductive sensor
<u>AT1/A0-1A</u>	Inductive sensor
<u>AT1/A0-1H</u>	Inductive sensor
<u>AT1/A0-2A</u>	Inductive sensor
<u>AT1/A0-2H</u>	Inductive sensor
<u>AT1/A0-3A</u>	Inductive sensor
<u>AT1/A0-3H</u>	Inductive sensor
<u>AT1/A0-4A</u>	Inductive sensor
<u>AT1/A0-4H</u>	Inductive sensor
AT1/AN-1A	Inductive sensor
<u>AT1/AN-1B</u>	Inductive sensor
AT1/AN-1H	Inductive sensor
<u>AT1/AN-2A</u>	Inductive sensor
AT1/AN-2B	Inductive sensor
AT1/AN-2H	Inductive sensor
AT1/AN-3A	Inductive sensor
AT1/AN-3AVE80	Inductive sensor
AT1/AN-3H	Inductive sensor
<u>AT1/AN-4A</u>	Inductive sensor
<u>AT1/AN-4H</u>	Inductive sensor
<u>AT1/AP-1B</u>	Inductive sensor
<u>AT1/AP-1B86</u>	Inductive sensor
<u>AT1/AP-2A</u>	Inductive sensor
<u>AT1/AP-2A86</u>	Inductive sensor
<u>AT1/AP-2A8R</u>	Inductive sensor
<u>AT1/AP-2B</u>	Inductive sensor
<u>AT1/AP-2B86</u>	Inductive sensor
<u>AT1/AP-2H</u>	Inductive sensor
<u>AT1/AP-3A</u>	Inductive sensor
<u>AT1/AP-3A86</u>	Inductive sensor
AT1/AP-3A8R	Inductive sensor M30 shielded NO/PNP cable 10m axial
<u>AT1/AP-3H</u>	Inductive sensor
AT1/AP-3HAN	Inductive sensor
<u>AT1/AP-4A</u>	Inductive sensor
<u>AT1/AP-4H</u>	Inductive sensor
AT1/AP-4HAN	Inductive sensor
AT1/CN-1A	Inductive sensor
AT1/CN-1B	Inductive sensor
AT1/CN-1H	Inductive sensor
AT1/CN-2A	Inductive sensor
<u>AT1/CN-2B</u>	Inductive sensor

Diell





Product	Description
AT1/CN-2H	Inductive sensor
AT1/CN-3A	Inductive sensor
AT1/CN-3H	Inductive sensor
AT1/CN-4A	Inductive sensor
AT1/CN-4H	Inductive sensor
AT1/CP-1A	Inductive sensor
AT1/CP-1B	Inductive sensor
AT1/CP-1H	Inductive sensor
<u>AT1/CP-2A</u>	Inductive sensor
<u>AT1/CP-2B</u>	Inductive sensor
<u>AT1/CP-2H</u>	Inductive sensor
AT1/CP-3A	Inductive sensor
AT1/CP-4A	Inductive sensor
AT1/CP-4H	Inductive sensor
AT6/AN-1A	Inductive sensor
AT6/AN-1H	Inductive sensor
<u>AT6/AN-2A</u>	Inductive sensor
AT6/AN-2H	Inductive sensor
AT6/AN-3A	Inductive sensor
AT6/AN-3H	Inductive sensor
AT6/AN-4A	Inductive sensor
AT6/AN-4H	Inductive sensor
<u>AT6/AP-1A</u>	Inductive sensor
AT6/AP-1H	Inductive sensor
<u>AT6/AP-2A</u>	Inductive sensor
AT6/AP-2H	Inductive sensor
AT6/AP-3A	Inductive sensor
<u>AT6/AP-3H</u>	Inductive sensor
<u>AT6/AP-4A</u>	Inductive sensor
<u>AT6/AP-4H</u>	Inductive sensor
AT6/BN-1A	Inductive sensor
<u>AT6/BN-1H</u>	Inductive sensor
AT6/BN-2A	Inductive sensor
AT6/BN-2H	Inductive sensor
<u>AT6/BN-3A</u>	Inductive sensor
AT6/BN-3H	Inductive sensor
<u>AT6/BN-4A</u>	Inductive sensor
<u>AT6/BN-4H</u>	Inductive sensor
<u>AT6/BP-1A</u>	
<u>AT6/BP-1H</u>	Inductive sensor
<u>AT6/BP-2A</u>	Inductive sensor
<u>AT6/BP-2H</u>	Inductive sensor
<u>AT6/BP-3A</u>	Inductive sensor





Product	Description
AT6/BP-3H	Inductive sensor
AT6/BP-4A	Inductive sensor
AT6/BP-4H	Inductive sensor
NX14SR/XAN-A010	Area sensor Kit
NX14SR/XAP-A000	Area sensor Kit
NX14SR/XAP-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX14SR/XCN-AT10	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX14SR/XCN-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX14SR/XCN-CT10	Area sensor Kit
NX16SR/XAN-C000	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAN-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAN-CT10	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAN-CT1020	Area sensor Kit
NX16SR/XAP-A010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XAP-C010	Area sensor
NX16SR/XAP-C01020	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-A010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-AT10	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-AT1020	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-C010	MEDIUM RESOLUTION AREA SENSORS WITHOUT HOUSING
NX16SR/XCN-CT10	Area sensor Kit
<u>BS2/00-0C</u>	Photoelectric sensor Diffuse 100 mm cable 2m 90°
<u>BS2/00-0E</u>	CUBIC PHOTOELECTRIC SENSORS DECOUT
<u>BS4/00-0C</u>	Photoelectric sensor
<u>BS4/00-0E</u>	Photoelectric sensor
<u>BS6/00-0C86</u>	Photoelectric sensor
<u>BS8/00-0C</u>	Photoelectric sensor
<u>BS8/00-0C86</u>	Photoelectric sensor
<u>BS8/00-0E</u>	
<u>BSC/00-0C</u>	Photoelectric sensor
<u>BSC/00-0C86</u>	Photoelectric sensor
<u>BSC/00-0E</u>	Photoelectric sensor
<u>BV2/00-0C</u>	Photoelectric sensor
<u>BVC/00-0C</u>	Photoelectric sensor
<u>BVC/00-0E</u>	Photoelectric sensor
BX04R/AD-HB	MEDIUM RESOLUTION AREA SENSORS
<u>BX04S/00-HB</u>	MEDIUM RESOLUTION AREA SENSORS
BX04SR/0A-HB	MEDIUM RESOLUTION AREA SENSORS
BX04SR/0A-HB79	Area sensor Kit
BX10R/AD-HB2D	Area sensor receiver
BX10R/AD-HB70	Area sensor Receiver
BX10R/CD-ABVE80	Area sensor Receiver
BX10R/CD-ABVE806A	Area sensor Receiver





Product	Description
BX10R/CD-HB	Area sensor Receiver
BX10R/CD-HB6X	Area sensor Receiver
BX10S/00-ABVE80	Area sensor Emitter
BX10S/00-ABVE806A	Area sensor Emitter
BX10S/00-HB6X	Area sensor Emitter
BX10S/00-HB70	Area sensor Emitter
BX10S/X0-HB	Area sensor Emitter
BX10SR/0A-AB	Area sensor Kit
BX10SR/0A-ABAT	Area sensor Kit
BX10SR/0A-HB6XLS	Area sensor Kit
BX10SR/0A-HB6XSY	Area sensor Kit
BX10SR/0A-HB74	complete emitter+receiver kit
BX10SR/0A-HB79	Area sensor Kit
BX10SR/0A-HBAN	Area sensor Kit
BX10SR/0A-HBLS	Area sensor Kit
BX10SR/0A-HBLSAN	Area sensor Kit 10 beams adj. P+N DO conn. M12 A
BX10SR/0C-HB	Area sensor Kit
BX10SR/0C-HB6A	Area sensor Kit
BX10SR/0C-HB6XLS	Area sensor Kit
BX10SR/XA-HB	Area sensor Kit
<u>BX80A/1N-0H</u>	Area sensor Receiver
BX80A/1P-0H2D	Area sensor Receiver
<u>BX80A/1P-0HAN</u>	Area sensor Receiver
<u>BX80A/1P-1A86</u>	Area sensor Receiv
BX80A/1P-1HDA	Area sensor Receiver
<u>BX80A/1P-2H</u>	Area sensor Receiver
<u>BX80A/2N-0H</u>	Area sensor Receiver
BX80A/2P-0H	Area sensor Receiver 1,5m 10ms PNP NO/NC conn.
<u>BX80A/2P-2H</u>	Area sensor Receiver
<u>BX80A/3P-0H</u>	Area sensor Receiver
<u>BX80A/3P-1A</u>	Area sensor Receiver
<u>BX80A/3P-1H</u>	Area sensor Receiver
<u>BX80A/3P-2H</u>	Area sensor Receiver
<u>BX80A/4P-0H</u>	Area sensor Receiver
<u>BX80A/4P-0H2D</u>	Area sensor Receiver
<u>BX80A/4P-1H</u>	Area sensor Receiver
<u>BX80A/4P-2H</u>	Area sensor Receiver
<u>BX80A/5P-0H</u>	Area photoelectric sensors, Receiver
<u>BX80A/5P-2H</u>	Area sensor Receiver
<u>BX80B/1P-0H</u>	Area sensor
BX80B/1P-0H6XLS	Area sensor Receiver
<u>BX80B/1P-1H</u>	Area sensor
<u>BX80B/2P-0H</u>	Area sensor





Product	Description
BX80B/3P-0H	Area sensor Receiver crossed beam 1m 3ms PNP NO/NC conn.
<u>BX80B/4P-0H</u>	Area sensor Receiver
BX80E/20-0H	Area sensor Emitter
BX80S/10-0H6XLS	Area sensor Emitter
BX80S/10-0H9K	Sensor
BX80S/10-0HAN	Area sensor
BX80S/10-1A86	Area sensor
BX80S/10-1HDA	Area sensor
BX80S/10-1HDA74	Area sensor
<u>BX80S/10-2H</u>	Area sensor
<u>BX80S/20-0H</u>	Area sensor Emitt. adj. 1,5m 10ms connettore
<u>BX80S/20-2H</u>	Area sensor
<u>BX80S/30-0H</u>	Area sensor Emitter
<u>BX80S/30-1H</u>	Area sensor Emitter
<u>BX80S/30-2H</u>	Area sensor Emitter
<u>BX80S/40-0H</u>	Area sensor Emitter
<u>BX80S/40-1H</u>	Area sensor Emitter
<u>BX80S/40-2H</u>	Area sensor Emitter
<u>BX80S/50-2H</u>	Area sensor Emitter
CX0E1RP/05-016V	Area sensor Intrinsic optical
CX0E1RP/10-016V	
CX0E1RP/10-032V	Area sensor
CX2E0RA/05-016V	Area sensor
CX2E0RA/05-032V	Area sensor
CX2E0RA/05-048V	Area sensor
CX2E0RA/05-048VTB	Area sensor
CX2E0RA/10-016V	Area sensor
CX2E0RA/10-032V	Area sensor
CX2E0RA/10-032VTB	Area sensor
CX2E0RA/10-048V	Area sensor
CX2E0RA/10-064V	Area sensor
CX2E0RA/10-080V	Area sensor
CX2E0RA/10-096V	Area sensor
CX2E0RA/20-016V	Area sensor
CX2E0RA/20-032V	Area sensor
CX2E0RA/20-048V	Area sensor
CX2E0RA/20-064V	Area sensor
CX2E0RA/20-080V	Area sensor
CX2E0RA/20-096V	Area sensor
CX2E0RB/05-016V	Area sensor
CX2E0RB/05-048V	Area sensor
CX2E0RB/10-016V	Area sensor
CX2E0RB/10-032V	Area sensor





Product	Description
CX2E0RB/10-048V	Area sensor
CX2E0RB/10-064V	Area sensor
CX2E0RB/10-096V	Area sensor
CX2E0RB/20-016V	Area sensor
CX2E0RB/20-032V	Area sensor
CX2E0RB/20-048V	Area sensor
CX2E0RB/20-064V	Area sensor
CX2E0RB/20-080V	Area sensor
CX2E0RB/20-096V	Area sensor
CX2E0RF/05-016V	Area sensor
CX2E0RF/05-032V	Area sensor
CX2E0RF/05-048V	Area sensor
CX2E0RF/10-016V	Area sensor
CX2E0RF/10-032V	Area sensor
CX2E0RF/10-048V	Area sensor
CX2E0RF/10-064V	Area sensor
CX2E0RF/10-080V	Area sensor
CX2E0RF/10-096V	Area sensor
CX2E0RF/20-016V	Area sensor
CX2E0RF/20-032V	Area sensor
CX2E0RF/20-048V	Area sensor
CX2E0RF/20-064V	Area sensor
CX2E0RF/20-080V	Area sensor
CX2E0RF/20-096V	Area sensor
<u>C18P/A0-1A</u>	Capacitive sensor
<u>C18P/A0-1E</u>	Capacitive sensor
<u>C18P/A0-2A</u>	Capacitive sensor
<u>C18P/A0-2E</u>	Capacitive sensor
<u>C18P/BN-1A</u>	Capacitive sensor
<u>C18P/BN-1E</u>	Capacitive sensor
<u>C18P/BN-2A</u>	Capacitive sensor
<u>C18P/BN-2E</u>	Capacitive sensor
<u>C18P/BP-1A</u>	Capacitive sensor
<u>C18P/BP-1E</u>	Capacitive sensor
<u>C18P/BP-2A</u>	Capacitive sensor
<u>C18P/C0-1A</u>	Capacitive sensor
<u>C18P/C0-1E</u>	Capacitive sensor
<u>C18P/C0-2A</u>	Capacitive sensor
<u>C18P/C0-2E</u>	Capacitive sensor
<u>C30M/00-1A</u>	Capacitive sensor
<u>C30M/00-1E</u>	Capacitive sensor
<u>C30M/00-2A</u>	Capacitive sensor
<u>C30M/00-2E</u>	Capacitive sensor





C30MEN-1A Capacitive sensor C30MEN-2A Capacitive sensor C30MEN-2E Capacitive sensor C30MEP-2E Capacitive sensor C30MEP-2E Capacitive sensor C30MEN-2A Capacitive sensor C30PR0-1A Capacitive sensor C30PR0-2E Capacitive sensor C30PR0-2A Capacitive sensor C30PR0-2A <th>Product</th> <th>Description</th>	Product	Description
C30M/BN-2A Capacitive sensor C30M/BP-1A Capacitive sensor C30M/BP-1E Capacitive sensor C30M/BP-2A Capacitive sensor C30M/BP-2A Capacitive sensor C30M/BP-2A Capacitive sensor C30P/00-1A Capacitive sensor C30P/00-1A Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2A Capacitive sensor <t< td=""><td>C30M/BN-1A</td><td>Capacitive sensor</td></t<>	C30M/BN-1A	Capacitive sensor
C30M/BP-12E Capacitive sensor C30M/BP-14E Capacitive sensor C30M/BP-2A Capacitive sensor C30M/BP-2A Capacitive sensor C30M/BP-2A Capacitive sensor C30M/BP-2A Capacitive sensor C30P/00-1A Capacitive sensor C30P/00-1E Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2E Capacitive sensor C30P/BN-1A Capacitive sensor C30P/BN-1A Capacitive sensor C30P/BN-1A Capacitive sensor C30P/BN-1A Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BN-1E Capacitive sensor C30P/BP-1A Capacitive sensor C30P/BP-1E Capacitive sensor C30P/BP-2E Capacitive sensor	C30M/BN-1E	Capacitive sensor
C30M/BP-1A Capacitive sensor C30M/BP-1E Capacitive sensor C30M/BP-2A Capacitive sensor C30P.00-1A Capacitive sensor C30P.00-1A Capacitive sensor C30P.00-1A Capacitive sensor C30P.00-1E Capacitive sensor C30P.00-2A Capacitive sensor C30P.00-2E Capacitive sensor C30P.00-2A Capacitive sensor C30P.00-2A Capacitive sensor C30P.00-2A Capacitive sensor C30P.00-2A Connector CD08(0A-020A1 Connector CD08(0A-020C5 Connector CD08(0A-020C5 Connector CD08(0A-050C5 Connector CD08(0A-050C5 </td <td><u>C30M/BN-2A</u></td> <td>Capacitive sensor</td>	<u>C30M/BN-2A</u>	Capacitive sensor
C30M/BP-1E Capacitive sensor C30M/BP-2A Capacitive sensor C30M/BP-2E Capacitive sensor C30P/00-1A Capacitive sensor C30P/00-1A Capacitive sensor C30P/00-1E Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2A Capacitive sensor C30P/BN-1E Capacitive sensor C30P/BN-1E Capacitive sensor C30P/BN-2A Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BP-1E Capacitive sensor C30P/BP-1E Capacitive sensor C30P/BP-2A Capacitive sensor CD08/0A-020A1 Connector CD08/0A-020A1 Connector <	<u>C30M/BN-2E</u>	Capacitive sensor
C30M/BP-2A Capacitive sensor C30M/BP-2E Capacitive sensor C30P:00-1A Capacitive sensor C30P:00-2A Capacitive sensor C30P:00-2A Capacitive sensor C30P:00-2E Capacitive sensor C30P:00-2A Capacitive sensor CD08:0A-202C5 Connector	<u>C30M/BP-1A</u>	Capacitive sensor
C30MBP-2E Capacitive sensor C30P:00-1A Capacitive sensor C30P:00-2A Capacitive sensor C30P:00-2E Capacitive sensor C30P:00-20A1 Connector CD08:00-020A5 Connector CD08:00-020A5 Connector CD08:00-020A5 Connector CD08:00-020A5 Connector CD08:00-050A5 Connector CD08:00-050A5 Connector CD08:00-100A5US Connector CD08:00-100A5US	<u>C30M/BP-1E</u>	Capacitive sensor
C30P:00-1A Capacitive sensor C30P:00-2E Capacitive sensor C30P:00-2E Capacitive sensor C30P:00-2E Capacitive sensor C30P:BN-1A Capacitive sensor C30P:BN-1A Capacitive sensor C30P:BN-1A Capacitive sensor C30P:BN-2A Capacitive sensor C30P:BN-2E Capacitive sensor C30P:BP-1A Capacitive sensor C30P:BP-2E Capacitive sensor C30P:BP-2A Capacitive sensor C30P:BP-2A Capacitive sensor C30P:BP-2E Capacitive sensor CD08:0A-020A5 Connector CD08:0A-202C1 Connector CD08:0A-202C5 Connector CD08:0A-100A5US Connector CD08:	<u>C30M/BP-2A</u>	Capacitive sensor
C30P/00-1E Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2E Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2A Capacitive sensor C30P/00-2A Connector CD08/0A-020A1 Connector CD08/0A-020A1 Connector CD08/0A-020A1 Connector CD08/0A-050A5 Connector CD08/0A-050A5 Connector CD08/0A-050A5 Connector CD08/0A-050A5 Connector CD08/0A-050A5 <td><u>C30M/BP-2E</u></td> <td>Capacitive sensor</td>	<u>C30M/BP-2E</u>	Capacitive sensor
C30P/00-2A Capacitive sensor C30P/00-2E Capacitive sensor C30P/BN-1A Capacitive sensor C30P/BN-1E Capacitive sensor C30P/BN-2A Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BP-1E Capacitive sensor C30P/BP-1E Capacitive sensor C30P/BP-2A Capacitive sensor C30P/BP-2E Capacitive sensor CD08/0A-020A1 Connector CD08/0A-020C1 Connector CD08/0A-020C2 Connector CD08/0A-020C3 Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/	<u>C30P/00-1A</u>	Capacitive sensor
C30P/00-2E Capacitive sensor C30P/BN-1A Capacitive sensor C30P/BN-1E Capacitive sensor C30P/BN-2A Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BN-2E Capacitive sensor C30P/BP-1A Capacitive sensor C30P/BP-2A Capacitive sensor C30P/BP-2A Capacitive sensor C30P/BP-2E Capacitive sensor C30P/BP-2E Capacitive sensor C30P/BP-2E Capacitive sensor C30P/BP-2E Capacitive sensor CD08/0A-020A1 Connector CD08/0A-020A5 Connector CD08/0A-020C5 Connector CD08/0A-020C5 Connector CD08/0A-020C5 Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-050A5US Connector CD08/0A-100A1US Connector CD08/0A-100A1US Connector CD08/0A-100A5US Conne	<u>C30P/00-1E</u>	Capacitive sensor
C30P/BN-1ACapacitive sensorQ30P/BN-1ECapacitive sensorC30P/BN-2ECapacitive sensorC30P/BN-2ECapacitive sensorC30P/BP-1ACapacitive sensorC30P/BP-1ECapacitive sensorC30P/BP-2ECapacitive sensorC30P/BP-2ECapacitive sensorC30P/BP-2ECapacitive sensorCD8/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A1USConnectorCD08/0A-100A1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0	<u>C30P/00-2A</u>	Capacitive sensor
C30P/BN-1ECapacitive sensorC30P/BN-2ACapacitive sensorC30P/BN-2ECapacitive sensorC30P/BP-1ACapacitive sensorC30P/BP-1ECapacitive sensorC30P/BP-2ACapacitive sensorC30P/BP-2ECapacitive sensorC30P/BP-2ECapacitive sensorC30P/BP-2ECapacitive sensorCD08/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1ConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1 <td><u>C30P/00-2E</u></td> <td>Capacitive sensor</td>	<u>C30P/00-2E</u>	Capacitive sensor
C30P/BN-2ACapacitive sensorC30P/BN-2ECapacitive sensorC30P/BP-1ACapacitive sensorC30P/BP-1ECapacitive sensorC30P/BP-2ACapacitive sensorC30P/BP-2ECapacitive sensorC30P/BP-2ECapacitive sensorC008/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C1ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A5USConnectorCD08/0A-050A5USConnectorCD08/0A-050C5SConnectorCD08/0A-050C5SConnectorCD08/0A-050C5SConnectorCD08/0A-050C5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnector	<u>C30P/BN-1A</u>	Capacitive sensor
C30P/BN-2ECapacitive sensorC30P/BP-1ACapacitive sensorC30P/BP-1ECapacitive sensorC30P/BP-2ACapacitive sensorC30P/BP-2ECapacitive sensorCD08/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5USConnectorCD08/0A-050A5USConnectorCD08/0A-050A5USConnectorCD08/0A-050C5USConnectorCD08/0A-050C5USConnectorCD08/0A-050C5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1SUSConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnector<	<u>C30P/BN-1E</u>	Capacitive sensor
C30P/BP-1ACapacitive sensorC30P/BP-1ECapacitive sensorC30P/BP-2ACapacitive sensorC30P/BP-2ECapacitive sensorCD08/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1SConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorC	<u>C30P/BN-2A</u>	Capacitive sensor
C30P/BP-1ECapacitive sensorC30P/BP-2ACapacitive sensorC30P/BP-2ECapacitive sensorCD08/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C1ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-100A1USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-1	<u>C30P/BN-2E</u>	Capacitive sensor
C30P/BP-2ACapacitive sensorC30P/BP-2ECapacitive sensorCD08/0A-020A5ConnectorCD08/0A-020A5ConnectorCD08/0A-020C1ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5USConnectorCD08/0A-050A5USConnectorCD08/0A-050C5USConnectorCD08/0A-050C5USConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD	<u>C30P/BP-1A</u>	Capacitive sensor
C30P/BP-2ECapacitive sensorCD08/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C5ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector	<u>C30P/BP-1E</u>	Capacitive sensor
CD08/0A-020A1ConnectorCD08/0A-020A5ConnectorCD08/0A-020C1ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USCo	<u>C30P/BP-2A</u>	Capacitive sensor
CD08/0A-020A5ConnectorCD08/0A-020C1ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050A5USConnectorCD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5SConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector	<u>C30P/BP-2E</u>	Capacitive sensor
CD08/0A-020C1ConnectorCD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5ConnectorCD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector	<u>CD08/0A-020A1</u>	Connector
CD08/0A-020C5ConnectorCD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5USConnectorCD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector	<u>CD08/0A-020A5</u>	Connector
CD08/0A-050A1USConnectorCD08/0A-050A5ConnectorCD08/0A-050A5USConnectorCD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector	<u>CD08/0A-020C1</u>	Connector
CD08/0A-050A5ConnectorCD08/0A-050A5USConnectorCD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector	<u>CD08/0A-020C5</u>	Connector
CD08/0A-050A5USConnectorCD08/0A-050C1USConnectorCD08/0A-050C5USConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-050C1USConnectorCD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5ConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150C1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector	<u>CD08/0A-050A5</u>	Connector
CD08/0A-050C5ConnectorCD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150C1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-050C5USConnectorCD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-100C5USConnectorCD08/0A-150SUSConnectorCD08/0A-150A1USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-100A1USConnectorCD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150USConnectorCD08/0A-150A1USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector	CD08/0A-050C5	Connector
CD08/0A-100A5ConnectorCD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector	CD08/0A-050C5US	Connector
CD08/0A-100A5USConnectorCD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-100C1ConnectorCD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		
CD08/0A-100C1USConnectorCD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-100C5USConnectorCD08/0A-150A1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-150A1USConnectorCD08/0A-150A5USConnectorCD08/0A-150C1ConnectorCD08/0A-150C1USConnectorCD08/0A-150C5USConnectorCD08/0A-200A1Connector		Connector
CD08/0A-150A5US Connector CD08/0A-150C1 Connector CD08/0A-150C1US Connector CD08/0A-150C5US Connector CD08/0A-200A1 Connector		Connector
CD08/0A-150C1 Connector CD08/0A-150C1US Connector CD08/0A-150C5US Connector CD08/0A-200A1 Connector		
CD08/0A-150C1US Connector CD08/0A-150C5US Connector CD08/0A-200A1 Connector		
CD08/0A-150C5US Connector CD08/0A-200A1 Connector		
CD08/0A-200A1 Connector		Connector
		Connector
CD08/0A-200A5 Connector		
	<u>CD08/0A-200A5</u>	Connector





Product	Description
CD08/0A-200C1	Connector
CD08/0A-200C5	Connector
<u>CD08/0B-020A1</u>	Connector M8 Axial CEI 2022 II 4 poles cable 2 m
CD08/0B-020A5	Connector M8 Axial PUR 4 poles cable 2 m M8
CD08/0B-020C1	Connector M8 90° CEI 2022 II 4 poles cable 2 m
CD08/0B-050A1US	Connector M8 Axial 4 poles cable 5 m CSA
<u>CD08/0B-050A5</u>	Connector M8 Axial PUR 4 poles cable 5 m M8
CD08/0B-050A5US	Connector
CD08/0B-050C1US	Connector
CD08/0B-050C5	Connector M8 90° PUR 4 poles cable 5 m M8
CD08/0B-050C5US	Connector
CD08/0B-100A1US	Connector
CD08/0B-100A5	Connector
CD08/0B-100A5US	Connector
CD08/0B-100C1	Connector M8 90° CEI 2022 II 4 poles cable 10 m
CD08/0B-100C1US	Connector M8 90° 4 poles cable 10 m CSA
CD08/0B-100C5US	Connector
CD08/0B-150A1	Connector
CD08/0B-150A1US	Connector