



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Nason

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">MM-56C-22F/HRVTAU193</a>	PRESSURE SWITCH
<a href="#">SM-2C-50R</a>	PRESSURE SWITCH
<a href="#">NS-T1C-12G/EFEP</a>	pressure switch
<a href="#">SM-2C-10F/BTAT21</a>	pressure switch
<a href="#">TT-D3A-105R/QC</a>	Temperature Switch
<a href="#">SP-1YXX-10R/55</a>	manocontact
<a href="#">LM-2A-225R/WL</a>	Pressure Switch
<a href="#">LM-2A-60R</a>	Pressure Switch
<a href="#">LM-11A-110R/QC119</a>	Pressure switch
<a href="#">CJ-2C-16G/WL115</a>	Pressure Switch
<a href="#">VP-48C-22R/6WLAQ2</a>	
<a href="#">CD-1B4-200G/HR232</a>	high pressure switch
<a href="#">CD-1A7-3200J/HR231</a>	high pressure switch
<a href="#">SM-2C-10F/BTAT24</a>	Pressure switch
<a href="#">WX-18C-1500G/HR</a>	high pressure switch
<a href="#">SM-2C-5F/QCAU</a>	pressure switch
<a href="#">SM-2C-45R/QCAU</a>	PRESSURE SWITCH
<a href="#">NS-P1A-10J/ELAU</a>	switch
<a href="#">SM-60A-64R/8WL</a>	noncontact
<a href="#">SM-12A-10F/PD</a>	Pressure Switch
<a href="#">TM-6A-120R/WL</a>	Temperature Switch
<a href="#">TM-2C-140R/HR</a>	Temperature switch
<a href="#">TD-2C-260R/8WLAU</a>	
<a href="#">SM-19C-7.5R/DPGG17</a>	NASON PRESS SW
<a href="#">001) NASON HT-1C-120R/HR</a>	Switch
<a href="#">SM-2C-20F/QC</a>	Pressure switch
<a href="#">SM-2C-20F/QCATBT</a>	PRESSURE SWITCH
<a href="#">SM-2C-10F/QC</a>	.
<a href="#">TM-7C-105R/HR</a>	Temperature Switch
<a href="#">XM-6B-600R/HR</a>	pressure switch
<a href="#">TT-F2B-80R</a>	TEMPERATURE SWITCH
<a href="#">WX-1C-500J/HR</a>	Pressure Switch
<a href="#">MM-2B-5R</a>	Pressure Switch
<a href="#">SP-2C-23R/5EL135</a>	
<a href="#">NS-B2C-16G/7WLEP84</a>	

Product	Description
<a href="#">LH-32X200MSM-UR</a>	
<a href="#">SM-2C-15F/QCVTAU739</a>	
<a href="#">WX-1C-1600J</a>	Pressure Switch
<a href="#">XP-19A-50F/ESAU23</a>	pressure switch
<a href="#">MM-2A-20R/NPAU76</a>	Pressure switch
<a href="#">MM-2C-20R/MPAT</a>	Pressure Switch
<a href="#">CD-11C5-500J/HR</a>	HIGH PRESSURE SWITCH
<a href="#">AC-M5</a>	
<a href="#">WX-4A-2700J/HR</a>	PRESS SWITCH
<a href="#">SM-2C-15F/QCVT552</a>	Pressure switch
<a href="#">WX-4C-800 J/ WL 14</a>	
<a href="#">NS-T1C-80J / EFEP</a>	High press SW
<a href="#">3PSI/DEC SPIC-4P</a>	
<a href="#">SM-2C-20F/QCATBT403</a>	Low Pressure Switch
<a href="#">SM-2C-45F/QCAU</a>	
<a href="#">TT-F3A-235R</a>	temperature switch
<a href="#">XM-69C-100F/WD266</a>	
<a href="#">TT-F3B-60F/72</a>	Switch
<a href="#">WX-1C-1600J / HR</a>	pressure switch
<a href="#">SM-12A-10F/PDHJ892</a>	
<a href="#">TT-D3A-135R/QC</a>	
<a href="#">LM-2C-145R/AT</a>	PRESSURE SWITCH
<a href="#">XM-6C-625R/WLAU</a>	switch
<a href="#">WX-1C-3500J</a>	
<a href="#">CD-1C6-1600J/WL179</a>	
<a href="#">WX-1C-270J/HR</a>	
<a href="#">MM-60A-64R/8WL</a>	
<a href="#">SM-2C-4F/AT</a>	pressure switch
<a href="#">SM-2C-20F/QCVTAU815</a>	PRESSURE SWITCH
<a href="#">MM-56C-22F/ESVTAU254</a>	NASON PRESSURE SWITCH
<a href="#">XP-1C-200G/WL</a>	
<a href="#">TT-D3A-235R/QCGG12</a>	Sensor
<a href="#">TD-2A-205R/QC51</a>	Sensor
<a href="#">45641</a>	switch
<a href="#">SM-A1A-8F/QC</a>	Pressure Control Switch
<a href="#">TT-F1A-20R</a>	
<a href="#">SM-1A-25F/7CL</a>	NASON PRESSURE SWITCH
<a href="#">SM-1C-58F/HH   0697375</a>	PRESSURE AIR SWITCH
<a href="#">TT-D1A-239R/WL</a>	Temperature Sensor
<a href="#">CD-174</a>	NASON SWITCH
<a href="#">SM-14C-20R/HR</a>	Low Pressure Switch
<a href="#">WX-1C-100J</a>	High Pressure Switch
<a href="#">XM-6C-625R</a>	PRESSURE SWITCH

Product	Description
<a href="#">SM-2C-95F/WLAU</a>	switch
<a href="#">CJ-1C2-10G/HM</a>	Sensor
<a href="#">WX-1C-100J/HR</a>	switch
<a href="#">LM-2A-225R/WL49</a>	Pressure switch
<a href="#">NASO0351</a>	Low Pressure Switch
<a href="#">SM-2C-60R/QC24</a>	PRESSURE SWITCH
<a href="#">SM-1C-100R/HH</a>	SWITCH, 100 PSI;
<a href="#">NT100-03-C-5000-G-BOO-4</a>	
<a href="#">XM-1C-150F/HR</a>	pressure switch
<a href="#">NASO0353</a>	High Pressure Switch
<a href="#">CD-1C4-200G/6WL378</a>	pressure switch
<a href="#">LM-85A-75R/WD219</a>	pressure switch
<a href="#">SM-T1C-1R/HR190</a>	Low Pressure Switch
<a href="#">SM-2B-120R/ QCAT885</a>	
<a href="#">SM-2C-27F/BTAT6</a>	Low Pressure Switch
<a href="#">SM-2C-20F/BTAT25</a>	Low Pressure Switch
<a href="#">TT-E1B-225R/WP</a>	thermocontact
<a href="#">SM-2A-15F/WPAU</a>	Monocontact
<a href="#">TM-1B-280R</a>	temperature switch
<a href="#">XM-1C-90F/WL</a>	pressure switch
<a href="#">SM-2C- 5 F/BTAT22</a>	pressure switch
<a href="#">NS-2C-50F/HR</a>	
<a href="#">SM-2C-15F/WD</a>	press switch
<a href="#">MM-56C-15F/HRVTAU191</a>	PRESS SWITCH
<a href="#">NS-2C-20F/HR</a>	
<a href="#">XM1C-60R/WD595</a>	
<a href="#">CJ-2C2-10G/WLEP</a>	switch
<a href="#">TM-1B-300R/33</a>	TEMPERATURE SWITCH
<a href="#">SM-2A-10F/WDAT487</a>	Lubricating oil pressure switch
<a href="#">SM-14C-8F/QC</a>	
<a href="#">SP-2C-60R</a>	pressure switch
<a href="#">SM-2C-20F</a>	PRESSURE SWITCH
<a href="#">WX-18C-150G/HR</a>	
<a href="#">NT25-09-B-3000-G-Q00-2-X</a>	
<a href="#">HT-2A-120R/QCAH</a>	
<a href="#">MM-1B-60R</a>	
<a href="#">TM-1A-210R</a>	pressure switch
<a href="#">HT-2C-205R</a>	
<a href="#">15.9971</a>	pressure switch
<a href="#">LS-25X20MTM-HS</a>	
<a href="#">MM-2C-60F/MPAT</a>	
<a href="#">SM-14C-80R/54</a>	
<a href="#">SM-2C-6R/WLGG783</a>	

Product	Description
<a href="#">SM-1C-55R/HH</a>	
<a href="#">SM-1A-25F/7CLEP</a>	Low Pressure Switch
<a href="#">WX-5C-1000J/HH141</a>	
<a href="#">TT-D3A-110R/QC</a>	temp switch
<a href="#">SM-2A-50R/QC</a>	Pressure switch
<a href="#">XM-6C-150R/HR</a>	
<a href="#">MM-19A-10F/AT</a>	Pressure Switch
<a href="#">HT-1C-160R/HR</a>	temperature switch
<a href="#">15.5405</a>	Pressure Switch
<a href="#">CJ-2C2-10G/WL</a>	Switch
<a href="#">XP-1C-200G/WL118</a>	Pressure Switch
<a href="#">CJ-U2C-16G/WL116</a>	
<a href="#">SM2CF15 QCVTAU739</a>	
<a href="#">SM2CF15 QCVT552</a>	
<a href="#">SM-1A-S0R/QCAT</a>	
<a href="#">HT-1A-120R/EL</a>	
<a href="#">TT-D6A-203R/QC</a>	
<a href="#">SM-14A-10R/WL</a>	
<a href="#">MM-1A-10R/WL</a>	
<a href="#">SM-2C-7F/VT</a>	
<a href="#">XP-2C-115R</a>	
<a href="#">CF-T6C-2000F/MPAT176</a>	
<a href="#">CF-T1C-1500F/MPAT175</a>	
<a href="#">SM-2C-10F/BTAT363</a>	NASON PRESSURE SWITCH
<a href="#">NS-2C-10F</a>	
<a href="#">XM-3C-2000F/WDAU</a>	switch
<a href="#">LM-6A-100R/NP</a>	pressure switch
<a href="#">XM-1C-90F/123</a>	PRESSURE SWITCH
<a href="#">WX-5C-2000J/HR136</a>	PRESSURE SWITCH
<a href="#">WX-61A-800G/WP</a>	
<a href="#">SM-U1A-8F/QCVT</a>	pressure switch
<a href="#">WX-1C-5500/HH27</a>	
<a href="#">sm-2c-50r/npvtt956</a>	
<a href="#">NASON LM-1C-50F/WPAT</a>	NASON SWITCH
<a href="#">LM-1C-200R/WP</a>	pressure switch
<a href="#">CJ-U1C3-80G/HM</a>	PRESSURE SWITCH
<a href="#">LM-2C-225R/ HR24</a>	PRESSURE SWITCH
<a href="#">CJ-1C-16G/WL247</a>	Pressure Switch
<a href="#">MM-19A-5F/ESAU</a>	
<a href="#">CD-1A2-45J-WDAT</a>	
<a href="#">SM-19A-7F/QC</a>	
<a href="#">CD-1A4-300J/WL</a>	
<a href="#">SM-2C-60F/HH</a>	PRESSURE SWITCH

Product	Description
<a href="#">SM-1C-15F/HR</a>	
<a href="#">SM-1C-25F/HR</a>	
<a href="#">SM-1A-10R/HR</a>	Low Pressure Switch
<a href="#">CH-20X050DMT</a>	
<a href="#">LH-081287</a>	
<a href="#">SM-2C-8R/DP193</a>	Engine oil pressure probe
<a href="#">CS-091713</a>	
<a href="#">CJ-1A3-45G/HM</a>	
<a href="#">SM-2C-20F / WP</a>	
<a href="#">TM-1A-129R/WP</a>	
<a href="#">TT-J1B-225R/SL 146</a>	
<a href="#">SM-2C-20F/CCATBT403</a>	low pressure switch
<a href="#">SM-1C-20RHR</a>	PRESSURE SWITCHE
<a href="#">NS-1C-70J/WL</a>	PRESSURE SWITCH
<a href="#">SM-2A-12F</a>	
<a href="#">TT-D6B-233R/QC</a>	TT Switches
<a href="#">TT-D1B-233R/QC</a>	
<a href="#">VF-48C-22R/6WLATAQ5</a>	
<a href="#">TT-D1A-221R/QC</a>	
<a href="#">SM-2C-10F/QCAU</a>	
<a href="#">SM-2C-20F/QC473</a>	
<a href="#">LM-2A-35R/AT</a>	
<a href="#">XM-6B-1600R/QC</a>	
<a href="#">SM-1C-20F/HR</a>	Pressure switch
<a href="#">MM-6B-75R/WD</a>	
<a href="#">LM 6A 200R /QC</a>	
<a href="#">CD-1B6-1000J/HR</a>	
<a href="#">SCP</a>	
<a href="#">XP-19A-50F/ESAU609</a>	PRESSURE SWITCH
<a href="#">TD-16B-225R/QC</a>	
<a href="#">MM-2A-5R/AU</a>	
<a href="#">TM-1C-215R</a>	
<a href="#">SM-1C-5R/NP</a>	
<a href="#">SM-2C-5F/QCVT775</a>	
<a href="#">TM-7C-75R/HR</a>	
<a href="#">TM-7C-203R/QC</a>	Flow transmitter
<a href="#">SM-14C-15F/QC</a>	
<a href="#">TT-J1B-240R/QC54</a>	SENSOR
<a href="#">SM-1C-7F/EL</a>	
<a href="#">TT-D1A-105R/QC</a>	Temperature Switch
<a href="#">TT-D6A-203R/QC 5/13</a>	
<a href="#">TM-7C-88R/HR</a>	Temperature Switch
<a href="#">SM-2B-20F/QC</a>	

Product	Description
<a href="#">CJ-1A3-60J/WL</a>	Low Pressure Switch
<a href="#">XM-11B1500 F/AT</a>	
<a href="#">SM-2A-9F/WLAU88</a>	Low Pressure Switch
<a href="#">TD-2A-180R/QCATGG</a>	TEMPERATURE SWITCH
<a href="#">TD-2A-170R</a>	
<a href="#">TM-2C-210R</a>	
<a href="#">LH-63X15MT</a>	
<a href="#">KR-LH63L</a>	
<a href="#">MM-11A-75R/WD</a>	pressure switch
<a href="#">TD-2C-210R</a>	
<a href="#">CJ-1C3-35G/175</a>	Switch
<a href="#">1104A30</a>	Pressure Switch
<a href="#">CD-T1C1-12G/EFEP</a>	Adjustable Switch
<a href="#">MM-T1C-12F/EFEP360</a>	Switch
<a href="#">TT-D13A-105R/QC</a>	SWITCH TEMPERATURE
<a href="#">CD-1C4-200G/WLAT</a>	
<a href="#">CJ-12A3-29J/HM</a>	low pressure switch
<a href="#">SM-1C-2F/HR</a>	Low-Pressure Switch
<a href="#">CD-11C7-2500J/HR</a>	PRESS. SWITCH
<a href="#">SM-2B-10R/GG</a>	
<a href="#">TM-25A-140R/WD</a>	
<a href="#">TT-F43A-130R/QC</a>	
<a href="#">SM-2B-10R</a>	Low pressure switch
<a href="#">SM-2A-15F</a>	
<a href="#">MM-17-C-22F/HR</a>	low pressure switch
<a href="#">SM-2C-15F/QCHJ</a>	switch
<a href="#">SM-2C-20F /QCAU</a>	
<a href="#">MM-60A-64R/8WLNE</a>	PRESSURE SWITCH
<a href="#">0697375   XM-2C-115R</a>	PRESSURE SWITCH
<a href="#">MM-2C-60R/AT</a>	
<a href="#">LM-72A-70R/WD123</a>	Switch
<a href="#">CD-1C7-1800J/6EF   0697375</a>	
<a href="#">LM-26A-40F/TP99   0697375</a>	PRESSURE SWITCH
<a href="#">SM-2C-10F/QC, 15.0342-A</a>	
<a href="#">SM-2C-20F/BTAT364</a>	Low Pressure Switch
<a href="#">15.11814   2529738</a>	Press switch
<a href="#">MM-1C-15F/EL352</a>	Low Pressure Switch
<a href="#">MM-17C-22F/HRVTAU192 OEM</a>	
<a href="#">MM-17C-22F/HRVTAU192</a>	
<a href="#">VM-1A-16R/QC   0697375</a>	
<a href="#">XM-6A-550R/WP</a>	
<a href="#">SM-1B-60FN/P</a>	
<a href="#">SM-2C-40R</a>	pressure switch

Product	Description
<a href="#">SM-1B-60F/WP</a>	
<a href="#">HT-1B-220R</a>	
<a href="#">XM-11C2500RWD</a>	
<a href="#">SM-1C-5R/5WDAUVL</a>	
<a href="#">TD-2A-150R</a>	Sensor
<a href="#">SM-2C-25R/HRAU</a>	
<a href="#">TM-1A-160R/WL</a>	
<a href="#">MM-1A-3R/HHAT</a>	
<a href="#">TD-1A-160R/WL</a>	TEMPERATURE SWITCH
<a href="#">TD-2B-225R/WDAT11</a>	
<a href="#">SM-1A-3R/HHAT</a>	Pressure Switch
<a href="#">CD-1A2-30J/ELAU</a>	High Pressure Switch CD
<a href="#">SQ3</a>	
<a href="#">CJ-1B2-30J/HM</a>	
<a href="#">TM-7B-160R/HR</a>	
<a href="#">NASON SQ-3</a>	ADJUSTABLE PRESSURE SWITCH
<a href="#">XM11B-1400F/WD331</a>	
<a href="#">WX-1C-1600J/HR49</a>	
<a href="#">TM-7B-120R/HR</a>	
<a href="#">SM-2C-16F-QCGG</a>	engine temperature sensor
<a href="#">XM-11A-100F/HR435</a>	
<a href="#">XM-11A-100F/HR435</a>	pressure switch
<a href="#">SM-1C-5R/HRAT</a>	
<a href="#">XM-1C-1700F/HR</a>	
<a href="#">SM-2A-50R/OC</a>	Nasson Press Switch
<a href="#">SM-2C-5F/QC603</a>	oil pressure switch
<a href="#">SM-1C-5R/HR</a>	
<a href="#">Is-143739-3</a>	
<a href="#">MM-1A-45R/WDAT</a>	
<a href="#">23520024</a>	PRESSURE SWITCH
<a href="#">SM-1A-25R/HRAT</a>	
<a href="#">CD-1C5-230J/WDAU512</a>	pressure switch
<a href="#">SM-2A-9F-WL88</a>	Low Pressure Switch
<a href="#">MM-60A S4R/8WLNE</a>	
<a href="#">TM - 2C - 210R - QC - 110</a>	water high temperature switch
<a href="#">CD-1C5-320J/WDAU512</a>	
<a href="#">HT-1B-265R/EL12</a>	TEMP SWITCH
<a href="#">WX-4B-1900J/HH</a>	WX ADJUSTABLE HYD HP SWITCH
<a href="#">MM-2C-5R/AT</a>	
<a href="#">SM-1B-6F/WP</a>	
<a href="#">VF-48C-22R/HRATAQ6</a>	
<a href="#">TM-2B-212R/WP</a>	Temperature Switch
<a href="#">TD-2B-212R/WP</a>	Temperature Switch



Product	Description
<a href="#">WX-39C-1200J/HH</a>	High Pressure Switch
<a href="#">LS-25X24MB</a>	
<a href="#">XM-1B-500 F/WL</a>	pressure switch
<a href="#">XM-5B-1050R</a>	High Pressure Switch
<a href="#">XM-11B-72.5F/HH204</a>	pressure switch
<a href="#">MM-6A-295R/WL84</a>	
<a href="#">HT-2C-120R/HR</a>	
<a href="#">SM-2C-20F/HR</a>	
<a href="#">CD-11C4-150J/HR</a>	
<a href="#">HT 5A-140R/QCAH</a>	
<a href="#">CJ-U1C3-080G/HM</a>	
<a href="#">TM-1C-215R/PD</a>	
<a href="#">SM-2B-7F/QC</a>	
<a href="#">LM-1C-200R/WL</a>	pressure switch
<a href="#">1018A30</a>	Pressure switch
<a href="#">SM-2C-70F</a>	Pressure Switch
<a href="#">MM-2C-10R/WL</a>	switch
<a href="#">MS90530-1</a>	switch
<a href="#">SM-1B-6F/P811</a>	
<a href="#">TD-7C-203R/QC</a>	
<a href="#">HT-5A-115R/QCAH</a>	Temperature Sensor
<a href="#">XM-17B- 1700F/WD501</a>	HYDRAULIC VALVE
<a href="#">SP-1C-4R/P60</a>	
<a href="#">SM-2C-9F/AT</a>	pressure switch
<a href="#">TD-17C-240R</a>	Snap-disc temperature switch
<a href="#">L20-40X30DMB-RH</a>	
<a href="#">MM-1C-25F/AU</a>	
<a href="#">MM-1C-35F/AU</a>	
<a href="#">SM-2C-50R/438</a>	pressure switches
<a href="#">CE-05X025MSM</a>	PNEUMATIC PISTON
<a href="#">SM-14C-80F/QC</a>	
<a href="#">SM-1A-25F/7QL</a>	switch
<a href="#">SM-1A-25R/7CL</a>	PRESSURE SWITCH
<a href="#">SM-2C-50F/HR</a>	
<a href="#">CD-T1C1-10G/HR</a>	High Pressure Switch
<a href="#">SM-T1C-10F/HR</a>	Low Pressure Switch
<a href="#">CM-17A-55F/QC</a>	PRESSURE SWITCH
<a href="#">SM-1B-60F/PD</a>	Pressure switch
<a href="#">SM-2C-40F/HR</a>	PRESSURE SWITCH
<a href="#">TM-1C-180R/WP</a>	
<a href="#">XM-19A-50F/ESAU609</a>	
<a href="#">TT-E11B-239R/QC</a>	TEMPERATURE SWITCH
<a href="#">MM-1C-4F/EL353</a>	

Product	Description
<a href="#">SM-2C-15F/QCVT</a>	LOW PRESSURE SWITCH
<a href="#">VM-2C-18R/CL21</a>	Pressure switch
<a href="#">CD-1A1-10J/ELAU</a>	High-Pressure Switch
<a href="#">VM-2C-12F/CL20</a>	
<a href="#">VF-2C-25R/QCAQ17</a>	Open switch
<a href="#">XM-1C-1500R/HHAU</a>	PRESSURE SWITCH
<a href="#">HT-1C-150R-HR</a>	Temperature switch
<a href="#">XM-11A-100F/HH</a>	Pressure Switch
<a href="#">SM-2C-15F/AT</a>	PRESSURE SWITCH
<a href="#">SM-2C-25F/AT</a>	PRESSURE SWITCH
<a href="#">CD-6B-2150R/WD194</a>	Pressure Switch
<a href="#">SM-2C-15F/HR</a>	
<a href="#">MM-19A-10F/ESAU302</a>	
<a href="#">SM-1C-8F/HHNF787</a>	Pressure Sensor
<a href="#">SM-2C-50R/NPVTAT956</a>	
<a href="#">SM-2C-15F/QC472</a>	
<a href="#">TM-1C 235R/AT</a>	
<a href="#">TT-D1A-220R/QC</a>	
<a href="#">TM-1C 234R/AT</a>	
<a href="#">SM-2C-15F</a>	
<a href="#">TD-7A-140R</a>	
<a href="#">wx-6c-200g/qc</a>	High pressure switch
<a href="#">XM-1C-1200F</a>	
<a href="#">MM-2C-40F/NP51</a>	pressure switch
<a href="#">WX-4B-1900J/HR</a>	
<a href="#">LM-2C-130R/WLAT</a>	
<a href="#">CD-1C7-1800J/HH</a>	
<a href="#">MM-2C-60R</a>	switch
<a href="#">SM-17B-10 F/WL</a>	
<a href="#">HT-1C-215R</a>	
<a href="#">WX-1C-600J/HR</a>	
<a href="#">XM-11A-1500R/HR</a>	
<a href="#">CD-1C4-150J/MPAT</a>	
<a href="#">WX-1C-600R/HR</a>	
<a href="#">SM-2C-10F/QC (1/8NPTF ISOLE )</a>	
<a href="#">MM-30B-10R/WL</a>	Pressure switch
<a href="#">SM-2C-4F</a>	