



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онгъл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Revere

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">SHBxR 50 kg C3</a>	Stainless steel bending bar load cell
<a href="#">HPS-12kg-C3</a>	REVERE TRANSDUCERS
<a href="#">0705C3V</a>	
<a href="#">3030C3</a>	R T E - CELL Type: ASC-30t-C3-SC in stainless steel
<a href="#">Typ: ACB-5t-C3-SC (285C3)</a>	R T E - Wägezelle
<a href="#">ART.NO.0125C3 CSP-M-25T-C3-SC</a>	R T E - LOAD CELL
<a href="#">3030C3 Type ASC-30t-C3-SC</a>	Load Cell
<a href="#">ASC-50T-C3-SC</a>	R T E - CELL
<a href="#">SHBxR-100kg-C3-SC ATEX</a>	Sensor
<a href="#">0530C3 Typ: HPS-30kg-C3</a>	REVERE TRANSDUCERS
<a href="#">RLC-10t-C3 1910C3</a>	R T E - WÄGEZELLE
<a href="#">0302C3 (SHBxR-200kg-C3-SC 3M/6W)</a>	R T E - WÄGEZELLE
<a href="#">RLC-0.5t-C3</a>	R T E - WÄGEZELLE
<a href="#">10420003C3</a>	Plattform-Wägezelle
<a href="#">642C</a>	Peson
<a href="#">ACB-1.0t-C3-SC</a>	Revere transducers
<a href="#">Mounting plate for RLC 0.25-5.0t</a>	RING TORSION LOAD CELL
<a href="#">Parts set for load corner RLC 0.25-1t/VA</a>	Compression vessel load cell
<a href="#">Adapter plate for RLC-1t</a>	Compression Load Cell
<a href="#">SSB-2t-C3-SC</a>	load cell
<a href="#">9363-1.5k-C3-20T1</a>	
<a href="#">HPS-60kg-C3 (0560CC)</a>	R T E - WÄGEZELLE
<a href="#">RLC-1.0t-C3 (191C3)</a>	R T E - WÄGEZELLE
<a href="#">1910C3) RLC-10t-C3</a>	Wägezelle
<a href="#">P/N: 0301C3 Type: SHBxR-100kg-C3-SC</a>	REVERE TRANSDUCERS
<a href="#">SHBxR</a>	Single-Ended Load Beam
<a href="#">RLC-0,25t-C3</a>	Ring torsion load cell
<a href="#">Typ: 5103-50 Klbs-C3-30K1 (14050C3)</a>	R T E - WÄGEZELLE
<a href="#">SHBxR-100kg-C3</a>	Load cell
<a href="#">9123-4klbs-D3-20P1</a>	Scherstab-Wägezelle
<a href="#">VT300 / A-2-1-0-0-E</a>	Wiege-Elektronik
<a href="#">021C3 SSB-1t-C3-SC</a>	R T E - WÄGEZELLE
<a href="#">07025C3V</a>	Universal Load Cell
<a href="#">Typ: 9102-500lbs-C3-SC /227 kg (160500C3V)</a>	load cell
<a href="#">HPS-12kg-C2</a>	

Product	Description
<a href="#">075C3V</a>	R T E - WÄGEZELLE
<a href="#">SHBxR-50kg-C3-SC 3M/6W</a>	Loadcell
<a href="#">SHBxR-50kg-C3-SC 3M/6W</a>	Loadcell
<a href="#">3050C3</a>	
<a href="#">0302C3</a>	Load Cell
<a href="#">AJB-04</a>	Klemmenkasten (Junction Box)
<a href="#">BSP-0,125t-C3-SC</a>	Universal Load Cell
<a href="#">5090701</a>	external joint head
<a href="#">5090302</a>	Single-Ended Load Beam
<a href="#">Typ: SSB-5,0t-C3-SC</a>	
<a href="#">Elastomer bearing for SSB 5t 511-52-10-4</a>	
<a href="#">P/N: 899560-33-RI</a>	
<a href="#">SHBxR-50kg-C3-SC 3M/6W</a>	
<a href="#">Typ: 9123-2,0t-C3-20P1</a>	Wägezelle
<a href="#">00ASC-040T-C4-00X</a>	
<a href="#">BSP-5,0t-C3-SC</a>	sensor
<a href="#">40050</a>	
<a href="#">9123-15K-A5-20P1</a>	cell
<a href="#">1905C3</a>	Load cell
<a href="#">SSB-5,0t-C3-SC</a>	Weighing Cell
<a href="#">HPS-6kg-C3</a>	load cell
<a href="#">363-100lbs-D3</a>	
<a href="#">BSP-1Klb-10000S-1C</a>	
<a href="#">SHBxR-200kg-C3-SC</a>	transducer
<a href="#">0301C3 / SHBxR-100kg-C3-SC</a>	Bendestab load cell
<a href="#">102113-01</a>	Hydrometer
<a href="#">0301C3 Type SHBxR-100kg-C3-SC</a>	REVERE TRANSDUCERS
<a href="#">9363-100kg-C3</a>	S-load cell
<a href="#">P/N: 03002C3 Type: SHBxR-20kg-C3-SC</a>	Load cell
<a href="#">RLC-1t-C3 / 191C3</a>	Ring load cell
<a href="#">5041906V</a>	Einkugel-foot
<a href="#">SHBxR-200kg-C3</a>	Load cell
<a href="#">SHBxR-500kg-C3</a>	
<a href="#">KSR-28t-R2</a>	Load cell
<a href="#">SSB-2000lbs-10000M-1C</a>	Load Cell
<a href="#">BSP-1,25t-C3-SC</a>	
<a href="#">9363-0,5T-C3</a>	sensor
<a href="#">ASC-30t-C3-SC</a>	pressure load cell
<a href="#">5041906V (504-79-70-4)</a>	Single ball base
<a href="#">SHBxR-100kg-C3-SC</a>	REVERE TRANSDUCERS
<a href="#">899513-19-R</a>	TRANSDUCER
<a href="#">9103-20Klbs-B10-30P1</a>	REVERE TRANSDUCERS
<a href="#">SHBxR-350kg-C3-SC</a>	Load cell



Ttsipn	Oe ntD Ds'
<a href="#">SRS5EN9</a>	Jellow ergonomic guard for operator
<a href="#">SRS5M8RR</a>	1ampholder
<a href="#">S:SAP132SC</a>	safety device
<a href="#">S:S5EHC(RO</a>	1inear fluorescent ceiling light
<a href="#">SRSEHS</a>	-ontact block B.N.
<a href="#">S0SA5VÄ1</a>	
<a href="#">S0SA5V9</a>	
<a href="#">SOSjSzRS(z5:1</a>	-ontrol panel housing
<a href="#">S0SA531D</a>	Emergency stop palm switch
<a href="#">SzS3SzSz(938x</a>	emergency stop push(button
<a href="#">SHSÄA8PROU+H,RW</a>	incandescent lamp
<a href="#">SRSEV</a>	test diode
<a href="#">SRSä1D</a>	light signal fittings
<a href="#">SRSä19</a>	1ight and signal fittings
<a href="#">SRSä1Ä</a>	1ight and signal fittings
<a href="#">SRS5RDUP</a>	5ush button switch
<a href="#">SRS52B</a>	button
<a href="#">SRS531D</a>	xushroom push(button
<a href="#">SRS5319</a>	xushroom push(button
<a href="#">SRS531U</a>	xushroom push(button
<a href="#">SRS531Ä1</a>	xushroom push(button
<a href="#">S8Sx-HRÄ(RO</a>	
<a href="#">SzS-S8Hz(:5C</a>	
<a href="#">SzS-S0S8(:5R</a>	
<a href="#">SzS-S0S8(:</a>	
<a href="#">SCS95CS</a>	9rey guard for mushroom push(button
<a href="#">SCS3H</a>	-ontact block B.N.7B.-.
<a href="#">SzS-ASzSz(09EAP</a>	
<a href="#">S0SA531Ä1</a>	
<a href="#">E13.S0S551VHH</a>	
<a href="#">S0S5x9D</a>	5ush(button enclosure
<a href="#">SRS52-9B</a>	9uarded push(button, black, rubber cap
<a href="#">SRS52-9D</a>	9uarded push(button, red, rubber cap
<a href="#">SRS52-9U</a>	9uarded push(button, green, rubber cap
<a href="#">SRS52-9Ä</a>	9uarded push(button, white, rubber cap
<a href="#">SRS5VAADG</a>	button
<a href="#">SHSÄA8P1URO</a>	9reen multi(chip led lamp
<a href="#">SRSPxNB</a>	Gnob selector switch
<a href="#">SRSPxAB</a>	Gnob selector switch
<a href="#">SRS5VAAPDG</a>	xushroom push(button
<a href="#">SHSÄA8P1DRO</a>	red led bulb
<a href="#">S:S32HR</a>	
<a href="#">SRS5DR8</a>	



