



# ENAPART



93 S Railroad Avenue Unit C  
Bergenfield NJ 07621 USA  
[www.enapart.com](http://www.enapart.com)  
[sales@enapart.com](mailto:sales@enapart.com)



Via del Canneto 35,  
Borgosatollo, Brescia - Italia  
[www.enapart.it](http://www.enapart.it)  
[vendite@enapart.it](mailto:vendite@enapart.it)



Barbaros Mah. Ihlamur Bul. Aĝaoĝlu  
My Newwork No:3/15 Ataşehir / İstanbul  
[www.enapart.net](http://www.enapart.net)  
[satis@enapart.net](mailto:satis@enapart.net)



PRIVADA 10 B SUR #3908 COL.  
ANZUREZ, C.P. 72530, PUEBLA, PUE  
[www.enapart.com.mx](http://www.enapart.com.mx)  
[sales@enapart.com.mx](mailto:sales@enapart.com.mx)



Friedrich-Ebert-Anlage 36, 60325  
Frankfurt am Main, Germany  
[www.enapart.de](http://www.enapart.de)  
[anfrage@enapart.de](mailto:anfrage@enapart.de)



4 boulevard Carnot, 95400  
villiers-le-bel, Paris, France  
[www.enapart.fr](http://www.enapart.fr)  
[sales@enapart.fr](mailto:sales@enapart.fr)



65049, ОДЕСА, ВУЛИЦЯ ІВАНА  
ФРАНКА, БУДИНОК 55, ПОВЕРХ 3  
[www.enapart.com.ua](http://www.enapart.com.ua)  
[sales@enapart.com.ua](mailto:sales@enapart.com.ua)



MUNICIPIUL BUCUREȘTI, SECTOR 3,  
B-DUL BASARABIA, NR.250, CORP P+5  
[www.enapart.ro](http://www.enapart.ro)  
[sales@enapart.ro](mailto:sales@enapart.ro)



〒584-0023 大阪府富田林市若松町  
東2丁目2番16号  
[www.enapart.co.jp](http://www.enapart.co.jp)  
[sales@enapart.co.jp](mailto:sales@enapart.co.jp)



PLAZA NUESTRA SEÑORA DE LAS  
NIEVES 12 ,LOCAL ,50012,ZARAGOZA  
[www.enapart.es](http://www.enapart.es)  
[ventas@enapart.es](mailto:ventas@enapart.es)



Складова база „Онџл“, Склад А2, п.к.  
4006, гр. Пловдив, България  
[www.enapart.bg](http://www.enapart.bg)  
[sales@enapart.bg](mailto:sales@enapart.bg)



3 Austin Mews, High Street, Hemel  
Hempstead, HP1 3AF , United Kingdom  
[www.enapart.co.uk](http://www.enapart.co.uk)  
[sales@enapart.co.uk](mailto:sales@enapart.co.uk)

## Ytc

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

### BRAND'S PRODUCTS

Product	Description
<a href="#">SR.YTC.1000L-DM231S0</a>	Positioner
<a href="#">YT-1000LDI111S0</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000LSM111S3</a>	Electro-pneumatic positioner
<a href="#">YT-1000RDM522S10</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000RDN521S10</a>	Electro-Pneumatic Positioner
<a href="#">YT-200BN010</a>	Regulator Filter
<a href="#">YT-300N1</a>	Flow Amplifier
<a href="#">YT-300P1</a>	Flow Amplifier
<a href="#">REPAIR KIT FOR YT-310</a>	REPAIR KIT
<a href="#">YT-400SN1</a>	Lock Relay
<a href="#">YT-520D22</a>	Relay
<a href="#">YT-520S21</a>	relay
<a href="#">YT-850M411</a>	Limit Switch Box
<a href="#">YT-320N2</a>	Flow Amplifier
<a href="#">Model: YT-2500, LSn2221 S</a>	Smart Positioner
<a href="#">YT-1000RDN521S13</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000RDN531S13</a>	Rotary Electro-Pneumatic Positioner - YT-1000R
<a href="#">YT-2500LSI1321S</a>	Linear Smart Positioner - YT-2500L
<a href="#">YT-2500LSI1322S</a>	Linear Smart Positioner - YT-2500L
<a href="#">YT-1000RDN131S14</a>	POSITIONER
<a href="#">YT-2500LSI2324S</a>	
<a href="#">YT-1000RSN521S11</a>	Electro-Pneumatic Positioner
<a href="#">SP-RK-310</a>	
<a href="#">YT-205BN22</a>	
<a href="#">YT-3300RDN5221S</a>	Smart positioner
<a href="#">YT-3301LDN1200S1</a>	SMART POSITIONER
<a href="#">YT-1000RDN522S00</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000RDN131S13</a>	Actuator
<a href="#">YT-205BN210</a>	Air Filter Regulator
<a href="#">YTC.525-S23</a>	jump relay
<a href="#">YT-200BN110</a>	
<a href="#">YT-520S22</a>	
<a href="#">YT-1000RDn511S11</a>	
<a href="#">YT-1000</a>	E/P POSITIONER
<a href="#">YT-400DN1</a>	Relay

Product	Description
<a href="#">YT-1000RSn531S00</a>	
<a href="#">YT-870M41</a>	
<a href="#">YT-2500RDN5505F</a>	Smart positioner
<a href="#">YT-3300RDI2122S</a>	Smart positioner YT-3300
<a href="#">YT-3300RSI1122S</a>	Smart positioner YT-3300
<a href="#">YT-3300LSI1100S</a>	Smart positioner YT-3300 linear
<a href="#">YT-3300LSI4100S</a>	Smart positioner YT-3300 linear
<a href="#">YT-3300RSI2122S</a>	Smart positioner YT-3300
<a href="#">YT-2700 LSN 1100 S</a>	Smart positioner
<a href="#">YT-2500RSI2222S</a>	
<a href="#">Repair kit for YT-300 N1</a>	Repair kit
<a href="#">Repair kit for YT-310 N1</a>	Repair kit
<a href="#">Repair kit - YT-320 N1</a>	Repair kit
<a href="#">Repair kit for YT-520 D21</a>	Repair kit
<a href="#">YT-1000RDN521S00</a>	VALVE POSITIONER
<a href="#">YT-205BN21</a>	
<a href="#">YT-3300RDN5201S</a>	Intelligent Positioner
<a href="#">YT 2500 RDN 5200 F</a>	
<a href="#">YT-1000RDM532S00</a>	
<a href="#">YT-3300RDI5221S</a>	
<a href="#">YT-1000RDN521H10</a>	Electro-Pneumatic positioner
<a href="#">YT-1000LDN412S0</a>	
<a href="#">YT-2500LSI1301S</a>	Intelligent Positioner - YT-2500L - Linear
<a href="#">YT-2500LDI4221S</a>	SMART POSITIONER
<a href="#">YT-850</a>	Limit Switch Box
<a href="#">YT-3400RSC5221S</a>	Smart positioner
<a href="#">YT-1000RDN122S00</a>	positioner
<a href="#">YT-3300RDI5200S</a>	Positioner
<a href="#">YT-3300RDN2200S</a>	Positioner
<a href="#">AFR.YTC.200-BN211</a>	Regulator Filter
<a href="#">YT-930I12S01</a>	Solenoid valve
<a href="#">YT2500RSN5104S</a>	Smart positioner
<a href="#">YT-1000 LDM231S0</a>	Electro-Pneumatic Positioner
<a href="#">YT-315N1</a>	Flow Amplifier
<a href="#">YT-1000RDN532S15</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000RSN535S15</a>	Electro-Pneumatic Positioner
<a href="#">YT-3300RDI1200S</a>	Positioner
<a href="#">YT-1000LDN122S0</a>	
<a href="#">YT-1000L +SPTM&amp;LCD</a>	Electro-Pneumatic Positioner
<a href="#">YT-200BP210</a>	Filter Regulator
<a href="#">YT-3300 LSI 04 20 S</a>	positioner
<a href="#">YT-3300LSN1521S</a>	Digital Positioner
<a href="#">YT-200BN210</a>	Air Filter Regulator

Product	Description
<a href="#">YT-200AN010</a>	Filter Regulator
<a href="#">YT-3300LDN1220S</a>	Intelligent Positioner
<a href="#">YT-3300RDI5201S</a>	Intelligent Positioner
<a href="#">YT-2500LSI2301S</a>	Intelligent Positioner
<a href="#">YT-3350LSN1420S</a>	Intelligent Positioner
<a href="#">YT-1000RSN131S01</a>	Electro-pneumatic positioner
<a href="#">YT-3450LSC4400S</a>	Intelligent Positioner
<a href="#">YT-2500LSI1220S</a>	Intelligent Positioner
<a href="#">YT-1000RDM131S00</a>	Electro-Pneumatic Positioner
<a href="#">YT-200AN110</a>	Filter Regulator
<a href="#">YT-1000RDN531S00</a>	Electro-pneumatic positioner
<a href="#">YT-205AN110</a>	Filter Regulator
<a href="#">YT-3300RSI5121S</a>	Intelligent Positioner
<a href="#">YT-320N1</a>	Flow Amplifier
<a href="#">YT-310N1</a>	Flow Amplifier
<a href="#">YT-1000LSM132S00</a>	Electro-Pneumatic Positioner
<a href="#">YT-3400RDC5520S</a>	digital positioner
<a href="#">YT-3300RDI5100S</a>	Intelligent Positioner
<a href="#">YT-2500RDI5104SPX</a>	positioner
<a href="#">YT-1000RDN532S01</a>	Electro-Pneumatic Positioner
<a href="#">YT-2500RSI5221S</a>	Intelligent Positioner
<a href="#">59701</a>	
<a href="#">59702</a>	
<a href="#">YT-205BN211</a>	Filter Regulator
<a href="#">YT-1000LSN432S0</a>	Electro-Pneumatic Positioner
<a href="#">VB.YTC.310-N1.NPT</a>	Booster raley
<a href="#">SPTM-6VLC2</a>	Position Transmitter
<a href="#">YT-2500LDI1200S</a>	Intelligent Positioner
<a href="#">YT-3350LSI1222S</a>	Intelligent Positioner
<a href="#">YT-3350RSI2222S</a>	Intelligent Positioner
<a href="#">YT-1000RSP432S00</a>	Electro-Pneumatic Positioner
<a href="#">YT-720DP33</a>	Solenoid valve
<a href="#">YT-3300LSN1421S</a>	Intelligent Positioner
<a href="#">YT-1000RDN132H00</a>	Electro-Pneumatic Positioner
<a href="#">P/N: 60239, Type: SR.YTC.1000R-DN132H00</a>	positioner
<a href="#">SPTM-6VRC1</a>	Position transmitter
<a href="#">YT-1000RSC532S16</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000RSN532S15</a>	Electro-Pneumatic Positioner
<a href="#">YT-520D21</a>	
<a href="#">YT-3300RDN5220S</a>	
<a href="#">YT-3300LDI0201S</a>	
<a href="#">TYPE: YT-2500 Code: 2500 LSN 1104 S</a>	
<a href="#">AFR.YTC.200-BN020</a>	

Product	Description
<a href="#">YT-200 BN220</a>	
<a href="#">YT3300 RSI1100S</a>	
<a href="#">YT-400 DP1</a>	Locking Relay
<a href="#">YT-3300LDI1203S</a>	
<a href="#">YT3300-LSI1220L</a>	Linear positioner
<a href="#">YT-1000 RDN131S00</a>	
<a href="#">YT-1000RDN521S11</a>	POSITIONER
<a href="#">YT-1000RDM531S00</a>	oroline valve
<a href="#">Typ YT-405</a>	check valve
<a href="#">SR-YT-3300RDN5200S</a>	electro-pneumatic positioner
<a href="#">YT-1000RDC121H02</a>	Electro-Pneumatic Positioner - YT-1000R - Rotary
<a href="#">YT-3350LSI1221S</a>	Positioner, SMART
<a href="#">YT-1000RDN131H00</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000RDM131S01</a>	Electro-Pneumatic Positioner
<a href="#">YT-3300LDN1421S</a>	
<a href="#">YT-1200LD132S0</a>	PNEUMATIC POSITIONER
<a href="#">H0320F-0055</a>	Volume booster Kit YT-320 N2
<a href="#">YT-3300 LSI 3200S</a>	Smart Positioner
<a href="#">YT-200AN211</a>	Filter Regulator
<a href="#">YT-220BN211</a>	Filter Regulator
<a href="#">G1/4//YT-2501LSI2321S1</a>	Intelligent Positioner
<a href="#">YT-1000RSN132S15</a>	Electro-Pneumatic Positioner
<a href="#">H0310F-0090</a>	Kit
<a href="#">YT-3303LSI3421S</a>	Valve Positioner
<a href="#">YT-2500RSN1104S</a>	Positionneur Intelligent
<a href="#">YT-3300RDI5204S</a>	Intelligent Positioner
<a href="#">YT-3300RSN5401S</a>	
<a href="#">YT-1000RDN532S00</a>	
<a href="#">YT-1000RSM131S00</a>	
<a href="#">YT-3300LSI1421S</a>	Intelligent Positioner
<a href="#">YT-3450RSC2221L</a>	smart positioner
<a href="#">YT-3450LSC2221L</a>	smart positioner
<a href="#">YT-3303RSN1220S</a>	Positioner
<a href="#">YT-2500RDI2121S</a>	POSITIONER DOUBLE ACTING
<a href="#">YT-3450RSC5220S</a>	
<a href="#">YT-3450LSC1220S</a>	
<a href="#">YT-3450LDC1220S</a>	
<a href="#">YT-3450RDC5220S</a>	
<a href="#">YT-3400LSC1220S</a>	
<a href="#">YT-3400RSC5220S</a>	
<a href="#">YT-3400RDC5220S</a>	
<a href="#">YT-3300RSI5221S</a>	
<a href="#">YT-3303RSN1201S</a>	

Product	Description
<a href="#">YT-3400RDC5103S</a>	
<a href="#">YT-3400LDC1220S</a>	
<a href="#">YT-850M1X0</a>	LIMIT SWITCH BOX
<a href="#">YT-3303LSN2421S</a>	
<a href="#">YT-3300 LDI 3101S</a>	
<a href="#">YT-405-DN1</a>	
<a href="#">YT-3303 LSN 2221S</a>	
<a href="#">BR-3303L/N</a>	
<a href="#">YT-3400 RDC 1101S</a>	
<a href="#">YT-310N3</a>	Booster Relay
<a href="#">YT-3400RDC5221S</a>	
<a href="#">YT-1000RSM532S10</a>	
<a href="#">YT3400LSC1420S</a>	
<a href="#">YT-3303LSIX221S</a>	position transmitter
<a href="#">YT-3300RDI5101S</a>	smart positioner
<a href="#">YT-3300RDN5200S</a>	
<a href="#">YT-1000LSI111S0</a>	Electro Pneumatic Positioner
<a href="#">YT-870M311</a>	
<a href="#">YT-3400RSC1220S</a>	
<a href="#">YT-305N3</a>	
<a href="#">YT-325N3</a>	
<a href="#">YT-3300LSN0220S</a>	SMART POSITOR
<a href="#">YT-1000RDN131S14 DA</a>	
<a href="#">YT-1000RDN131S14 RA</a>	
<a href="#">YT-3303RDN2101S</a>	Electro-Pneumatic Positioner
<a href="#">YT-1000LSM131S00</a>	MEDICAL POSITIONER
<a href="#">YT1000 RDN131S13RA</a>	
<a href="#">YT-1000RDN512S00</a>	Electropneumatic positioner
<a href="#">YT 3400LDC 3221S</a>	ELECTRO PNEUMATIC POSITIONER
<a href="#">YT 3400LSC 2221S</a>	ELECTRO PNEUMATIC POSITIONER
<a href="#">YT 3400LDC 2221S</a>	ELECTRO PNEUMATIC POSITIONER