







93 S Railroad Avenue Unit C Bergenfield NJ 07621 USA www.enapart.com sales@enapart.com



Via del Canneto 35. Borgosatollo, Brescia - Italia www.enapart.it vendite@enapart.it



Barbaros Mah. Ihlamur Bul. Ağaoğlu My Newwork No:3/15 Ataşehir / İstanbul www.enapart.net satis@enapart.net



PRIVADA 10 B SUR #3908 COL. ANZUREZ, C.P. 72530, PUEBLA, PUE www.enapart.com.mx sales@enapart.com.mx



Friedrich-Ebert-Anlage 36, 60325 Frankfurt am Main, Germany www.enapart.de anfrage@enapart.de



4 boulevard Carnot, 95400 villiers-le-bel, Paris, France www.enapart.fr sales@enapart.fr



65049, ОДЕСА, ВУЛИЦЯ ІВАНА ФРАНКА, БУДИНОК 55, ПОВЕРХ 3 www.enapart.com.ua sales@enapart.com.ua



MUNICIPIUL BUCUREŞTI, SECTOR 3, B-DUL BASARABIA, NR.250, CORP P+5 Hempstead, HP1 3AF , United Kingdom www.enapart.ro sales@enapart.ro



〒584-0023 大阪府富田林市若松町 東2丁目2番16号 www.enapart.co.jp sales@enapart.co.jp



PLAZA NUESTRA SEÑORA DE LAS NIEVES 12 ,LOCAL ,50012,ZARAGOZA www.enapart.es ventas@enapart.es



Складова база "Онгъл", Склад А2, п.к. 4006, гр. Пловдив, България www.enapart.bg sales@enapart.bg



3 Austin Mews, High Street, Hemel www.enapart.co.uk sales@enapart.co.uk





Vaisala

Enapart always strives to provide the competitive prices and timings of supplies for its customers. We sell only original equipment and spare parts, although we are not always the official distributor or manufacturer's dealer. All displayed trademarks and part numbers are the property of their respective owners.

BRAND'S PRODUCTS

Product	Description
<u>1434WA</u>	Sensor Board WAV15x Sensors
<u>16644WA</u>	Service Kit for Wind Sensors
HMT310 5A5A1BCX14BJAA1A2	Premium sensor
DMT143-G1C1A1A0A0ASA	
<u>DMT348</u>	Transmissor
DRD11A	Precipitation Detector
<u>GM45237SP</u>	Protective Sleeve for GMP222
GMP222 (B0N0 CO2 PROBE)	
P/N: HM70, Type: B1B1A0AA	Portable humidity and temperature meter
<u>HMP155E1AA11A0B2A1B0A</u>	Humidity and temperature sensor
HMT330 3E0A001BCAB200A0CAABAA1	Humidity and temperature sensor
HMT120 TD0AXA11A2A0Z	Humidity and temperature transmitter
HMT120 KB1A1B12A1Z0Z	Humidity and Temperature Transmitter, ±1.5 %RH, 420 mA
HMT330 3E0B141BCAD100A0AAAAAA1	Humidity and temperature transmitter
HMT360 1D22BCE1A2BA5A10	SENSOR
MM70F1A1A5A1A0A2B0	Handheld Moisture and Temperature Meter
PTB330 A1AAHAAPEB0A0B	digital barometer
PTU30011801A1BCAF1A4A1FAE0B0A	Pressure, Humidity and Temperature Transmitter
PTU300 12A01C1BCPF1A0A1BAB0B0A	(Pressure, humidity and Measured temperature transmitter)
PWD Weather/visibility sensor	Visibility sensor
<u>WAA151</u>	Windgeschwindigkeitssensor WAA151
<u>WSP150</u>	Surge Protector no Connectors
<u>ZZ45036</u>	sensor cable
<u>ZZ45037</u>	sensor cable
<u>ZZ45048</u>	Signal cable 16 x 0.25 mm2
HMT330 -340B101CHAH100A01ACBAA1	TEMPERATURE TRANSMITTER
GMW93R	CO2+RH+T transmitter Voltage output
GMW94R	CO2+RH+T transmitter Current output
<u>219690</u>	USB cable
<u>HUMICAP180R</u>	Humidity sensor
<u>QMT110</u>	Temperature sensor
HMT 330 340A021CBAX100A01ACBAA1	Temperature Sensor
HM70A0C1A0AA	Humidity and Temperature Probe
HMD60U	Humidity Transmitter

Enapart Group ! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom





DM70F5B1A3B1 Hand-held Dewpoint and Temperature Meter set with carrying case for Desicoant Dryers DM70F5A1A3B1 Hand-held Dewpoint and Temperature Meter HM7360 4022HHK1A2BE5A3K HM7360 4022HHK1A2BE5A3K Measuring device for humidity and temperature HM7360 1A0A101BCAB100AAAABAA1 Feuchte und Temperaturmesswertgeber External power supply module External power supply module HM7360 1A0A101BCAB100A11ABAA1 Feuchte und Temperaturmesswertgeber WXF530 6C1B2A3D2B1B Weather Transmitter WXT530 6C1B2A3D2B1B Weather Transmitter WXT530 6C1B2A3D2B1B Transmitter Spare Part Transmitter Spare Part United WXT520 AAD1BE31B0 Weather Transmitter Spare Part Service Kit WXF520 AAD1BE31B0 Weather Transmitter Spare Part Differential Pressure (±/- 60Pa.) 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter Spare Part Differential Pressure (±/- 60Pa.) 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter Spare Part Differential Pressure (±/ 60Pa.) 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter Spare Part Dewpoint sensor Part Service Kit WXT520 AAD1BE31B0 Weather Transmitter United Service Kit WXT530 6C4B1A2B2B1B Dewpoint sensor Dewpoint sensor Part Service Kit WXT530 6C4B1A2B2B1B Dewpoint sensor Part Service Kit WXT530 6C4B1A2B2B1B AAD1A2B2B1B AAD1A2B2 Part Service Kit WXT530 6C4B1A2B2B1B AAD1A2B2 Part Service Kit WXT530 Fervice Kit WXT530 6C4B1A2B2B1B AAD1A2B2 Part Service Kit WXT530 6C4B1A2B2B1B2B2B2B2B2B2B2B2B2B2B2B2B2B2B2B2	Product	Description
HMT330.1A0A121BCAB100A0AABAA1 POWER-1 External power supply module HMT330.1A0A101BCAB100A1AABAA1 Feuchte und Temperaturmesswertgeber External power supply module HMT330.1A0A101BCAB100A11AABAA1 WXT530.2C1BEA3D1B1B WXT530.6C1B2A3D1B1B WXT530.6C1B2A3D2B1B WXT530.6C1B2A3D2B1B Transmitter PDT101.P4C DDT101.P4C DIfferential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included WXT520.AAD1BE31B0 WXT520.AAD1BE31B0 Weather Transmitter 16644WA Service Kit WXT520.AAB1BC10B0 Wettermesswertgeber HM70D0A1A0DE HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät HM7335 GMT222.GQA1B0NXA0A CC2 Transmitter WXT530.BCAB1A2B2B1B QML201C AWS Logger MAWS WXT530.BCAB1A2B2B1B AWS Logger MAWS WXT530.BCAB1A2B2B1B AWS Logger MAWS WAT530.BCAB1A2B2B1B AWS Logger MAWS Wather Transmitter HMT331 Raumfühler zur Wandmontage HUMIGAP1B012 HMMGAP1B012 HAMP10.V00C2C1A0 HMT10.V00C2C1A0 HMT10.V0CCC1A0 HMT10.V0CCC1A0 HMT130.BCAB1B1BA1AACAA1 GMM22 HMM330.BW0F1450CAL.100A02DMBAA1 AGT420 A	<u>DM70F5B1A3B1</u>	
HMT330_IA0A121BCAB100A0AABAA1 Feuchte und Temperaturmesswertgeber External power supply module	<u>DM70F5A1A3B1</u>	Hand-held Dewpoint and Temperature Meter
POWER-1 HMT330 1A0A101BCAB100A11AABAA1 Feuchte und Temperaturmesswertgeber WXT530 AC1B2A3D1B1B WXT530 BC1B2A3D2B1B GLT321SP CLT321SP PDT101-P4C Differential Pressure (+/- 6px). 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter WXT520 AAD1BE31B0 Weather Transmitter WXT520 AAD1BE31B0 Weather Transmitter 16644WA Service Kit WXT520-AAB1BC10B0 HMT0D0A1A0DE Portables Feuchte- und Temperaturmessgerät HMP235 - E2A1A1AA32A1A3B Dewpoint sensor HMT331 GAM222 G0A1B0NXA0A WXT536 6C4B1A2B2B1B AWX Logger MAWS WXT536 GAB1A2B2B1B AWX Logger MAWS WXT536 HMT331 Raumfühler zur Wandmontage HUMICAP180L2 HMT331 Raumfühler zur Wandmontage HUMICAP180L2 HMM2 HMT30 6R0K1A111A1A001E2D6K00 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMT330 AX0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber MMT330 8W0F145QCAL100A02DMBAA1 AOT420 AIF QUality Transmitter for Oil AIF QUAlity Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 HMT330 SN0B101GCAF10A01CGBAA1 HMT330 SN0B101GCAF10A01CGBAA1 HMT315 / 5A5A1BCX18H11A1A2 AQT420 10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. Ultrasonic Wind Sensor Miniature Dew Point Transmitter HMT330 3E0B101XCAX100A0AAACAA1	HMT360 4D22HHK1A2BE5A3K	Measuring device for humidity and temperature
HMT330 1A0A101BCAB100A11AABAA1 WXT530 2C1B2A3D1B1B WXT530 6C1B2A3D2B1B CLT321SP CLT321SP Transmitter Spare Part PDT101-P4C Differential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 16844WA Service Kit WXT520-AAB1BC10B0 HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät HMP235 - E2A1A1AA32A1A3B Dewpoint sensor HMT335 GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT530 6C4B1A2B2B1B GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B GML201C AWS Logger MAWS WXT536 WSAT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A02) HMP155 A2GB13A0A2A1A0A HMT1330 / BX0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A DMT152A1CBB10A010A1A DMT152A1CBB10A010A1A AGM22 HMT330 SW0F145COAL100A02DMBAA1 HMT330 WOST145COAL100A02DMBAA1 HMT330 WOST145COAL10A01CGBAA1 HMT315 // 5A5A1BCX14BH1A1A2 AOT420 IN AGM22 UItrasonic Wind Sensor DMT143 G1CB1A30ASX HMT9F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	HMT330 1A0A121BCAB100A0AAABAA1	Feuchte und Temperaturmesswertgeber
WXT530 2C182A3D1B1B Weather Transmitter WXT530 6C182A3D2B1B air sensor CLT321SP Transmitter Spare Part PDT101-P4C Differential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter 16644WA Service Kit WXT520-AAB1BC10B0 HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät HMP235 - E2A1A1AA32A1A3B Dewpoint sensor HMT335 GMT222 G0A1B0NXA0A CO2 Transmitter QML201C AWS Logger MAWS WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT530 HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 HMM1331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 HMT30 FROMKIA111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A02) HMP155 A2GB13A0A2A1A0A HUMICAP180A1A0A010A1A GMM222 HMT330 Transmitter GMM222 HMT330 MMT330 8WDH10BCAD100A0ADNGAA1 AC1420 A	POWER-1	External power supply module
WXT530 6C182A3D2B1B CLT321SP Transmitter Spare Part PDT101-P4C Differential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter 16644WA Service Kit WXT520-AAB1BC10B0 HM70D0A1A0DE HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät HMP235 - E2A1A1AA32A1A3B Dewpoint sensor HMT335 GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HMM1331 Raumfühler zur Wandmontage Feuchtesensor HM42 HAM1331 Haunfühler zur Wandmontage Feuchtesensor HM42 HAM1301 Feuchtesensor HM42 HAM1301 Feuchtesensor HM9110 V00C2C1A0 HM7120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMM1330 / 8X0B101BCAD100A0ADNGAA1 GMM222 HMT330 / 8X0B101BCAD100A0ADNGAA1 AT aupunktmesswertgeber MMT330 8W0B101BCAD100A0ADNGAA1 AT aupunktmesswertgeber MMT330 8W0B101BCAD100A0ADNGAA1 Feuchte und Temperature Meter HMT330 5N0B001GCAF100A01CGBAA1 HMT330 5N0B001GCAF100A01CGBAA1 HMT330 5N0B001GCAF100A01CGBAA1 HMT315 // 5A5A1BCX14BH1A1A2 AQT420 AQT420 AQT420 AI QUilty Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperature Meter Vollutant Gases and Particulate Matter HMT315 // 5A5A1BCX14BH1A1A2 AQT420 II pcs) 22608 WXTPTUSP PTU-Module Spare Part for the WXT530 series. MXTPTUSP PTU-Module Spare Part for the WXT530 series. MMT330 3E0B101XCAX100A0AAACAA1	HMT330 1A0A101BCAB100A11AABAA1	Feuchte und Temperaturmesswertgeber
CLT321SP PDT101-P4G Differential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter 16644WA Service Kit WXT520-AAB1BC10B0 HM700A1A0DE HM700A1A0DE HM7335 GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B QML201C WXT536 Weather Transmitter HM7331 Raumfühler zur Wandmontage HUMICAP180L2 HUMICAP180L2 HUMICAP180L2 HAM1330 HM710 V0002C1A0 HM7110 V0002C1A0 HM7120 (KA1A1B12A1A02) HM7155 A2GB13A0A2A1A0A HM7130 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A DMT152A1CBB10A010A1A Taupunktmesswertgeber MM7330 8W0F145CAL100A02DMBAA1 AOT420	WXT530 2C1B2A3D1B1B	Weather Transmitter
PDT101-P4C Differential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included WXT520 AAD1BE31B0 Weather Transmitter 16644WA Service Kit Service Kit WXT520-AAB1BC10B0 Wettermesswertgeber HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät Dewpoint sensor HM7335 E2A1A1AA32A1A3B Dewpoint sensor HM7335 GM7222 G0A1B0NXA0A CC2 Transmitter WXT530 6C4B1A2B2B1B AWS Logger MAWS WXT536 Weather Transmitter HM7331 Raumfühler zur Wandmontage HUMICAP18012 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DM7340 6R0K1A111A1A001E2D6K0C0 Dry Sensor HMP110 V0002C1A0 Humidity and temperature probe HM7130 / 8X0B101BCAD100A0ADNGAA1 Humidity and Temperature Meter DM7152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HH71330 Transmitter MM7330 8W0F145QCAL100A01CGBAA1 Moisture and Temperature Transmitter for Oil AOT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HM7315 // 5A5A1BCX18BH1A1A2 AQT420 II Probable Spare Part for the WXT530 series. 121792 Uttrasonic Wind Sensor DM1143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HM730 380B101XCAX100A0AAACAA1	WXT530 6C1B2A3D2B1B	air sensor
WXT520 AAD1BE31B0 16644WA Service Kit WXT520-AAB1BC10B0 Wettermesswertgeber HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät HMP235 – E2A1A1AA32A1A3B Dewpoint sensor HMT335 GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B OML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A02) HMP155 A2GB13A0A2A1A0A HMM1330 (AR0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A GMM222 HMT330 MMT330 SW0F14SCGAL100A02DMBAA1 AQT420 AQT420 AIR QUAINTY Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 HMT330 5N0B001GCAF100A01CGBAA1 HMT330 5N0B001GCAF100A01CGBAA1 HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 12792 Ultrasonic Wind Sensor MMT330 3E0B101XCAX100A0AAACAA1	CLT321SP	Transmitter Spare Part
16644WA	<u>PDT101-P4C</u>	Differential Pressure (+/- 60Pa.). 4-20mA. Tubing & wiring not included
WXT520-AAB1BC10B0 HM70D0A1A0DE Portables Feuchte- und Temperaturmessgerät HMP235 – E2A1A1AA32A1A3B Dewpoint sensor HMT335 GMT222 GOA1B0NXA0A CC2 Transmitter WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 HAM1331 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145OCAL100A02DMBAA1 AQT420 AQT420 AQT420 AQT420 AQT420 AGM22 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor HMT330 3 50B010XCAX100A0AAACAA1	WXT520 AAD1BE31B0	Weather Transmitter
HM70D0A1A0DE Portables Feuchte- und Temperaturmessgeråt HMP235 – E2A1A1AA32A1A3B Dewpoint sensor HMT335 GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 Dry Sensor HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) Humidity and Temperature probe HMT330 / 8X0B101BCAD100A0ADNGA41 Taupunktmesswertgeber GMM222 HMT330 / BWOF145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT315 / 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. LMT330 3C0B101XCAX100A0AAACAA1 HMT330 3C0B101XCAX100A0AAACAA1	<u>16644WA</u>	Service Kit
HMP235 – E2A1A1AA32A1A3B HMT335 GMT222 GOA1BONXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B QML201C WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 HAM2 HAM11A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT340 6R0K1A11A1A01A01E2D6K0C0 HMP155 A2GB13A0A2A1A0A HUMICH WANDMONTANA MMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A GMM222 HMT330 MMT330 8W0F145QCAL100A02DMBAA1 AQT420 AQT420 AQT420 AGT420 AGT	WXT520-AAB1BC10B0	Wettermesswertgeber
HMT335 GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 GC4B1A2B2B1B QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A Humidity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 Taupunktmesswertgeber GMM222 HMT330 WOF145QCAL100A02DMBAA1 MOISture and Temperature Transmitter for Oil AQT420 HMT330 SNOB001GCAF100A01CGBAA1 Feuchte und Temperaturesswertgeber HMT330 5NOB001GCAF100A01CGBAA1 Feuchte und Temperaturesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HMT0F4A1A0DB HMT30 3CB0B101XCAX100A0AAACAA1	HM70D0A1A0DE	Portables Feuchte- und Temperaturmessgerät
GMT222 G0A1B0NXA0A CO2 Transmitter WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K13111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A02) HMP155 A2GB13A0A2A1A0A HUMIdity and temperature probe HMT330 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F1450CAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 GIC1B1A3A0ASX Miniature Dew Point Transmitter	HMP235 – E2A1A1AA32A1A3B	Dewpoint sensor
WXT530 6C4B1A2B2B1B QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 MMT330 8W0F1450CAL100A02DMBAA1 MOISture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 GICIB1A3A0ASX Miniature Dew Point Transmitter	<u>HMT335</u>	
QML201C AWS Logger MAWS WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A Humidity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 Humidity and Temperature Meter DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter	GMT222 G0A1B0NXA0A	CO2 Transmitter
WXT536 Weather Transmitter HMT331 Raumfühler zur Wandmontage HUMICAP180L2 Feuchtesensor HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 A0T420 AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturenesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter	WXT530 6C4B1A2B2B1B	
HUMICAP180L2 HUMICAP180L2 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A GMM222 HMT330 MMT330 8W0F145QCAL100A02DMBAA1 AQT420 HMT330 5N0B001GCAF100A01CGBAA1 HMT330 / SA5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX HMT330 3E0B101XCAX100A0AAACAA1	<u>QML201C</u>	AWS Logger MAWS
HUMICAP180L2 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 Dry Sensor HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HUMIdity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter	<u>WXT536</u>	Weather Transmitter
HM42 Handheld Humidity and Temperature Meter with Probe DMT340 6R0K1A111A1A001E2D6K0C0 Dry Sensor HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A Humidity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 Humidity and Temperature Meter DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HMT0F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	<u>HMT331</u>	Raumfühler zur Wandmontage
DMT340 6R0K1A111A1A001E2D6K0C0 HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMMI330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 AQT420 AQT420 HMT330 5N0B001GCAF100A01CGBAA1 HMT335 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	HUMICAP180L2	Feuchtesensor
HMP110 V00C2C1A0 HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMMP155 A2GB13A0A2A1A0A HUMIdity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HMT0F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	<u>HM42</u>	Handheld Humidity and Temperature Meter with Probe
HMT120 (KA1A1B12A1A0Z) HMP155 A2GB13A0A2A1A0A HMMIdity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 Humidity and Temperature Meter DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		Dry Sensor
HMP155 A2GB13A0A2A1A0A Humidity and temperature probe HMT330 / 8X0B101BCAD100A0ADNGAA1 Humidity and Temperature Meter DMT152A1CBB10A010A1A Taupunktmesswertgeber GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT335 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	<u>HMP110 V00C2C1A0</u>	
HMT330 / 8X0B101BCAD100A0ADNGAA1 DMT152A1CBB10A010A1A GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HMT330 3E0B101XCAX100A0AAACAA1		
DMT152A1CBB10A010A1A GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HMT330 3E0B101XCAX100A0AAACAA1	HMP155 A2GB13A0A2A1A0A	Humidity and temperature probe
GMM222 HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	HMT330 / 8X0B101BCAD100A0ADNGAA1	· · · · · · · · · · · · · · · · · · ·
HMT330 Transmitter MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1	<u>DMT152A1CBB10A010A1A</u>	Taupunktmesswertgeber
MMT330 8W0F145QCAL100A02DMBAA1 Moisture and Temperature Transmitter for Oil AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		
AQT420 Air Quality Transmitter for Pollutant Gases and Particulate Matter HMT330 5N0B001GCAF100A01CGBAA1 Feuchte und Temperaturmesswertgeber HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		
HMT330 5N0B001GCAF100A01CGBAA1Feuchte und TemperaturmesswertgeberHMT315 // 5A5A1BCX14BH1A1A2AQT420 (10 pcs)226068WXTPTUSPPTU-Module Spare Part for the WXT530 series.212792Ultrasonic Wind SensorDMT143 G1C1B1A3A0ASXMiniature Dew Point TransmitterHM70F4A1A0DBHMT330 3E0B101XCAX100A0AAACAA1		
HMT315 // 5A5A1BCX14BH1A1A2 AQT420 (10 pcs) 226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		
AQT420 (10 pcs) 226068 PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		Feuchte und Temperaturmesswertgeber
226068 WXTPTUSP PTU-Module Spare Part for the WXT530 series. 212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		
WXTPTUSPPTU-Module Spare Part for the WXT530 series.212792Ultrasonic Wind SensorDMT143 G1C1B1A3A0ASXMiniature Dew Point TransmitterHM70F4A1A0DBHMT330 3E0B101XCAX100A0AAACAA1	· · ·	
212792 Ultrasonic Wind Sensor DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		
DMT143 G1C1B1A3A0ASX Miniature Dew Point Transmitter HM70F4A1A0DB HMT330 3E0B101XCAX100A0AAACAA1		·
<u>HM70F4A1A0DB</u> <u>HMT330 3E0B101XCAX100A0AAACAA1</u>		
HMT330 3E0B101XCAX100A0AAACAA1		Miniature Dew Point Transmitter
MMT330 8V0F101CQAE100A02DNBAA1 Moisture and Temperature Transmitter		
	MMT330 8V0F101CQAE100A02DNBAA1	Moisture and Temperature Transmitter

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom! RADWARD LTD United Kingdom





Product	Description
HMP110C15A0C3A0	
DMT143 N1C1B1A3A0ASX	
WAC155CB	Component Board
4H0B001BCAK100A0ACEBAA1 (HMT330)	Premium Humidity and Temperature Transmitter with metal enclosure
MMT330 2D0F121CQQC123A32DABAA1	Transducers for oil humidity and temperature with cable probes
HMP46	Thermohygrometer
<u>GMP222</u>	CO2 Probe (ppm)
HMT360	HumudityTempTransmitter
HMP155 A4JC11A0A0A1A0A	
WSP152	
HMT330 7S1D001GXCX103A0DAABAA1	Humidity and temperature sensor
WXT530 6A1A1A1A1B	Weather transmitter
8V0F121CPQL143C12E3BBA1	
<u>GMP222G0N0</u>	
<u>WA15D7B</u>	Wind sensor component set
<u>219687</u>	Transfer cable
WM30 C1BA	
<u>15778HM</u>	
<u>PDT102-P2V</u>	
HMT120 (KC0A1F12A2A0Z)	
<u>DM70 / B0B1A3B1</u>	Hand-Held Dewpoint Meter
DM70 A0B0A0A0	Portable dew point meter
DMT143L1CAA1A010ASX	DMT143 Transmitter
DMT143R1CAAFA011ASX	DMT143 Transmitter for Low Dewpoint
HMS82W	
HMD62	Temperature Transmitter
<u>HM70A0E1A0AA</u>	probe
DMT143 G1C1A1A3A0ASX	Miniature Dew Point Transmitter
DTR503A	Radiation Shield
HMP155 /A2JB11A0A0A1A0A	Humidity and temperature probe
Rosa DR322SYS	weather station with data logger
<u>DRS511AB15</u>	Road and runway surface with a cable
<u>DTS12G3</u>	Ground/Soil temperature probe
<u>WA15</u>	Wind set
DMT143 N1C2D1X4S0ASX	Transmitter for Low Dewpoint
<u>HPP272</u>	Hydrogen Peroxide, Humidity and Temperature Probe
WXT530 6C1B1A3D1B1B	Weather Transmitter WXT530 Series
PTB330 B1AEJAACEB0A0B	Digital Barometer
HMP110A15A1C3B0	Probe
<u>HMP60</u>	Sensor
MMT330 (7S0F141QCAL100C02EKBAA1)	Moisture in Oil and Temperature Transmitter with Remote Probes
<u>HM47280SP</u>	Filter
HMT330 3E0B101XCAG100A0AACBAA1	Premium Humidity and Temperature Transmitter with metal enclosure

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom

! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Vaisala Page 3 / 9





Product	Description
HMP360 3B5A1B2	Humidity and Temperature Probe
PTB210 A1B3B	Outdoor Barometer with RS232, RS485, 0-5 or 0-2.5V outpu
<u>SPH210</u>	static pressure head
SPH20	Static Pressure Head
HMT310 FC5A1NRA17CRGG1B2	Humidity and Temperature Transmitter
HMT330 1A0B001BCAF100A0AAABAA1	Humidity and Temperature Transmitter
HMT330 3E0B101BCAC100G0AAABAA1	Humidity and Temperature Transmitter with Remote Probe
DMT340 6R0K1C121A1A001A2D6K4C0	Dew point and temperature transmitter
HMP60 A12A0A2B0	INTERCAP Humidity and Temperature Probe
HMP9	Compact Humidity and Temperature Probe
HMP360 1A5A1A4	Humidity and Temperature Transmitter
HMT360 1A22BCA2A4BA5A10	Humidity and Temperature Transmitter
CLB311-230SP	Window Blower
<u>DRW010276SP</u>	Sensor protective grid
HMT330 3E0B015BCAG100A0ACABAA1	Premium Humidity and Temperature Transmitter
HMT330 3G0B111DCAF100A0ACCBAA1	Feuchte und Temperaturmesswertgeber
HMT318 (8A5A1BCJ14BSAC1M2)	Premium Humidity and Temperature Transmitter
GMP251 A2B0C1C1	Carbon Dioxide Probe, GMP251 CO2 series
GMP251 A2B0C1C1	Carbon Dioxide Probe GMP251,CO2
WXT530 6C1B2A1D1B1B	weather sensor
1A22BCA1B2BA5A10 (HMT360)	Messgerät für Feuchte und Temperatur
<u>212483</u>	EX food separator
<u>210664</u>	Sicherheitsbarriere
<u>214101</u>	
JUNCTIONBOX-8	Junctionbox-8 Junction Box With 8-contacts Klemens
WXT530, Order code: 6B1B1A3B2B1B	WXT530 series weather sensor
<u>WAC151</u>	Sensor support arm including terminal box WAC151
<u>HMP360 325A104</u>	Humidity and temperature transmitters
HMT 360 3A22BCD1A4B25A10	Humidaity and Temperature Transmitter
<u>DSC211</u>	Remote Road Sensor
<u>HMT 140</u>	Data Logger
<u>GMP343</u>	Junction Box with 8 contacts
GMD20	Transmitter
HMT360 (p/n 1A22BCA1B2BA5A10)	Humidity and Temperature transmitter with Sensor Probes
PTU300-11A01A0AAAA1A4ABAE0B3A	Pressure, Humidity and Temperature Transmitter
<u>MI70</u>	Indicator Only w/ Rechargeable Battery System
<u>PTB330</u>	Digital Barometer
HMP155 // A2AB12A4A4A1D0A	Humidity & Temp Probe
<u>DM70 B5A1A3B1</u>	Portable dew point meter
PTU 303 (32D01A1BCPB1A0A1B1B0B0A)	Pressure, humidity and temperature transmitter
HMT330 (340A141BCAD100A0CAABAA1)	Humidity and temperature transducers
<u>DM70 B5A0A4B1</u>	Handheld Dewpoint Meter for Spot-Checking Applications
<u>HM70 B4A1A0DB</u>	Portable Humidity and Temperature Meter

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom! RADWARD LTD United Kingdom





HMD65 TS1D021XCAB200A0EAQBAA1 Premium Humidity and Temperature Transmitter HM70 B0D1A0AB Handheld Humidity and Temperature Meter HM70F4E1A0DB Multi-Sample HMP360 HUMIDITY AND TEMPERATURE MEASURING DEVICE HMP110 HMP100 HEMPAGE HM46670SP Total Stainless Steel Filter, Male Thread HM7300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 Total Stainless Steel Filter Probe HMP77 Total Stainless Cable Humidity Probe DMPX Dew point and temperature Meter 215619 HMT300 A022BCG1A2B15A1B HMM1300 A020A0C1B0 HMT300 350B101XCAL100A0AACBAA1
HM70 B0D1A0AB Handheld Humidity and Temperature Meter HM70F4E1A0DB Multi-Sample HMP360 temperature humidity meter HM40S HUMIDITY AND TEMPERATURE MEASURING DEVICE HMP110 temperature/humidity sensor 17086SP temperature sensor for HMD60Y Vaisala HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HM70F4E1A0DB Multi-Sample HMP360 temperature humidity meter HM40S HUMIDITY AND TEMPERATURE MEASURING DEVICE HMP110 temperature/humidity sensor 17086SP temperature sensor for HMD60Y Vaisala HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HM70F4E1A0DB Multi-Sample HMP360 temperature humidity meter HM40S HUMIDITY AND TEMPERATURE MEASURING DEVICE HMP110 temperature/humidity sensor 17086SP temperature sensor for HMD60Y Vaisala HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HMP360 temperature humidity meter HM40S HUMIDITY AND TEMPERATURE MEASURING DEVICE HMP110 temperature/humidity sensor 17086SP temperature sensor for HMD60Y Vaisala HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HM40S HUMIDITY AND TEMPERATURE MEASURING DEVICE HMP110 temperature/humidity sensor 17086SP temperature sensor for HMD60Y Vaisala HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
17086SP temperature sensor for HMD60Y Vaisala HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HM46670SP Sintered Stainless Steel Filter, Male Thread HMT300TMK MOUNTING KIT HMP76 Relative Humidity Measurement Probe HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HMT300TMKMOUNTING KITHMP76Relative Humidity Measurement ProbeHMP775 Meter Extension Cable Humidity ProbeDMPXDew point and temperature probe245931HMT360 3A22BCG1A2B15A1BHMT360 3A22BCG1A2B15A1BHumidity and Temperature Meter215619Duct kitHMP110V00A0C1B0
HMT300TMKMOUNTING KITHMP76Relative Humidity Measurement ProbeHMP775 Meter Extension Cable Humidity ProbeDMPXDew point and temperature probe245931HMT360 3A22BCG1A2B15A1BHMT360 3A22BCG1A2B15A1BHumidity and Temperature Meter215619Duct kitHMP110V00A0C1B0
HMP77 5 Meter Extension Cable Humidity Probe DMPX Dew point and temperature probe 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
DMPX 245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
245931 HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
HMT360 3A22BCG1A2B15A1B Humidity and Temperature Meter 215619 Duct kit HMP110V00A0C1B0
<u>215619</u> Duct kit <u>HMP110V00A0C1B0</u>
HMP110V00A0C1B0
HMT330 350B101XCAL100A0AACBAA1
DMT143G1C1A1B3A0ASA Miniature Dew Point Transmitter
DMT143 G1G1A1A3A0ASX Miniature dew point sensor
GMP222C0N0 Probe
HM40 D1BB Humidity and Temperature Meter
HMW92D Humidity and Temperature Transmitter
DMT340 6Q0K0A112A1A001A2D6K0C0 Low Dew Point Transmitter
219452SP Sintered PTFE Filter, Female Thread
DL1700SP Thermocouple Data Logger
HMT360 3A12BCD2A4B11A10
HMT330 7T0B101BCAL100A0CALKAA1 hydrometer
DMT143 G1C1A1D3A0ASX Miniature Dew Point Transmitter
WXT530 4C1B1A2D1B1A Transmitter
HMT3301A0B101BCAB200A0ACABAA1 Temperature Transmitter with Integral Probe, with Display
DRW010335SP Sintered filter Ø12 x 20
PTB330 A0AAHAAFEB5A01 Digital Barometer
MI70 C10 Measurement Indicator
MMT162 Sensor for oil humidity and temperature
PDT101-W4C2 Differential Pressure Transmitter
HMM100 45A2DE Humidity Module
HMW93
HMP1 Temperature Probe
HMP1 Temperature Probe AQT530 Air Quality Transmitter
AQT530 Air Quality Transmitter

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom! RADWARD LTD United Kingdom





Product	Description
TMD62	
INTERCAPSET-10PCS	Intercap Sensor Spare Part
P/N: R73000350 Type: DSP111	Surface Patrol with display and digital output
P/N: 340B001CBAL100A0ACCBAA1, Type:	· · · · · · · · · · · · · · · · · · ·
<u>HMT330</u>	Transducers
HM46PROBE	
HTM10SP	Humidity and Temperature Replacement Module
HMS82	Outdoor Humidity and Temperature Transmitter
HMT310 5B5A1BCX14BJDA1A2	premium humidity and temperature transmitter
<u>DM70F0B1A3A1</u>	
<u>WXT530</u>	Weather sensor series WXT530
HM40 D2BB	Hand-held Humidity and Temperature Meter
WMT700 3A1A2B003B1A2	ultrasonic wind sensor series WMT700
<u>HA0C1A022A1A0Z</u>	Humidity Transmitter
<u>DRW010525SP</u>	Grid Filter
WMT701 B1A0C3EDB1B1	Ultrasonic wind sensor series
<u>DMT345</u>	Dewpoint Transmitters
<u>DMT346</u>	Dewpoint Transmitters
<u>867896</u>	LED Bolt
HMS1102D0VA1NN	
<u>TMW92</u>	
DMT143 G1C1A1A0A0ASX	Miniature dew point transducer
<u>GM70 B4A1E1A2B</u>	Portable CO2 meter
HMT330 3F0B101DCAB100B0AAABAA1	humidity and temperature transmitter
<u>WMT700</u>	
<u>HMP63</u>	Vaisala INTERCAP® Humidity and Temperature Probe
<u>GMP222E0N1</u>	
HMD83	transmitter
HMT360: 7D12HLK1A2CW5A1M+210664	Humidity sensor
HM70D4D1A0AB	Handheld temperature & humidity meter
<u>221801</u>	M170 Connection cable
<u>221040</u>	USB PC connection cable
<u>2787HM</u>	membrane filter
<u>HMT315</u>	Humidity & Temperature Transmitter
<u>243261SP</u>	Probe Mounting Flange For GMP251 and GMP252
GMP252 15C0B0N1	
<u>HM41</u>	Humidity and Temperature Meter
DMT143 G1C1A1D3A0ASA	Transmitter
DMT242SC	SAMPLING CELL
DMT242SC2	SAMPLING CELL WITH SWAGELOK
<u>5A1A0A0A0A1</u>	DEW POINT AND TEMPERATURE PROBE
<u>INDIGO201 1A1B0</u>	1A1B0 transmitter analog output
Certificate of Conformity	
<u>G1C1A1A3A0ASX / DMT143</u>	

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF, United Kingdom! RADWARD LTD United Kingdom

! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Vaisala Page 6/9





Product	Description
MMT330 8V0F101CQAE100A02DABCA1	
GMP343 B1A1B0B0N0B	
INDIGO510-B1N1A1AAAN	Transmitter
242659	USB adapter
GMP25214A0B4N1	·
<u>HMP77B</u>	Sensor for Handy Humidity Thermometer
HUMICAP	Sensor
HM40	indicator
HMW110	wall mount transmitter
HMP360 (8R5A3N2)	Humidity and temperature probe
DTR504A	Radiation Shield
HMPX 7E1D0A0A0H0	Humidity and Temperature Probe
TMPX 1A1A0A0A0B0	Temperature Probe
INDIGO520 A1N1B1AAAN	Transmitter
USB2	Indigo-compatible USB Adapter
HMPX 3A2A1A0A0C0	Humidity and Temperature Probe
INDIGO520 A3N3A3AAAN	Transmitter
SP-1416-44V	
HMPX 5C1B0A0A000	Humidity and Temperature Probe
INDIGO520 A1N1A4AAAN	Transmitter
GMP251	
SHM40	Humidity and Temperature Measurement Kit
WXT53/ 6G1C1A1A1B1B	Weather sensor
HMP155 A4JB11A0A3A1A0A	Humidity and Temperature Probe
HMPX / HMP7 / 7E1B2A0A0J0	Humidity and Temperature Probe
DMPX / DMP7 / 7D1A0A0A0E0	Dew Point and Temperature Probe
INDIGO520 /A2N3B5NAAN	INDIGO520 TransmiΣer
HMP7 - 7E1B2A0A0G0	III DIG GOLO ITALISHILLON
DMP7 - 7D1A0A0A0D0	
MMT330 830E 101CPAH100C12DMAAA1	
DM70 DM70F0A1A0A1	Handheld Chew Meter
DM70 DM70F0A0A0A1	Handheld dew Meter
G1G1A1A30ASX	TRANSMITTER DEWPOINT
HMT310 5A5A1BCX14BJAC1A2	Humidity and Temperature Transmitter
PWD B5NNNNNANENNDN	Weather/visibility sensor
WXT530 / 6B1A2A1C2B1B	vvcatrici/visibility scrisor
Mounting for PWD (pole with 60 mm	
diameter)	
Mast cable 35 m, PWD sensors	
HMD82	
HMP110 V00B0C1A0	Probe
HMP155 / A2GB11A0A1A1B0A	
HMP360 / 1A5A1A2	Humidity and Temperature Probe
	process refractometer

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom

! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Vaisala Page 7/9





Product	Description
MMPX 8A1A0B1D0C0	MMPX Moisture in Oil and Temperature Probe
CBL210896-3MSP	Probe cable
TMS82	Outdoor Temperature Transmitter
DMT143	Miniature Dew Point Transmitter
HMT310 3B5A1BXA15DBAA1A2	
HMP110C15B0C3B0	
HMT330 (340B141BCAD100A0CAABAA1)	Transmitter
Indigo80 + DMP80	
ASM210856SP	MEMBRANE FILTER PC WHITE UV STABILIZED
INDIGO80 (A1A1N1N0)	Handheld Indicator
WXT530 / 6B1B1A3B1A1B	Weather Transmitter
HMT310 5B5A1BCX14BJAA1A2	Transmitter
DMP80 (BG1A5AS0)	Handheld Dew Point Probe
GMP252 (61C0B8H3)	CO2 Probe for ppm Measurements
HMM100 / 12A1CE	
HELACCRCAL-1	
PR53AC A 1 1 A 1 A 1 A 1 A 0 N	Refractometer
INDIGO520/ A3N3D0NLAN	Transmitter
<u>CG31</u>	
HMP110 / HMP110C15A2C1A0	Humidity and Temperature Probe
<u>HMP75</u>	
CLE321SP	
PTB330 A1AAHHACPB0A0B	Digital Barometer
DMT143 - L1C1A1A010ASX	Transmitter
<u>RJ45 219685</u>	
<u>HMP155</u>	Humidity & Temperature Sensor, 0-1V outputs, 3.5m cable (11.5 feet)
<u>HMP155</u> <u>HMPX 5C1B0A0A0F0</u>	Humidity & Temperature Sensor, 0-1V outputs, 3.5m cable (11.5 feet) Humidity and Temp. Probe
	· · · · · · · · · · · · · · · · · · ·
HMPX 5C1B0A0A0F0	Humidity and Temp. Probe Transmitter Transmitter
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN	Humidity and Temp. Probe Transmitter
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520	Humidity and Temp. Probe Transmitter Transmitter
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor PR53 process refractometer cable
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010 WXT535 / WXT5305G1A1A1B2B1B	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor PR53 process refractometer cable SENSOR
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010 WXT535 / WXT5305G1A1A1B2B1B WXT530 6B1B2A2B2B1B HMP50Z300SP WXT530 - 4B1B1A6D2B1A	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor PR53 process refractometer cable SENSOR Weather Transmitter Weather sensor
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010 WXT535 / WXT5305G1A1A1B2B1B WXT530 6B1B2A2B2B1B HMP50Z300SP WXT530 - 4B1B1A6D2B1A 19731HM	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor PR53 process refractometer cable SENSOR Weather Transmitter
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010 WXT535 / WXT5305G1A1A1B2B1B WXT530 6B1B2A2B2B1B HMP50Z300SP WXT530 - 4B1B1A6D2B1A	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor PR53 process refractometer cable SENSOR Weather Transmitter Weather sensor
HMPX 5C1B0A0A0F0 INDIGO520 B1N1AANAAN INDIGO520 INDIGOCABLE10m TMP1 5L0B101XCAX100A0ACGGDA1 / HMT330 HMP155 - A2JB11A0A4A1A0A 58USB2 58KWF-2205-010 WXT535 / WXT5305G1A1A1B2B1B WXT530 6B1B2A2B2B1B HMP50Z300SP WXT530 - 4B1B1A6D2B1A 19731HM	Humidity and Temp. Probe Transmitter Transmitter Probe Connection Cable (M12-M12), 10 m Temperature Probe USB adaptor PR53 process refractometer cable SENSOR Weather Transmitter Weather sensor Calibration Salt

! 3 Austin Mews, High Street, Hemel Hempstead, HP1 3AF , United Kingdom ! RADWARD LTD United Kingdom

! + 44 20 81571300 ! sales@enapart.co.uk ! www.enapart.co.uk

Vaisala Page 8/9





Product	Description
DMT143N1C1C1D4A0ASX	TRANSMITTER
<u>229104</u>	Nokeval transducer
<u>229110</u>	Nokeval programming kit
HMP110-C15C0CFB0	Humidity and Temperature Probe
GMP252 11A0A0N1	Pg/Measuring device-CO2 measuring device 1-2
HMT120 KC0A1E12C2A0Z	Humidity and Temperature Transmitter